

DPI 610E DPI 610E-IS

Portable Pressure Calibrator Instruction Manual



DPI 610E-PC



DPI 610E-SPC



DPI 610E-HC



DPI 610E-SHC

Druck.com

Copyright	© 2022 Druck Ltd. All rights reserved
-----------	---------------------------------------

Trademarks	All product names are trademarks of their respective owners
------------	---

Contents

1.	Overview	9
1.1	DPI 610E Series	9
1.1.1	Firmware Versions	9
1.2	Equipment in the Box	11
1.2.1	Pneumatic Units	11
1.2.2	Hydraulic Units	11
1.3	Specifications for DPI 610E	11
1.4	Accessories	12
1.5	Observance of Manual	12
1.6	Safety	12
1.6.1	General Safety Precautions	13
1.6.2	Operation in a Hazardous Environment	13
1.6.3	General Warnings	13
1.6.4	Electrical Warning	13
1.6.5	Pressure Warnings	14
1.6.6	Overvoltage Categories	14
1.7	Maintenance	15
1.7.1	Visual Inspection	15
1.7.2	Cleaning	15
1.7.3	Calibration	15
1.8	Service and Repair	15
1.9	Spares	16
1.10	Instrument Return	16
1.10.1	Returned Goods Procedure	16
1.10.2	Instrument Disposal	16
1.11	Packaging For Storage or Transportation	16
1.11.1	Environment	16
1.12	Preparing the Instrument	17
1.12.1	Initial Checks	17
1.13	Battery and Charging	17
1.13.1	Battery Status Indicator	18
1.14	Power ON/OFF	18
1.14.1	Power ON	18
1.14.2	Power OFF	18
1.14.3	Auto Power Down	18
1.15	Parts	19
1.15.1	Test Port	21
1.15.2	Reservoir (Hydraulic Version)	21
1.15.3	Pressure Release Valve	21
1.15.4	Electrical Connections	21
1.15.5	Handle and Shoulder Strap	21
1.15.6	Pump (Pneumatic Version)	21
1.15.7	Priming Pump (Hydraulic Version)	21
1.15.8	Volume Adjuster (Pneumatic Version)	21
1.15.9	Volume Adjuster Wheel (Hydraulic Version)	21
1.15.10	Pressure/ Vacuum Selector (Pneumatic Version)	21
1.15.11	Auxiliary Ports	21
1.15.12	External Sensor Port	21
1.15.13	Barometric Port (Pneumatic Version only)	22

1.16	Label on Instrument Base.	22
1.17	User Interface	23
1.17.1	Buttons and softkeys	23
1.18	First Use	24
1.19	Dashboard	24
1.19.1	Dashboard Softkeys	24
1.19.2	Dashboard Navigation	25
1.19.3	Set Date, Time and Language	25
2.	Pump Operations	27
2.1	Pneumatic System	27
2.1.1	Use of Blanking Plug	27
2.1.2	Flexible hose	27
2.1.3	Venting to atmosphere	27
2.1.4	Attach Instrument Dirt (and Water) Trap to Test Port	28
2.1.5	Attach/Remove Device Under Test	28
2.1.6	Preparing the instrument for Pressure/Vacuum operation	30
2.1.7	Generating Pressure/Vacuum	31
2.2	Hydraulic System	34
2.2.1	Filling the reservoir	34
2.2.2	Priming the Instrument	35
2.2.3	Generating Pressure	39
2.2.4	Releasing Pressure	39
2.2.5	How to achieve 400 bar	39
2.2.6	How to replace the fluid in the Hydraulic System	39
3.	Basic Tasks	42
3.1	Tasks	42
3.1.1	P-I (Pressure to Current measure)	42
3.1.2	P-P (Pressure to Pressure)	42
3.1.3	P-V (Pressure to Voltage)	43
3.1.4	I-P (Pressure to Current source)	43
3.1.5	P-Display (Pressure to Display)	43
3.1.6	Leak Test	43
3.1.7	Switch Test	43
3.1.8	TX SIM (Transmitter Simulation)	43
3.1.9	Relief Valve Test	43
3.2	Tasks Selection	44
3.3	Adding Tasks to the Dashboard	44
3.4	Removing Tasks from the Dashboard	44
4.	General Settings	45
4.1	DATE, TIME and LANGUAGE	45
4.2	BACKLIGHT	46
4.3	USB	47
4.4	AUTO POWER DOWN	48
4.5	TOUCHSCREEN LOCK	49
4.6	ENABLE HOLD	50
4.7	ADVANCED	51

5.	Advanced Menu	53
5.1	CALIBRATION Menu	54
5.2	CHANGE PIN	55
5.3	SOFTWARE UPGRADE	56
5.3.1	How to load a Software Upgrade File	56
5.3.2	How to upgrade the Firmware	58
5.4	FACTORY RESET	60
5.5	FORMAT FILE SYSTEM	62
5.6	SERVICE / ENGINEERING	63
6.	Calibrator Tasks	64
6.1	Calibrator Task Screen	64
6.1.1	Calibrator Tasks Screen Shortcuts	65
6.1.2	Error Indications	71
6.2	Functions	72
6.2.1	Functions available by channel	72
6.2.2	None	74
6.2.3	Pressure	74
6.2.4	Sum	81
6.2.5	Difference	83
6.2.6	Barometer	85
6.2.7	Observed	87
6.2.8	RTD	88
6.2.9	Current	89
6.2.10	Voltage	105
6.2.11	Millivolts Measure - Configuration	107
6.2.12	HART	109
6.3	Process Options	111
6.3.1	Tare	111
6.3.2	Min/Max/Mean	113
6.3.3	Filter	116
6.3.4	Flow	118
6.3.5	Alarm	120
6.3.6	Scaling	123
7.	Utilities	129
7.1	Leak Test	129
7.2	Switch Test	134
7.3	TX (Transmitter Simulation) Simulator	137
7.4	Relief Valve Test	139
8.	External Sensors	141
8.1	PM700E	141
8.1.1	Overview	141
8.1.2	Media Compatibility	141
8.1.3	Setup	142
8.1.4	The Zero Function	143
8.1.5	Available External Pressure Sensors	143
8.1.6	Configuration of an External Pressure Sensor	144
8.2	RTD Probe and Interface	147
8.2.1	Overview	147

8.2.2	Temperature Considerations	147
8.2.3	Setup	148
8.2.4	Configuration of a channel for a RTD sensor	150
8.2.5	RTD Profiles	152
9.	Data Log	155
9.1	Data Log Setup Menu	155
9.1.1	How to set the Data Log Filename	156
9.2	TRIGGER Menu	158
9.3	Periodic Trigger Options	159
9.3.1	TIME INTERVAL	159
9.3.2	LOG DURATION	161
9.3.3	DATA POINTS	162
9.4	Setting up Manual Data Logging	164
9.5	Setting up Periodic Data Logging	166
9.6	Viewing & Deleting Data Log files	167
9.6.1	Viewing Data Log Files	167
9.6.2	How to use a PC to view Data Log files in the DPI 610E	168
9.6.3	Deleting Data Log Files	169
9.7	How to transfer a Data Log file	172
10.	Analysis	174
10.1	Overview	174
10.2	Analysis Application	174
10.3	Setup	175
10.3.1	START/END Values	175
10.3.2	LINEARITY	175
10.3.3	ERROR TYPE	176
10.3.4	TOLERANCE	176
10.4	Analysis Function	176
10.4.1	DATA LOGGING within Analysis	177
11.	Documenting	178
11.1	Overview	178
11.1.1	How to start the Documenting application	178
11.2	Internal Procedures	178
11.2.1	How to select the INTERNAL PROCEDURES mode.	178
11.2.2	How to create an Internal Procedure	179
11.2.3	How to start a Test Procedure	187
11.2.4	How to delete a Test Procedure	187
11.2.5	Starting a Test Procedure	188
11.3	The Documenting Main Screen	192
11.4	Documenting Settings	194
11.5	Running a Test Procedure	196
11.6	Post Examination of Test Procedure Results	198
11.7	Making an adjustment on the Device Under Test (DUT)	199
11.8	How to redo a Test Procedure	200
11.9	How to View Test Results.	201
11.10	Deleting Asset Data	203
11.11	How to use the Calibration Certificate Wizard	203
11.12	Remote Documenting	205

11.12.1 Setup and Connection.	206
11.12.2 Running 4sight (Remote) Calibration Test Procedures	210
11.13 Linear / Proportional Test Procedure	211
11.14 Switch Test Procedure	215
11.15 Making an adjustment on the Device Under Test (DUT)	221
11.16 How to View Test Results	222
11.17 Deleting Remote Procedure Files	226
11.18 Uploading Test Results To 4Sight2	227
12. HART	230
12.1 HART® Application	230
12.1.1 Starting the HART application (1st Method)	230
12.1.2 Starting the HART application (2nd Method)	232
12.1.3 HART device electrical connection	233
12.2 HART Device Configuration	234
12.3 HART Dashboard	239
12.3.1 Unique ID	240
12.3.2 Device Information	240
12.3.3 Measure Variables	242
12.3.4 Signal Condition	242
12.3.5 Sensor Information	243
12.4 HART Service Methods	244
12.4.1 LOOP TEST	244
12.4.2 D/A OUTPUT TRIM	246
12.4.3 PRESSURE ZERO TRIM	250
12.5 HART Error and Message Codes	251
13. Instrument Calibration	252
13.1 How to show the Instrument Calibration screen	252
13.1.1 The Instrument Calibration screen options	254
13.2 PERFORM CALIBRATION	255
13.2.1 Calibration - Electrical Functions	255
13.2.2 Calibration - Internal Pressure Sensor	260
13.2.3 Calibration – Internal Barometer	264
13.3 INTERNAL PRESSURE SENSOR STATUS	268
13.4 SET CALIBRATION DATE & INTERVAL	269
13.4.1 Change Last Calibration Date	270
13.4.2 Change Calibration Interval	271
13.4.3 Change Calibration Due Date	272
13.5 BACKUP CALIBRATION	273
13.6 RESTORE CALIBRATION	274
13.7 RESTORE FACTORY CALIBRATION	275
13.8 EXTERNAL PRESSURE SENSOR CALIBRATION MENU	276
13.8.1 PERFORM CALIBRATION	276
13.8.2 VIEW EXTERNAL PRESSURE SENSOR STATUS	277
13.8.3 SET CALIBRATION DATE & INTERVAL	278
13.9 EXTERNAL RTD SENSOR CALIBRATION MENU	282
13.9.1 PERFORM CALIBRATION	282
13.9.2 SET CALIBRATION DATE & INTERVAL	286

14.	Files System	290
14.1	How to access the Files system menu	290
14.1.1	The Files system screen options	291
14.2	Calibration	291
14.3	Data Log	292
14.4	Procedures	292
14.5	Leak Test	293
14.6	Switch Test	293
14.7	Relief Valve	294
14.8	How to view the File System on a PC	294
14.9	Favorites, Error Log and Event Log	295
15.	Status Menu	296
15.1	Status Menu Options	296
15.2	How to show the Status menu screen	296
15.3	SOFTWARE BUILD	297
15.4	CALIBRATION	298
15.5	BATTERY	299
15.6	MEMORY	300
15.7	SENSOR	301
15.8	ERROR LOG	302
15.8.1	How to export and view Exported Error Log files	302
15.9	EVENT LOG	303
15.9.1	How to export and view Exported Event Log files	303
16.	Favorites Menu	304
16.1	Favorites Menu Options	304
16.1.1	Save Current Calibrator Task	305
16.1.2	Save New Configuration as Favorite	307
16.2	To Load a Favorites Configuration	309
16.3	Edit an Existing Favorite File	309
16.4	Delete Favorite Files	309
16.5	Transferring Favorite Files	309
16.6	Accessing Favorite Files via the File System	309
17.	General Specification	311
17.1	Open Source Software Licenses	311
18.	Manufacturer	312
18.1	Contact details	312

1. Overview

The DPI 610E series instrument comprises a portable pressure calibrator with an in-built pressure generation manual pump, with pressure measurement and simulation capability. It is to be used to calibrate pressure sensors and transmitters. It has a smart and simple user interface allowing it to be operated by any technician, service or maintenance engineer.

The DPI 610E series combines a practical and robust design with reliable and accurate measurements. It is battery-powered and features highly reliable pneumatic and hydraulic assemblies for continuous and reliable performance for field calibration, even in harsh environmental conditions.

A flexible hose is supplied with the instrument to enable connection to other equipment.

This calibrator is enhanced with data logging functionality with internal memory for secure file storage.

The analysis feature includes field error calculations with PASS/FAIL status with the ability to create or download procedures which can be run on multiple devices, providing calibration certification for asset management and maintenance purposes.

The DPI 610E supports the HART (Highway Addressable Remote Transducer) communication protocol and allows basic HART operation and configuration on HART supported devices.

1.1 DPI 610E Series

1.1.1 Firmware Versions

This manual is based on the use of application firmware DK0492 version 02.00.03 and 02.00.04. For further details see End User Software Release Note document **169M2231** available at Druck.com/DPI610E.

Table 1-1: DPI 610E Series

Product Name	Case Color	Pressure Range	Calibrator Type
DPI 610E-PC	Blue	0.35 bar - 35 bar (5 - 500 psi) (0.035 MPa - 3.5 MPa)	Pneumatic
DPI 610E-SPC	Yellow	0.35 bar - 35 bar (5 - 500 psi) (0.035 MPa - 3.5 MPa)	Pneumatic - Intrinsically Safe
DPI 610E-HC	Blue	70 bar - 1000 bar (1000 psi - 15000 psi) (7 MPa - 100 MPa)	Hydraulic
DPI 610E-SHC	Yellow	70 bar - 1000 bar (1000 psi - 15000 psi) (7 MPa - 100 MPa)	Hydraulic- Intrinsically Safe

Photographs of these Calibrator types are on the next page.



Model: DPI 610E-PC
Type: Pneumatic
Pressure Range: 0.35 - 35 bar,
5 - 500 psi, 0.035 - 3.5 MPa



Model: DPI 610E-SPC
Type: Pneumatic - Intrinsically Safe
Pressure Range: 0.35 - 35 bar,
5 - 500 psi, 0.035 - 3.5 MPa



Model: DPI 610E-HC
Type: Hydraulic
Pressure Range: 70 - 1000 bar,
1000 - 15000 psi, 7 - 1000 MPa



Model: DPI 610E-SHC
Type: Hydraulic - Intrinsically Safe
Pressure Range: 70 - 1000 bar,
1000 - 15000 psi, 7 - 1000 MPa

1.2 Equipment in the Box

The following items are supplied with the instruments in the DPI 610E series. When unpacking the instrument, make sure that there are no missing items.

Note: When the hydraulic instrument is delivered there is a protective cap in the reservoir socket. Keep this cap for future use: this is for sealing the socket when no reservoir is attached.

1.2.1 Pneumatic Units

1. DC Power Supply (IO610E-PSU)
2. BSP Swivel Adapter (184-203)
3. NPT Swivel Adapter (184-226)
4. Blanking Plug (111M7272-1)
5. (IDT) Instrument Dirt Trap (IO620-IDT621-NEW) - packed separately, OR (IDT) Instrument Dirt Trap (IO620-IDT621-IS) - packed separately
6. Hose sets: 1m (IO620-HOSE-P1) or Intrinsically Safe (IO620-HOSE-P1-IS)
7. Electrical Test Lead Set (IO6X-LEAD)
8. 2m USB Cable (IO610E-USB-CABLE)
9. DPI 610E Quick Start and Safety Manual (165M0437)
10. Certificates Document Pack (IS product only)
11. Factory Calibration Certificate.

1.2.2 Hydraulic Units

1. DC Power Supply (IO610E-PSU)
2. BSP Swivel Adapter (184-203)
3. NPT Swivel Adapter (184-226)
4. Blanking Plug (111M7272-1)
5. Hose sets: 1m long (IO620-HOSE-H1) or Intrinsically Safe (IO620-HOSE-H1-IS)
6. Reservoir (PV411-115 or Intrinsically Safe PV411-115-IS) - packed separately
7. 250 mL Reservoir Filler Bottle (1S-11-0085)
8. Electrical Test Lead Set (IO6X-LEAD)
9. 2m USB Cable (IO610E-USB-CABLE)
10. DPI 610E Quick Start and Safety Manual (165M0437)
11. Certificates Document Pack (IS product only)
12. Factory Calibration Certificate.

1.3 Specifications for DPI 610E

Refer to www.druck.com/dpi610e for the Datasheet that gives the technical specifications for the DPI 610E.

1.4 Accessories

Table 1-2 shows common accessories for the DPI 610E series. See Datasheet (BHCS39207) for a full list of accessories.

Table 1-2: Common accessories

Part Code	Description
RTD-INTERFACE-485	RTD Interface only (non-IS area)
RTD-INTERFACE-IS	RTD IS Interface (IS area)
RTD-PROBE-485	RTD Interface with PT100 Probe (non-IS area)
RTD-PROBE-IS	RTD Interface with PT100 Probe (IS area)
IO-RTD-M12CON	M12 Field Wireable Connector to fit RTD Interface (IS and non-IS area)
IO-RTD-M12EXT	RTD M12 male to female extension lead 2 m (6.5 ft) 4-wire
IO-RTD-PRB150	150 mm length 6 mm diameter PT100 steel RTD probe, Class A
PM700E	Remote Pressure Sensor (non-IS area)
PM700E-IS	Remote Pressure Sensor (IS area)
PM700E-CABLE	Remote Sensor Extension Cable 2.9 m (9.5 ft)
IO620-IDT621-NEW	Bar Dirt and Moisture Trap (non-IS area)
IO620-IDT621-IS	Bar Dirt and Moisture (IS area)
IO610E-CASE	Carrying Case (suitable for IS and non-IS use)

1.5 Observance of Manual



INFORMATION This manual contains operating procedures and safety information for the DPI 610E series. It is the responsibility of the customer to make sure that all personnel operating and maintaining the equipment are correctly trained and qualified.

Note: Before operating or using the equipment, read and obey all warnings and cautions given in the Quick Start and Safety Manual.

1.6 Safety



INFORMATION The manufacturer has designed this equipment to be safe when used as detailed in this manual. Operators should read and obey all local Health and Safety regulations and Safe Working Procedures or Practices.

When performing a procedure or task:

1. Do not use this instrument for any other purpose than stated in this manual. Incorrect use may reduce safety.
2. Follow all operating and safety instructions in the Quick Start and Safety Manual.
3. Use suitably qualified Technicians and good engineering practice for all procedures in this documentation.

1.6.1 General Safety Precautions

- Use only the approved tools, consumable materials and spares to operate and maintain the equipment.
- Make sure all work areas are clean and clear of unwanted tools, equipment and materials.
- Make sure all unwanted consumable materials are discarded in accordance with local health and safety and environmental regulations.

1.6.2 Operation in a Hazardous Environment



WARNING Do not use the DPI 610E-HC or DPI 610E-PC in locations where explosive gas, vapor or dust are present. There is a risk of an explosion.

Refer to the Quick Start and Safety Manual provided with the instrument.

1.6.3 General Warnings



Make sure that the instrument is safe to use with the proposed media. Some liquid and gas mixtures are dangerous. This includes mixtures that result from contamination.

Do not use in an enriched oxygen environment or with other strong oxidizers - this can cause an explosion.

Do not use tools on the instrument that might cause incendive sparks - this can cause an explosion.

It is dangerous to ignore the specified limits (refer to data sheet) for the DPI 610E series or to use the instrument when it is not in its normal condition. Use the applicable protection and obey all safety precautions.

1.6.4 Electrical Warning



RISK OF ELECTRIC SHOCK To prevent electrical shocks or damage to the instrument, do not connect more than 30 V CAT I between the terminals, or between the terminals and the ground (earth). Any connection must be compliant with the terminal input/output parameters.

External circuits should have appropriate insulation to the mains.



WARNING This instrument uses a Lithium-Ion (Li-Ion) battery pack. To prevent an explosion or fire, do not short circuit and do not disassemble. Keep the battery safe from damage.



WARNING To prevent an explosion or fire, only use the Druck specified battery (150M8295-1) and power supply (149M4334-1) rated for this instrument.

To prevent battery leakage/damage or excess heat generation, only use the mains power supply in the ambient temperature range 0 to 40°C (32 to 104°F). The power supply input range is 90 – 264 VAC, 50 to 60 Hz, 300 mA, installation category CAT II.

Note: Position the power supply without obstructing the supply disconnecting device.

Note: The instrument is suitable for short-term and long-term temporary overvoltage that may occur between the line conductor and earth in electrical installations.

Note: Keep all leads free from contaminants.

1.6.5 Pressure Warnings



INFORMATION The instrument contains an internal over-pressure vent mechanism to protect the internal pressure sensor and pump mechanism from damage.

Note: Maximum Operating Pressure (MWP) is stated on the label on the underside of the instrument. Over pressure should be limited to $1.5 \times \text{MWP}$ (MWP is based on unit pressure range).



WARNING Always wear appropriate eye protection when working with pressure.

To prevent a dangerous release of pressure, make sure that all the related pipes, hoses and other accessories have the correct pressure rating, are safe to use and are correctly attached. Isolate and bleed the system before you disconnect a pressure connection.

It is dangerous to attach an external source of pressure to the instrument. Use only the internal mechanisms to set and control pressure in the pressure station.

1.6.6 Overvoltage Categories

The following summary of installation and measurement overvoltage categories is derived from IEC610101. The overvoltage categories indicate the severity of overvoltage transients.

Table 1-3: Overvoltage Categories

Category	Description
CAT I	This is the least severe overvoltage transient. CAT I equipment cannot be directly connected to the mains power. E.g a process loop powered device.
CAT II	This is for single phase electrical installation. E.g appliances and portable tools.

1.7 Maintenance

Maintain the instrument using the procedures outlined in this User Manual. For information relating to maintenance issues please contact:

www.bakerhughesds.com/druck/global-service-support

Table 1-4 summarizes manufacturer recommended maintenance tasks for the DPI 610E series.

Table 1-4: Maintenance Tasks

Task	Period
Visual Inspection	Before Use
Cleaning	Determined by usage
Calibration	12 months (recommended)

1.7.1 Visual Inspection

Inspect the instrument before use, checking for signs of damage (e.g case cracking, pressure connector damage or pressure leakage), to ensure continued safe working.

1.7.2 Cleaning

Clean the surface of the instrument should using a damp cloth with water and mild detergent. Do not submerge the instrument in water.

1.7.3 Calibration

To calibrate the instrument, please contact www.bakerhughesds.com/druck/global-service-support

1.8 Service and Repair



WARNING Servicing or repairing the equipment may result in damage to property and serious personal injury (including death). It is important that service and repair are only done by a Druck authorized service provider.

Repair activities undertaken by unauthorized personnel may invalidate the equipment warranty. Druck cannot be held liable for any damage (including damage to the equipment), monetary fine or personal injury (including death) that may occur during or as a result of service maintenance or repair work undertaken by an unauthorized service provider.

Internal components, such as the Lithium battery pack, may be under pressure or create other hazards if abused.

For more details, please see www.bakerhughesds.com/druck/global-service-support

1.9 Spares

For advice or technical support relating to spare parts, please contact:

drucktechsupport@BakerHughes.com

1.10 Instrument Return

1.10.1 Returned Goods Procedure

If the unit requires calibration or is unserviceable, please return it to the nearest Druck Service Centre listed at: <https://www.bakerhughes.com/druck>

Contact the Service Centre to obtain a Return Goods Authorization (RGA). If you are in the USA, obtain a Return Material Authorization (RMA).

Provide the following information on either a RGA or RMA:

- Product code
- Serial number
- Details of defect/work to be undertaken
- Error code(s) if applicable
- Operating conditions.

1.10.2 Instrument Disposal

Do not dispose of this product as household waste. Use a Recycling Passport for the product. This can be downloaded from the product web page:

<https://www.Druck.com/expert>. Use an approved organization that collects and/or recycles redundant electrical and electronic equipment.

For more information contact either our Customer Service Department (<https://www.bakerhughes.com/druck>) or your local government office.

1.11 Packaging For Storage or Transportation

1.11.1 Environment

The equipment must be maintained in the conditions shown in Table 1-5. This applies for both shipping and storage.

Table 1-5: Conditions for Storage and Transportation

Condition	DPI 610-E	Mains Plug 149M43341
Outdoor use	Not for permanent installation outdoors	For indoor use only
IP rating	IP54	IP20
Operating temperature	-10 to 50°C	-10 to 50°C
Storage and shipping temperature	-20 to 70°C	-20 to 70°C
Altitude	-300 to 2000m	-300 to 2000m
Operating humidity	0 to 95% relative humidity (RH) non-condensing	0 to 95% relative humidity (RH) non-condensing
Pollution degree	1	1

1.12 Preparing the Instrument



INFORMATION When you receive the instrument, check that the box contains the items listed in Section 1.2, “Equipment in the Box,” on page 11. It is recommended that you retain the box and packaging for future use.

1.12.1 Initial Checks

- Visual check (for cracks/defects)
- Do not use any equipment that you know is damaged or faulty
- Ensure the battery is charged (see Section 1.13).

1.13 Battery and Charging

The instrument contains a rechargeable Li-ion battery. To charge the battery, plug the power supply into the DC charging port located under the protection flap, in the head of the instrument.

The instrument can also be charged from any vehicle with a standard 12 V accessory socket with an IO610E-CAR CHARGER (optional accessory).

The instrument can be charged while switched on and also when powered off. Battery charge time is approximately two hours from empty to fully charged.




Figure 1-1: Battery Charging Socket

Chapter 1. Overview


1.13.1 Battery Status Indicator




The battery status indicator (located at the right hand side of instrument) provides a visual indication of the battery level, even when the instrument is off. Press the circular button on the right of the display to temporarily show the charge: the display will automatically close down. Each LED represents approximately 25% battery capacity.

1.14 Power ON/OFF

1.14.1 Power ON


To switch the instrument ON, hold down the power button  for about 2 seconds, until the Druck Logo splash screen appears.

1.14.2 Power OFF


To switch the instrument OFF, hold down the power button  for about 4 seconds until the closing screen appears.

1.14.3 Auto Power Down

The instrument has an Auto Power Down feature that can be enabled/deactivated as required. See General Settings Section 4 on page 45: (on the instrument it can be found under the **General**

Settings  screen on the Dashboard).

1.15 Parts



Pneumatic version

Number	Item	Number	Item
1	Pressure Release Valve	10	Pressure/Vacuum Selector
2	Test Port (including Swivel Connector)	11	Pressure/Vacuum Hand Pump
3	Auxiliary Ports (DC power supply port Battery Charging, USB micro port.	12	Volume Adjuster (Fine control of pressure)
4	Electrical 4mm sockets	13	Instrument Dirt (& Fluid) Trap (IDT)
5	Screen Selection softkeys	14	Clip Fastener for Carrying Strap
6	Power ON/OFF button	15	Barometer Port
7	Help Button	16	Battery Level Indicator (One bar equals 25% charge)
8	Home Button	17	External Sensor Port
9	Navigation Pad		



Hydraulic version

Number	Item	Number	Item
1	Hydraulic Reservoir	9	Navigation pad
2	Test Port (including swivel connector)	10	Pressure Hand Pump
3	Auxiliary Ports (DC power supply port Battery Charging, USB micro port.	11	Volume Adjuster Wheel (Fine control of pressure)
4	Electrical 4mm Sockets	12	Clip Fastener for Carrying Strap
5	Screen Selection softkeys	13	Pressure Release Valve
6	Power ON/OFF button	14	Battery Level Indicator (One bar equals 25% charge)
7	Help button	15	External Sensor Port
8	Home button		

1.15.1 Test Port

The Test Port is at the top left corner of the instrument. Pressure can be generated and supplied to pressure devices that are connected either directly or by the use of compatible hose fittings.

1.15.2 Reservoir (Hydraulic Version)

Make sure the Reservoir is filled with the correct hydraulic fluid before use. Recommended fluid ISO viscosity grade ≤ 22 , such as demineralized water or mineral oil.

1.15.3 Pressure Release Valve

The Pressure Release valve is on the top right of the instrument for the Pneumatic version and on the left side for the Hydraulic version. To release all pressure within the instrument, slowly open the pressure release valve by turning it counter-clockwise. Make sure the system is sealed before pressure generation by completely closing the pressure release valve in the clockwise direction.

1.15.4 Electrical Connections

Four electrical 4mm sockets are on the left side of the instrument glass face. These are labeled for different electrical measurement or source functions.

1.15.5 Handle and Shoulder Strap

The DPI 610E has a carry handle to allow for a steady grip on the instrument, while the shoulder strap can be used for more comfortable use.

1.15.6 Pump (Pneumatic Version)

When the pump selector is in the (+) orientation the hand pump generates pressure by a forward-backward stroke action. When the pump selector is in the (-) orientation the pump creates a vacuum by a backward-forward stroke action. To prevent damage to the device the system must be fully vented before switching between vacuum and pressure.

1.15.7 Priming Pump (Hydraulic Version)

The priming pump is used to draw hydraulic fluid from the reservoir and force air, gas or vapor present, out of the system.

1.15.8 Volume Adjuster (Pneumatic Version)

The volume adjuster is used to control the pressure for fine adjustments.

1.15.9 Volume Adjuster Wheel (Hydraulic Version)

The volume adjuster wheel is used to adjust the pressure in the range of 20 - 1000 bar. To increase the pressure, turn the wheel clockwise. To decrease the pressure, turn the wheel counter-clockwise.

1.15.10 Pressure/ Vacuum Selector (Pneumatic Version)

The pressure/vacuum selector can be set to generate a pressure or a vacuum. To prevent damage to the unit the system must be fully vented before switching between vacuum and pressure.

1.15.11 Auxiliary Ports

The auxiliary ports are at the top of the instrument and enclosed within the rubberized flap. It accommodates a DC power supply port and a Micro USB port.

1.15.12 External Sensor Port


On the right side of the instrument is the RS485 communications port to enable connection of external remote sensors such as the PM700E pressure sensor and the RTD-Interface.

Chapter 1. Overview

1.15.13 Barometric Port (Pneumatic Version only)

The left side has a Barometer port that provides a static pressure inlet for the internal barometric pressure sensor.

1.16 Label on Instrument Base.



Note: Certification markings might be different on instrument, depending on model purchased.

Number	Item
1	Full code Identification of instrument.
2	Pressure range of instrument.
3	Maximum Working Pressure is 1.2 x value of top value of pressure range
4	Serial number of the instrument
5	Date of Manufacture: Month, Year
6	Current and Voltage rating for the instrument
7	ATEX Certificate Number
8	EU Directive 2014/34/EU Marking
9	EU Hazardous Area Marking
10	IECEx Certificate Number
11	UKEX Certificate Number
12	Current output of Charger
13	Full address of manufacturer of instrument
14	This mark indicates that this product complies with the Great Britain standard for the safety of products
15	This mark indicates that this product complies with the European standard for the safety of products.
16	Canada ISED Radio Approval ID (Bluetooth)
17	US FCC Radio Approval ID (Bluetooth)
18	China RoHS
19	WEEE (Recycling) Marking. Do not dispose of as normal refuse - take to an authorized disposal facility.

1.17 User Interface




Figure 1-2: Instrument User interface


The user interface (Figure 1-2) can be operated using the touchscreen, buttons or softkeys.

1.17.1 Buttons and softkeys


1.17.1.1 Power Button

The power button  is used to switch the instrument on and off. See Section 1.14, “Power ON/OFF,” on page 18.


1.17.1.2 Help Button

The Help button  provides relevant information on how to use the instrument. It is context-sensitive which means the information provided when the help button is pressed will be related to the specific screen or task in use at that moment in time. The Help button also provides a link and QR code to access the full user manual online through a smart device or PC.


1.17.1.3 Home Button

The **Home** button  acts as a shortcut key which enables quick navigation to the Dashboard home screen from anywhere in the user menu.

1.17.1.4 Enter button


An **Enter** button  is in the middle of the Navigation Pad.

1.17.1.5 Navigation Pad



The Navigation Pad consists of Up, Down, Left, Right and Enter buttons which allow quick and easy navigation when using the user interface.

1.17.1.6 Softkeys

	<p>There are four softkeys on the right side of the LCD display. These softkeys are context-sensitive and their use varies from screen to screen depending on the menu or task being accessed. Each softkey has a corresponding on-screen icon which provides a visual display of the purpose of that specific button as shown in Figure 1-2. The on-screen icons also act as touch-screen buttons for the same purpose as the corresponding softkey.</p>
---	---

1.18 First Use

Check that the default settings for the instrument are correct before the first use of the instrument: refer to Section 4 on page 45 for how to set its default values. For example, it might be necessary to change the language for the user interface or the time and date.

1.19 Dashboard








Figure 1-3: Instrument Dashboard

On power up, the instrument displays the Dashboard. The Dashboard is the home screen through which all functions, tasks and settings can be accessed. The Dashboard has icons which represent different applications. The Calibrator, Tasks, HART, Analysis, Documenting, and Data Log icons are fixed and always present.

Note: If additional applications are configured on the instrument license, their respective icons will also be present and fixed on the Dashboard (See Chapter 4 on page 45).

1.19.1 Dashboard Softkeys

The dashboard softkey icons are on the right of the dashboard screen. The icons are  General Settings,  Status,  Favorites and  File System. An icon is activated by either tapping the screen where it is or by pressing the softkey on the right of the icon.

Note: The icons on the sidebar are fixed on the Dashboard.



Be careful to avoid accidentally touching the display screen when using the instrument. This can make the system execute unintended actions. This can happen, for example, when pushing cables into the sockets in the face of the instrument or by letting cables touch the screen.

1.19.2 Dashboard Navigation

To access an application, the user should select the relevant icon on the touch screen. The user can also use the navigation buttons to navigate between icons on the dashboard as described in Section 1.17.1.5.

To access the icons on the side bar, select the relevant icon on the touch screen, or press the corresponding softkey.

Note: To return to the Dashboard, the user can select the home button <HOME>.

1.19.3 Set Date, Time and Language

1.19.3.1 Date and Time

To access the **Date/Time** menu screen (Figure 1-4), select:

Dashboard >> ⚙ General Settings >> TIME/DATE




Figure 1-4: Time/Date Menu Screen

On the Navigation Pad, use the **UP/DOWN** navigation buttons to select the time and date parameters to be changed, then use the **LEFT/RIGHT** buttons to increase or decrease the values. If using the touchscreen, tap the required time or date parameter to be changed and then tap on the right side of the set value (in bold font) to increment or on the left side to decrement the value as required.

When all parameters have been selected press the **Tick** ✓ softkey to accept the **Date/Time** changes or press the **Back** ↩ button to exit without saving the changes.

1.19.3.2 Language

To access the **Language** menu (Figure 1-5), select:

Dashboard >> ⚙️ General Settings >> Language



Figure 1-5: Language Menu Screen

Use the navigation buttons to select the desired language. If using the touchscreen, tap on the desired language option. Press the **Tick** ✓ softkey to accept the changes or select the **Back** ↶ softkey to exit without saving any changes.

1.19.3.3 Open Source Licenses

There are two files that relate to the software for upgrading the firmware for this instrument:

1568-notices-report-08_08_2022_17_04.txt covers DK0491 DPI610E Bootloader

1563-notices-report-08_08_2022_16_01.txt covers DK0492 DPI610E Main Application.

2. Pump Operations

2.1 Pneumatic System

2.1.1 Use of Blanking Plug



A Blanking Plug seals the test port and stops foreign matter getting into the port. It is good practice to attach the Blanking Plug when the test port is not in use.

To attach the Blanking Plug to the test port: put the plug into the swivel connector and hold in position while turning the swivel connector fully counter-clockwise until it is hand tight.

To release the plug, hold the plug in position while turning the swivel connector clockwise until the plug can be removed.

2.1.2 Flexible hose

A flexible hose is delivered with the DPI 610E, to enable connection to other equipment. Two types of hose are available: one for Safe area use and the other for Intrinsically Safe (IS) environments.

Before use always visually check the hose for faults, such as splits or cuts in the hose.

Always make sure the instrument is safe to use.

2.1.3 Venting to atmosphere



A rapid drop in pressure can damage the instrument. Open the pressure release valve slowly and monitor the pressure reading until you reach the desired pressure.



To vent the system to atmospheric pressure, slowly turn the pressure release valve fully counter-clockwise until the sensor returns to zero (gauge sensor) or 1 bar (absolute sensor).

Chapter 2. Pump Operations


2.1.4 Attach Instrument Dirt (and Water) Trap to Test Port



INFORMATION It is recommended that a dirt trap is always used.



CAUTION To avoid damage to the dirt trap, hold it firmly while screwing it into the test port.



To attach the Instrument Dirt (and Water) Trap (IDT) to the test port, first remove the Blanking Plug if it is in the test socket: turn the swivel connector clockwise to release the plug. Put the trap into the socket while turning the swivel connector fully counter-clockwise until it is hand tight.

2.1.5 Attach/Remove Device Under Test

2.1.5.1 Attach Device Under Test



To avoid damage to the device under test, hold it firmly while screwing it into the test port/dirt trap.



To attach the device under test to the test port or dirt trap, put the trap into the thread of the swivel connector, then turn the swivel connector fully counter-clockwise until it is hand tight.



Note: Make sure that the device under test has a male G $\frac{3}{8}$ Quickfit adapter thread or use a suitable adapter rated to 35 bar.

If in doubt, please contact www.bakerhughesds.com/druck/global-service-support

2.1.5.2 Remove Device Under Test
















A rapid drop in pressure can damage the instrument. Open the pressure release valve slowly and monitor the pressure reading until you reach the desired pressure

Step 1		Release all of the pressure in the instrument by opening the pressure release knob fully counter-clockwise.
Step 2		To remove the device under test, hold it firmly while turning the swivel connector it fully clockwise. Attach the Blanking Plug to seal and protect the socket if the instrument will not be in immediate use, see “Use of Blanking Plug” on page 27.


Chapter 2. Pump Operations

2.1.6 Preparing the instrument for Pressure/Vacuum operation

Make sure the instrument is safe to use: refer to the instructions on page 27.


Step 1		To power ON the instrument, push down the power button for 2 seconds until the Druck splash screen appears.
Step 2		<p>Select the required pressure function from the Channel Function screen.</p> <p>Note: From the dashboard select:</p> <p>CALIBRATOR >>  or  >> FUNCTION >> Pressure> INT>>Normal</p> <p>Select the Tick  softkey and press the Back  icon.</p>
Step 3		<p>Select the required units.</p> <p>Note: From the dashboard select:</p> <p>CALIBRATOR >>  or  >> UNITS >> either tap the unit required on the screen or use the Navigation key pad arrow keys to select the unit.</p> <p>Select the Tick  softkey and press the Back  icon.</p>
 <p>CAUTION To avoid damage to the device under test, hold it firmly while screwing it into the test port/dirt trap.</p>		
Step 4		<p>To attach the device under test to the test port or dirt trap: hold the device in the socket, then turn the swivel connector at the base of the connector fully counter-clockwise until it is hand tight.</p> <p>Note: Make sure that the device under test has a male G 3/8 Quickfit adapter thread or use a suitable adapter rated to 35 bar.</p> <p>If in doubt, please contact www.bakerhughesds.com/druck/global-service-support</p>

2.1.7 Generating Pressure/Vacuum

Step 1		Seal the system by turning the pressure release valve fully clockwise.
--------	---	--





CAUTION Do not submerge the instrument in the pressure medium. If fluid enters any part of the electrical connection panel, allow the instrument to dry out thoroughly before use.

Step 2		Adjust the pressure-vacuum selector to pressure mode (+) or vacuum mode (-) depending on the desired operation. Note: To adjust the selector from pressure mode to vacuum mode, turn it clockwise. To adjust the selector from vacuum mode to pressure mode, turn it counter-clockwise.
--------	---	---




CAUTION To prevent the instrument from sliding, make sure that either the slip prevention feet are engaged or the instrument is secured against a flat surface.

Step 3		Use the pump to achieve the desired pressure/vacuum.
Step 4		Turn the volume adjuster to make fine adjustments to the pressure/vacuum.

Chapter 2. Pump Operations



A rapid change in pressure/vacuum can damage the instrument. Open the pressure release valve slowly and monitor the reading on the screen until you reach the desired pressure/vacuum.

Optional		To decrease pressure/vacuum, open and close the pressure release valve slowly.
----------	---	--

The above procedure is appropriate for general use, however, the procedure must be modified when low pressure (350 mbarg) or high vacuum (-950 mbarg) is required.

2.1.7.1 Creating Low Pressure (350 mbarg Full Scale)

Follow these instructions to achieve a low pressure:

1. Make sure that the device under test is properly connected to the test port and that the DPI 610E release valve is fully open (turn counter-clockwise).
2. Make sure the pressure-vacuum selector is set to the '+' position for the pressure mode.
3. Turn the fine adjustment knob counter-clockwise until about 2 inches/5 cm of thread is exposed (from "fully in" position this should take around 15 full rotations).
4. Close the release valve (turn clockwise) firmly to hand tight, to seal the system.
5. Make sure that the internal pressure is displayed on the unit display.
6. Push the pump slowly and gently and at the same time monitor the display for the increasing pressure. Stop pumping as soon as the required pressure is reached.

Note: The required pressure may be achieved with a less than one full pump stroke or it may require more depending on the connected device under test.

7. If the pressure is below the required value then go back to step 5.
8. If the pressure indicated is above the required pressure or if on the display shows >>>> (i.e. pressure is above the internal sensor full-scale limit) then use the fine adjustment knob by rotating counter-clockwise slowly to bring the pressure down to the required value.

2.1.7.2 Creating a High Vacuum (-950 mbarg)

Follow these instructions to achieve a high vacuum:

1. Turn the pressure/vacuum selector collar to the vacuum '-' position. Note that as the vacuum increases, it is only the last part of the pump travel (i.e. fully pulled-out) that actually increases the vacuum. This is exactly similar to pumping positive pressure, where it is only the last part of the inward travel that pushes air past the non-return valve as pressure rises. Therefore, for effective use, the pump must be fully pulled out (until the end stop is felt) to effectively generate vacuum.
2. It is much more effective to pull the pump knob out quite quickly (until end stop is hit) because this keeps the non-return valve fully open.
3. To try to get to -950 mbar is similar to trying to remove 95% of the air from the system: this requires approximately 15-20 (fast) strokes to achieve.
4. If difficulty is still encountered getting to low vacuum then stop pumping and use the volume adjuster – unscrewing this will draw further vacuum and reduce the pressure.
5. If -950 mbar is achieved but then the pressure slowly increases (i.e. system appears to be leaking) then check that the release valve is tightly shut and the IDT (Instrument Dirt Trap) top/bottom seals are not leaking.

2.2 Hydraulic System



2.2.1 Filing the reservoir


Make sure the instrument is not pressurized: refer to Section 2.2.2 on page 35 for instructions. The instrument is supplied with a 100 cc (3 oz) reservoir tank. The pressure reservoir can be filled attached or detached from the instrument. When the reservoir is removed, seal the socket with the protective cap delivered with the instrument to prevent entry of foreign matter. Make sure that the pressure medium is compatible with your test device.

Note: The recommended pressure medium is demineralized water or mineral oil.



CAUTION Do not submerge the instrument in the pressure medium. If fluid enters any part of the electrical connection panel, allow the instrument to dry out thoroughly before use.



Step 1		Turn the reservoir into the reservoir port. Turn the reservoir clockwise, until it is hand tight.
Step 2		Turn the reservoir locknut counter-clockwise and remove the reservoir cover.



INFORMATION The pressure medium level must stay above the horizontal pin in the reservoir at all times when the instrument is in use. The volume of pressure medium in the reservoir shall not exceed 75cc when the instrument is in use. To avoid contamination, use only one type of pressure media in the instrument. If you wish to change the pressure medium after first use, please contact the Service Department.

The pressure medium level must always stay above the horizontal pin in the reservoir when the instrument is in use.

The volume of pressure medium in the reservoir must not exceed 75cc when the instrument is in use. The reservoir can be unscrewed from the instrument and filled. To avoid contamination, use only one type of pressure media in the instrument. If you wish to change the pressure medium after first use, please contact the Service Department.

Step 3		Use the squeeze bottle to fill the reservoir with pressure medium to approximately 75% capacity of the reservoir.
Step 4		Push the reservoir cover into position and turn the locknut clockwise until the reservoir cover just seals the reservoir, leaving a small amount of play, (finger tight and back off a quarter turn).



2.2.2 Priming the Instrument

















CAUTION Before operating the priming pump, always make sure that the test port is sealed beforehand. Priming the instrument when the test port is unsealed could cause the pressure medium to spray from the test port into the electrical ports.







INFORMATION A blanking plug has been provided by the manufacturer and shipped with the instrument.

Step 1		<p>Make sure the test port is sealed by the Blanking Plug.</p> <p>To attach the Blanking Plug to the test port: put the plug into the thread of the swivel connector and hold in position while turning the swivel connector fully counter-clockwise until it is hand tight.</p> <p>Note: It is easier to bleed the system if a hose is attached after air has already been removed from the instrument. Go to step 16 for more information.</p>
Step 2		<p>Turn the volume adjuster wheel clockwise until it stops: this can be up to 30 turns.</p> <p>Note: This is the zero point.</p>

Chapter 2. Pump Operations

Step 3		Make sure that the pressure release knob is at its fully closed position (hand tight): turn the knob in a clockwise direction.
Step 4		The reservoir must be connected the reservoir port and filled to the required level. See Section 2.2.1 on page 34.
Step 5		To power ON the instrument, push down the power button for 2 seconds until the Druck splash screen appears.
Step 6		<p>Select the required pressure function from the Channel Function screen.</p> <p>Note: From the Dashboard select:</p> <p>CALIBRATOR >>  or  >> FUNCTION >> Pressure> INT>>Normal</p> <p>Press the Tick  softkey and press the Back  icon to show the previous screen.</p>
Step 7		<p>Select the required units.</p> <p>Note: From the Dashboard select:</p> <p>CALIBRATOR >>  or  >> UNITS >> either tap the unit required on the screen or use the Navigation key pad arrow keys to select the unit.</p> <p>Press the Tick  softkey and press the Back  button to show the previous screen.</p>
Step 8		Slowly operate the priming pump until the pressure reaches 5-10 bar.


Step 9		Turn the volume adjuster wheel fully counter-clockwise until it stops (this could need at least 29 turns). The indicated pressure reading will decrease.
Step 10		Slowly operate the priming pump until the pressure reaches 5-10 bar.
Step 11		Turn the pressure release knob a quarter of a turn counter-clockwise to release the pressure.
Step 12		Slowly operate the priming pump until no air bubbles come out of the hole in the reservoir center stem. Note: It should take 10-15 strokes to remove trapped air from the system.




CAUTION Do not continue to operate the pump after air bubbles stop coming out of the central reservoir stem hole.



CAUTION Do not remove the blanking plug when the instrument is under pressure. Before removing the blanking plug, check the instrument pressure display for pressure. If pressure is observed, turn the pressure release knob fully counter-clockwise until the pressure display reads zero (gauge sensor) or atmospheric pressure (absolute sensor).


Step 13		Remove the blanking plug from the test port.
---------	---	--

Chapter 2. Pump Operations

Step 14		Turn the pressure release knob fully clockwise, hand tight.
---------	---	---




CAUTION Do not operate the priming pump. Only use the volume adjuster wheel.

Step 15		Slowly turn the volume adjuster wheel 2-5 turns clockwise to remove any trapped air. [If mineral oil is used as the pressure media, operate the pump gently to avoid creating a mess.] Note: The user may notice air bubbles at the opening of the test port.
Step 16	The instructions in this Step 16 relate only to the connection of a hose to the test port and removal of air from this hose. If a test device is to be connected directly to the instrument (or to the hose after air has been removed), go to Step 17. Connect the hose to the test port and use the Step 10 to Step 15 procedures to remove air from the hose. Use Steps 10 and 11. Ignore Step 12. Use Steps 13 and 14. Step 15: Use the pump to move fluid into the hose. Stop using the pump when air bubbles do not appear at the hose outlet.	




CAUTION Do not allow movement of the hose to rotate the adapter as this may cause internal damage to the instrument.

Step 17	Hold the test device in position in the test socket while fully turning the swivel connector counter-clockwise until it is hand tight. A blanking plug can be attached to the hose end instead of a test device. Note: As required, use adapters provided with the instrument or an AMC adapter(s) and the corresponding seal(s).	
Step 17		Use the priming pump to prime the system to a maximum of 10-20 bar.


2.2.3 Generating Pressure



INFORMATION Make sure the instrument is primed before attempting to generate pressure. Check the instrument pressure range on rear label before attempting to generate pressure.

Step 1		After priming the instrument as described in Section 2.2.2, turn the volume adjuster wheel clockwise until the required pressure is achieved. Note: If the required pressure is not achieved or not stable, release the pressure in the instrument and repeat the priming sequence.
--------	---	---

2.2.4 Releasing Pressure

Step 1		To release pressure, open the pressure release knob by turning it counter-clockwise.
--------	--	--

2.2.5 How to achieve 400 bar

For applications where pressures above 400 bar are required to be generated it is recommended that the system is primed to around 25 bar using the priming pump and that a hydraulic hose of no more than 1m length is used to connect to the device under test.

Note: Using long (or wide-bore) hoses may prevent the required pressure from being reached within the limits of the screw pump mechanism.

2.2.6 How to replace the fluid in the Hydraulic System

The hydraulic system can either use ionized water or hydraulic fluid. The following instructions are for how to remove old fluid and replace with new fluid of the same type. Contact the Services Department for guidance about how to change the type of fluid medium in the device.

Wear the appropriate personal protection equipment when following these procedures e.g., eye protection glasses.

1. Remove old fluid in the Reservoir (if necessary clean the reservoir) and then fill the Reservoir with fresh fluid (to 75% reservoir capacity). Dispose of this old fluid in accordance with your company's procedures.
2. Attach this Reservoir to the DPI 610E Reservoir port.
3. Close the Pressure Release Valve (Hand tight).
4. Remove the DUT or (blanking plug if attached) and then attach the supplied hose (or compatible hose) to the test port with the open end of the hose in an empty container.



Chapter 2. Pump Operations

5. Turn the Volume adjustment wheel counter-clockwise until it stops.
6. Move the Priming pump handle seven strokes to move hydraulic fluid into the container.
7. Turn the Volume adjustment wheel clockwise until it stops.
8. Move the Priming pump handle seven strokes again.
9. Remove the hose from the test port and then make sure the fluid drains into the container.
10. Dispose of the old fluid collected in the container in accordance with the local regulations.
11. Use the blanking plug to seal the test port.
12. Make sure that Pressure Release Valve is closed (Hand tight), Power on the DPI 610E.
13. Operate the Priming pump until the indicated pressure is at 20bar.
14. Open the Pressure release valve.
15. Operate the Priming pump seven strokes.
16. Remove the reservoir and empty the hydraulic fluid (if necessary clean the reservoir again) and then fill the Reservoir with fresh fluid to the recommended level (75% full).
17. Attach the Reservoir filled with new fluid to the DPI 610E Reservoir port.

3. Basic Tasks

3.1 Tasks

Use the Dashboard to access the **Tasks** application. The **Tasks** menu has a list of tests that automatically configure the instrument when selected. The following options are available on the **Tasks** screen:

Step 1		<p>Select the Tasks icon on the Dashboard to show a list of available tasks. Tap on the task to select it.</p>
		<p>Note: Any Task option added to the Dashboard screen will be identified by a mini Home icon next to the option text. (As shown in the second screen).</p>

3.1.1 P-I (Pressure to Current measure)

This configures channel **CH1** to measure pressure, which can be internal (**INT**) or external (**EXT**). If external pressure is detected on **CH1**, it will retain this function, otherwise it defaults to internal pressure.

Channel **CH2** is configured to measure Current.

This task is typically for calibrating Current Output Pressure transmitters.

3.1.2 P-P (Pressure to Pressure)

This configures **CH1** to internal (**INT**) pressure measurement and **CH2** to external (**EXT**) pressure measurement.

3.1.3 P-V (Pressure to Voltage)

This configures **CH1** to measure pressure, that can be internal (**INT**) or external (**EXT**). If external pressure is detected on **CH1**, it will retain this function, otherwise it defaults to internal pressure. **CH2** is configured to measure Voltage.

This task is typically for calibrating Voltage Output Pressure transmitters.

3.1.4 I-P (Pressure to Current source)

This configures **CH1** to measure pressure, that can be internal (**INT**) or external (**EXT**). If external pressure is detected on **CH1**, it will retain this function otherwise, it defaults to internal pressure. **CH2** is configured to Current source.

This task is typically used for calibrating I/P pressure converters.

3.1.5 P-Display (Pressure to Display)

This configures **CH1** to measure pressure that can be internal (**INT**) or external (**EXT**). If external pressure is detected on **CH1**, it will keep this function otherwise, it defaults to internal pressure. **CH2** is configured to Observed function.

This task is typically used for calibrating pressure devices with no electrical output but which have a visual indication of measured pressure.

3.1.6 Leak Test

This configures **CH1** to pressure measure that can be internal (**INT**) or external (**EXT**) with the **Leak Test** utility. If external pressure is detected on **CH1**, then the external pressure configuration is kept, otherwise **CH1** defaults to internal pressure configuration.

CH2 configuration remains unchanged.

For more details on the **Leak Test**, refer to Section 7.1 on page 129.

3.1.7 Switch Test

This configures **CH1** to measure pressure, that can be internal (**INT**) or external (**EXT**) while the **Switch Test** utility details are displayed on **CH2**. If external pressure is detected on **CH1**, it keeps this function, otherwise it defaults to internal pressure.

For more details on the **Switch Test**, refer to Section 7.2 on page 134.

3.1.8 TX SIM (Transmitter Simulation)

This configures **CH1** to measure pressure, that can be internal (**INT**) or external (**EXT**). If external pressure is detected on **CH1**, it will retain this function otherwise, it defaults to internal pressure. **CH2** is configured with Current source (in transmitter simulation mode).

For more details on the **TX SIM** task, refer to Section 7.3 on page 137.

3.1.9 Relief Valve Test

This configures **CH1** to measure pressure, that can be internal (**INT**) or external (**EXT**), with the **Relief Valve Test** utility. If external pressure is detected on **CH1**, it will retain this function otherwise, it defaults to internal pressure.

CH2 configuration remains unchanged.




For more details on the **Relief Valve Test**, refer to Section 7.4 on page 139.


3.2 Tasks Selection

To select any of the options on the **Tasks** menu for automatic configuration, first tap the desired option to select it, then tap again to initiate the configuration of the selected task. This is effectively a two-tap action that can be done in quick succession. If using the navigation buttons, use the UP/DOWN/LEFT/RIGHT buttons to select the desired task and press the Navigation Pad




 **Enter** button to initiate configuration of the selected task.


3.3 Adding Tasks to the Dashboard

Up to three commonly used tasks from the Tasks menu can be added to the Dashboard (Home) screen as a shortcut. To add a **Task** option to the Dashboard, tap to select the desired Task, then select the **(HOME+)**  softkey to add the selected option to the Dashboard. If using the navigation buttons, use the UP/DOWN/LEFT/RIGHT buttons to select the desired task and press the **(HOME+)**  icon to add the selected option to the Dashboard. Any **Task** option added to the Dashboard screen will be identified by a mini Home  icon next to the option text.



3.4 Removing Tasks from the Dashboard


Only Tasks added through the **Tasks** menu can be removed from the Dashboard. To remove a Task option from the Dashboard: from the **Tasks** menu tap to select the desired Task, then select the **(HOMEEx)**  icon to remove the selected option. If using the navigation buttons, use the **UP/DOWN/LEFT/RIGHT** buttons to select the desired task and press the **(HOMEEx)**  softkey to remove the selected option. Once removed, the mini **HOME**  icon next to the option text will disappear.






4. General Settings

The following **General Settings** are available on the DPI 610E:

Setting	Description
DATE/TIME	Set the date/time.
LANGUAGE	Set the language.
BACKLIGHT	Turn the back light on/off.
USB	Select the USB communication mode.
AUTO POWER DOWN	Enable/disable Auto Power Down.
TOUCHSCREEN LOCK	Enable/disable Touchscreen Lock.
ENABLE HOLD	Enable/disable Hold.
ADVANCED	Access the Advanced Menu.

Note: To access the **General Settings** menu from the Dashboard, tap the  icon on the touchscreen or press the corresponding softkey as shown below:

Option 1		Tap the  icon on the touchscreen.
Option 2		Press the softkey corresponding to the General Settings icon.


4.1 DATE, TIME and LANGUAGE



To change the Date, Time and Language settings, see “Set Date, Time and Language” on page 25 and page 26.


4.2 BACKLIGHT

This feature controls the instrument backlight. By default, the DPI 610E is configured to **Timed (5 Minutes)**.

To change this setting:

1. Select **Backlight** from the **General Settings** menu.
2. Select the required mode (described below).
3. Select  to confirm.

	<p>If ALWAYS ON is selected, the backlight will remain on when the instrument is on, except when the battery is at a critically low level.</p>
	<p>If ALWAYS OFF is selected, the backlight will remain off at all times when the instrument is on.</p>


	<p>If TIMED (5 MINUTES) is selected, the backlight will remain on and automatically switch off after a period of 5 minutes of inactivity.</p>
---	--

4.3 USB

The following USB settings are available on the DPI 610E:

Setting	Description
Mass Storage	Storage mode facilitating the transfer of files/folders between the instrument and a PC.
Virtual Comms Port (VCP)	Communications mode.

Note: MASS STORAGE mode is the default USB setting at each power on.
To change this setting during use:




<p>Step 1</p>		<p>Select the MASS STORAGE radio button if it is not already selected.</p> <p>Select ✓ to confirm.</p>
---------------	---	---

4.4 AUTO POWER DOWN

This feature controls the auto power down behavior of the instrument. By default, the DPI 610E is configured to remain on until powered down by the user.

To change this setting:




1. Select **Auto Power Down**.
2. Select the required mode (described below).
3. Select ✓ to confirm.

	<p>If Never is selected, the instrument will remain on until powered down by the user.</p>
	<p>If 10 Minutes Inactivity is selected, the instrument will automatically switch off after 10 minutes of inactivity.</p> <p>Note: Auto Power Down will not come into effect until all tests running have been completed.</p>
	<p>If 30 Minutes Inactivity is selected, the instrument will automatically switch off after 30 minutes of inactivity.</p> <p>Note: Auto Power Down will not come into effect until all tests running have been completed.</p>

4.5 TOUCHSCREEN LOCK

This feature allows the user to lock the touchscreen and navigate using the navigation keypad and softkeys only. By default, the DPI 610E is configured with **Touchscreen Lock** disabled.

To change this setting:




Step 1		<p>Check that the TOUCHSCREEN LOCK box is unchecked (it has no Tick mark).</p>
Step 2		<p>Select OK.</p>
Step 3		<p>Ensure that TOUCHSCREEN LOCK is checked.</p> <p>Note: TOUCHSCREEN LOCK can be disabled by tapping anywhere on the touchscreen 3 times within 5 seconds.</p>

Chapter 4. General Settings

4.6 ENABLE HOLD

This feature allows the user to enable/disable the **Hold**  icon on the main reading screen. By default the DPI 610E is configured with **Enable Hold** enabled.

To change this setting:

Step 1		Click on the ENABLE HOLD checkbox to remove the tick mark.
Step 2		Select OK .
Step 3		Confirm that the ENABLE HOLD checkbox does not have a Tick mark.



4.7 ADVANCED


This feature provides access to the **Advanced Menu**, which has the following options:

Option	Description
CALIBRATION*	Calibration options.
CHANGE PIN	Change the Advanced menu PIN.
SOFTWARE UPGRADE	Upgrade system software.
FACTORY RESET	Set the instrument back to default settings
FORMAT FILE SYSTEM	Erases all content on mass storage and creates factory default folders
SERVICE/ ENGINEERING	Reserved for internal use

* The CALIBRATION options are dealt with by Chapter 13, “Instrument Calibration,” on page 252 and the other options from Section 5.2 on page 55 forwards.

To access the **Advanced Menu**:

Step 1		<p>Enter the PIN. The default PIN is 4321 and it can be changed by the user at any time. See Section 5.2 on page 55.</p>
Step 2		<p>Select ✓ to confirm.</p>

Step 3		The Advanced Menu screen is now unlocked and its options available (see Chapter 5, “Advanced Menu,” on page 53).
--------	---	---

5. Advanced Menu

The following options are available in the **Advanced** menu:

Option	Description
*CALIBRATION	Calibration options
CHANGE PIN	Change the PIN
SOFTWARE UPGRADE	Start software upgrade
FACTORY RESET	Set the instrument back to default settings
FORMAT FILE SYSTEM	Erases all content on mass storage and creates factory default folders
SERVICE / ENGINEERING	Reserved for internal use

* A separate chapter describes the **Instrument Calibration** options that become available when CALIBRATION is selected. (See Chapter 13, “Instrument Calibration,” on page 252).

Note: To access the Advanced menu, select **ADVANCED** from the **General Settings** menu (see Chapter 4.7, “ADVANCED,” on page 51).

5.1 CALIBRATION Menu

The **INSTRUMENT** option is available in the **Calibration** screen (Figure 5-1):

Option	Description
INSTRUMENT	Perform calibration activities on the instrument




Figure 5-1: Calibration Menu



Note: To access the **CALIBRATION** menu (Figure 5-1), select **CALIBRATION** from the **Advanced Menu** screen as shown below:

Step 1	A screenshot of a mobile application interface titled "Advanced Menu". It lists several options: "> CALIBRATION", "CHANGE PIN", "SOFTWARE UPGRADE", "FACTORY RESET", "FORMAT FILE SYSTEM", and "SERVICE / ENGINEERING". The "> CALIBRATION" option is highlighted with a red rectangular border. At the bottom, there is a status bar showing the date and time "04 MAY 2022 14:28" and a battery level icon. A black curved arrow points from the bottom right corner of the screen towards the caption.	Select CALIBRATION from the Advanced Menu .
--------	---	---

Refer to Chapter 13, “Instrument Calibration,” on page 252 that describes the options available when this CALIBRATION menu becomes active.

5.2 CHANGE PIN






This option allows the user to change the instrument PIN number.




Step 1		Select CHANGE PIN from the Advanced menu.
Step 2		To change the PIN to a new number, use the onscreen keypad to enter the new number. Select ✓, enter the new PIN again and select ✓ to confirm the selection.

5.3 SOFTWARE UPGRADE

This option allows the user to upgrade the firmware software of the instrument. Before this can be done, a software upgrade file must first be transferred into the instrument.

5.3.1 How to load a Software Upgrade File

Step 1	Download the “DK0492.raw” application image from https://inspectionworks.com/druck-portal/#/store/public on to the PC that is to connect to the DPI 610E. Make sure the file name is not renamed.	
Step 2		<p>Select the Settings icon  on the Dashboard. Press the Home button  if necessary, to show the Dashboard. To select, tap on the icon or press the softkey on the right of icon.</p>
Step 3		<p>The General Settings screen appears. Select the USB option.</p> <div data-bbox="501 1682 1091 2040">  <p>USB PORT</p> </div>



Step 4		<p>Click on MASS STORAGE to select the option.</p> <p>Select ✓ to confirm the selection.</p>
Step 5	<p>Connect the DPI 610E to the PC using a micro-USB data cable. The PC should automatically detect the DPI 610E which should appear as a Mass Storage drive (default name is DPI610E).</p> 	
Step 6	<p>Copy the DK0492.raw file from the PC file system location and paste it into the root directory of the DPI 610E mass storage drive.</p>  <p>If a previously existing DK0492.raw file is present, a popup window will indicate this. Select Overwrite to replace the old file.</p>	










Chapter 5. Advanced Menu

Step 7	Remove the USB cable from the DPI 610E when the successful transfer of the DK0492.raw file from the PC to the memory of the DPI 610E is confirmed. The next heading describes the procedure for how to upgrade the software firmware.
--------	---

5.3.2 How to upgrade the Firmware




Use the following procedure to upgrade the firmware (software embedded in hardware):



Step 1		Select SOFTWARE UPGRADE from the Advanced Menu screen. Refer to Section 5.3.1 on page 56 for how to show this screen.
Step 2		Press the OK button to start the upgrade process. Be aware that this will reboot the DPI 610E.

Step 3	   	<p>The DPI 610E starts again and shows the Dashboard screen.</p> <p>Press the Information (Status)  icon then select SOFTWARE BUILD on the Status screen that appears.</p> <p>The versions of the DK0491 Boot-loader and DK0492 Application software will be shown. Check that these are correct.</p> <p>The  icon shows a QR image that can be scanned using a mobile phone. This will take you to a website that describes how to upgrade your application.</p> <p>Select  to return to the Status screen.</p>
Step 4	 	<p>If the 'Software Upgrade file not found' notification appears. Make sure that the upgrade file "DK0492.raw" has been copied into the instrument's root directory, as stated in the previous steps.</p> <p>Select the OK button to close this screen message.</p> <p>Contact the Technical Support Dept using the links given in Chapter 1 of this manual if you are unable to upgrade the software.</p>

5.4 FACTORY RESET




This option allows the user to reset the instrument to factory settings. You have the option to remove all previous user files by this operation (Step 3 below).

Step 1		Select FACTORY RESET from the Advanced Menu screen.
Step 2		Select the OK button to confirm the selection of Factory Reset .
Step 3		Select the OK button to confirm deletion of all user files.

Step 4		Select the OK button to confirm the restart of instrument.
Option		If Cancel is selected in Step 4, reset will be completed on next boot. Select the OK button to confirm selection.

5.5 FORMAT FILE SYSTEM

The file system can be formatted if the instrument is out of storage space and a one-step clear-out is desired. It is important to save any important files as well as the files available in the HART folder before formatting. (Use the Step 5 to 6 procedures in Section 5.3.1 on page 56 to copy files).

Step 1		Select FORMAT FILE SYSTEM from the Advanced Menu screen.
Step 2		A popup window appears. All user files must be deleted, to enable formatting of the file system operation to occur. Press the OK button to proceed.
Step 3		To restart the instrument and complete the format operation, select Yes in the popup message window. If No is selected, a popup message appears "Formatting will be completed on next reboot". Click OK to close this message window. After the instrument is restarted, copy any backup files back into their respective folders.

5.6 SERVICE / ENGINEERING

This Advanced **SERVICE/ENGINEERING** function is not for operator use and requires a PIN for use only by specialist users.

6. Calibrator Tasks

6.1 Calibrator Task Screen






Figure 6-1: Calibrator Task Screen

1. **Function Name** – name of the currently selected function on the channel.
2. **Primary reading** – measured values that directly represent the channel function description and displayed in large digits within the channel windows. A secondary reading can appear in either channel window. This reading is in smaller digits just above the primary reading and shows the measured values associated with the primary reading of the channel function.
3. **Full-scale value** – each function selected has a maximum measurement capability which is captured by the positive full-scale value. It is always displayed in the channel window (with a prefix **FS:**).
4. **Sensor Type** – this applies to pressure or temperature sensors. The pressure sensor type (Gauge, Sealed Gauge or Absolute) or RTD sensor being used by the channel function will be displayed in this field.
5. **Process Options** – any Process options that are currently active for each channel is indicated by process icons in this area of the channel window.
6. **Units** – measurement units of the primary (and secondary reading where applicable) are displayed in the units field on the right hand side of the channel window below the primary reading.
7. **Full Scale Bar** – this bar gives a visual indication of the proportion of generated and measured pressure from the internal sensor of the full-scale range.
8. **Status bar** – the status bar area is present throughout the user interface and provides date and time information, battery level indication on the bottom right hand side of the screen. On the left side of the status bar, additional information about remote or external sensor connection status is provided. Critical information such as calibration overdue or an alarm condition also appear in this status bar.
9. **Softkey** – up to four softkeys are available throughout the menu screens giving touchscreen and button options for operating different aspects of the user interface.

6.1.1 Calibrator Tasks Screen Shortcuts

6.1.1.1 Maximize and Minimize Channel Window

Using the Touchscreen






<p>Step 1</p>	<div> </div>	<p>When in the default 50:50 channel window layout, tap on any blank area on the desired channel window (except the Units area) to maximize the window area. This will minimize the other channel window.</p>
---------------	---	---



INFORMATION When in maximized/minimized layout, the 50:50 layout can be restored by tapping on any area of the channel windows with the exception of the Units area.

Chapter 6. Calibrator Tasks






Using Navigation Buttons

<p>Step 1</p>	 	<p>When in the default 50:50 channel window layout, press the UP button to select the Channel 1 (CH1) window area.</p>
<p> INFORMATION Press the DOWN button to select the Channel 2 (CH2) window area.</p>		
<p>Step 2</p>	 	<p>Press the Enter button to maximize the Channel window.</p>

 **INFORMATION** When in a maximized/minimized layout, the 50:50 layout can be restored by pressing the **ENTER** button.

6.1.1.2 Change Measurement Units

To change the measurement units on each channel on the calibrator task screen:

Step 1		<p>Select the units text on the relevant channel window.</p> <p>From the dashboard select:</p> <p>CALIBRATOR >>  or  >> UNITS.</p>
Step 2		<p>Select the desired unit from the CH Units screen. Either tap the unit required on the screen or use the Navigation key pad arrow keys to select the unit.</p> <p>Select ✓ to confirm the selection.</p> <p>Note: A DPI 610E can be ordered as either SI only or use both SI and Non-SI units. An SI model will only show SI units on this screen.</p>
Step 3		<p>The desired unit appears on the configured channel window.</p>

Note: An alternative method to select units of measurement is given in Step 3 of Section 2.1.6 on page 30.

Chapter 6. Calibrator Tasks

6.1.1.3 10 V/24 V Loop Power Enable/Disable

The Loop Drive is the internal power supplied by the DPI 610E. It is available to use with any of the electrical functions listed in the **CH2 Setup** screen (to enable the Loop Power, see Section 6.2.9 on page 89).

When 10 V or 24 V Loop Power is enabled, it is displayed at the top of the **CH2** channel window (see Figure 6-2).






Figure 6-2: 24 V Loop Power Enabled

The **Loop Power** function can be disabled quickly without leaving the Calibrator screen:






Using the Touchscreen

Step 1	 <p>The first screenshot shows the Calibrator screen with '24V ON' highlighted in a red box. The second screenshot shows the same screen with '24V ON' removed, indicating the function has been disabled.</p>	<p>Tap on the 10 V/ 24 V text field in the Calibrator screen.</p> <p>Check that the 10 V/ 24 V function has been disabled: as shown by the removal of the voltage text field (e.g. 24V ON).</p>
--------	--	--

Using Navigation Buttons

Step 1	 <p>The screenshot shows the Calibrator screen with a navigation pad overlay. The 'DOWN' button is highlighted with a red box, indicating it should be pressed to select the channel 2 window area.</p>	<p>Press the DOWN button to select the channel 2 window area.</p>
--------	--	--



Chapter 6. Calibrator Tasks

Step 2	 	Press the RIGHT button until the 10V/24V text area is highlighted.
Step 3	 	Press the Enter Key to cancel the 24V ON function.
Step 4		Check that the 10 V/24 V function is not in the display after the function has been disabled.

6.1.2 Error Indications

An out-of-range error message occurs when the values of the primary reading measure are more than the full-scale value of the function range.

Table 6-1: Error Indicators

Condition	Description	Depiction
Under-range	Measured reading<110% of the negative full-scale value.	
Over-range	Measured reading>110% positive full scale.	



INFORMATION If the display shows any of the above error indications: Check the sensor/measurement full scale pressure range (shown on screen) against the range of the system being measured.

6.2 Functions

6.2.1 Functions available by channel




Figure 6-3: Channel 1 Functions




Figure 6-4: Channel 2 Functions

Figure 6-5 is a channel function combination matrix. It shows the combinations of channel selections that are supported in the DPI 610E product range.

Figure 6-5: Channel Function Combination Matrix

			Channel 2										
			None	Electrical	Pressure				Barometer	Observed	RTD	HART	
					INT		Ext						
					Normal	Pseudo	Normal	Pseudo					
Channel 1	None			o	o	o	o	o	o	o	o	o	
	Pressure	INT	Normal	o	o	x	x	o	o	o	o	o	
			Pseudo	o	o	x	x	o	x	x	o	o	
		EXT	Normal	o	o	o	o	x	x	o	o	x	o
			Pseudo	o	o	o	x	x	x	x	o	x	o
	Sum			o	o	x	x	x	x	o	o	o	o
	Difference			o	o	x	x	x	x	o	o	o	o
Barometer			o	o	o	x	o	x	x	o	o	o	
Observed			o	o	o	o	o	o	o	o	o	o	
RTD			o	o	o	o	x	x	o	o	x	o	



INFORMATION 'Electrical' includes Current, Voltage and Millivolt functions.

Note: 'o' denotes a supported combination of functions.

Note: 'x' denotes that a combination of functions is not supported.

Chapter 6. Calibrator Tasks

6.2.2 None

Users can select this function option if they do not wish to display any function or readings on the channel being setup. On the Calibrator main reading screen, the channel window will be cleared of all readings and information with only the function name present.

6.2.3 Pressure

6.2.3.1 Internal Pressure

Pneumatic units contain internal pressure sensors which range from 350 mbarg to 35barg.




Hydraulic units contain internal pressure sensors which range from 70 bara/g to 1000bara.

Available internal pressure sensors are listed in Table 6-2.




Table 6-2: Internal Pressure Sensors in DPI 610E Range

Pressure	Pressure Range Code	Pneumatic	Hydraulic
350 mbar / 5 psi / 35 kPa	03	G	-
1 bar / 15 psi / 100 kPa	05	G	-
2 bar / 30 psi / 200 kPa	07	G	-
3.5 bar / 50 psi / 350 kPa	08	G	-
7 bar / 100 psi / 700 kPa	10	G	-
10 bar / 150 psi / 1000 kPa	11	G	-
20 bar / 300 psi / 2 MPa	13	G	-
35 bar / 500 psi / 3.5 MPa	14	G	-
70 bar / 1000 psi / 7 MPa	16	-	G or A
100 bar / 1500 psi / 10 MPa	165	-	G or A
135 bar / 2000 psi / 13.5 MPa	17	-	G or A
200 bar / 3000 psi / 20 MPa	18	-	G or A
350 bar / 5000 psi / 35 MPa	20	-	A
700 bar / 10000 psi / 70 MPa	22	-	A
1000 bar / 15000 psi / 100 MPa	23	-	A

To configure a pressure measurement reading from an internal sensor

<p>Step 1</p>		<p>Select the desired channel (Channel 1 in this example).</p>																								
<p>Step 2</p>		<p>Select FUNCTION in the Channel Setup screen.</p>																								
<p>Step 3</p>	 <table border="1"> <thead> <tr> <th>FUNCTION</th><th>SENSOR</th><th>RANGE</th></tr> </thead> <tbody> <tr> <td>None</td><td>INT</td><td>Normal</td></tr> <tr> <td>Pressure</td><td>EXT</td><td>Pseudo</td></tr> <tr> <td>Sum</td><td></td><td></td></tr> <tr> <td>Difference</td><td></td><td></td></tr> <tr> <td>Barometer</td><td></td><td></td></tr> <tr> <td>Observed</td><td></td><td></td></tr> <tr> <td>RTD</td><td></td><td></td></tr> </tbody> </table>	FUNCTION	SENSOR	RANGE	None	INT	Normal	Pressure	EXT	Pseudo	Sum			Difference			Barometer			Observed			RTD			<p>Select Pressure in the Channel Function screen. Select INT (for Internal). Select Normal or Pseudo.</p> <p>Select ✓ to confirm the selections.</p>
FUNCTION	SENSOR	RANGE																								
None	INT	Normal																								
Pressure	EXT	Pseudo																								
Sum																										
Difference																										
Barometer																										
Observed																										
RTD																										

i **INFORMATION** See Chapter 6.2.3.4, “Normal and Pseudo Pressure Range,” on page 78.

Step 4		Check that the desired configuration appears in the Channel Setup screen. Select  to return to the Calibrator Main screen.
Step 5		Check that INT Pressure appears on top left corner of the desired channel screen.

6.2.3.2 External Pressure

External pressure sensors (PM700E) are available in the range 25 mbarg/d to 1400 bara. Refer to “External Sensors” on page 141 for a list of available sensors, and information about how to configure the DPI 610E to recognize and use external sensors and RTD probes.



6.2.3.3 The Zero Function



The **Zero** function is used on gauge sensors to remove offset drifts and therefore maintain the highest accuracy.

i **INFORMATION** The Zero function is only available on gauge sensors. It is not possible to apply total vacuum to absolute sensors, as they are designed to measure atmospheric pressure.

Note: It is recommended that all gauge sensors are zeroed at the beginning of each day before use.

To zero a gauge sensor

Step 1	See Chapter 2.1.3 on page 27 for pneumatic units or Chapter 2.2.4 on page 39 for hydraulic units.	Make sure that the sensor is open to atmosphere. Example: For the DPI 610E internal sensor, open the pressure release knob fully or make sure that the test port is open to atmosphere.
Step 2	See Chapter 6.2.3.1 (INT) or Chapter 6.2.3.2 (EXT).	Select the desired pressure function (INT or EXT) from the CH Setup menu on CH1 or CH2 .
Step 3		Expand the pressure channel by tapping anywhere in the channel window (except the Units area) (See Chapter 6.1.1.1, “Maximize and Minimize Channel Window,” on page 65).
Step 4		Select 0 to set the pressure sensor to zero.

Step 5		Select OK to confirm.
Step 6		<p>Check that the desired pressure channel has been zeroed.</p> <p>Note: A Zero Error can occur if the pressure reading, measured from the sensor, is outside 1% of the full scale value when the instrument pressure port is opened to atmosphere.</p>

6.2.3.4 Normal and Pseudo Pressure Range

Internal and external pressure sensors are either gauge (measuring with respect to atmospheric pressure) or absolute (measuring with respect to vacuum). The measured readings from these sensors in their native form are referred to as 'Normal'.

The sensors in pneumatic variants contain an accurate barometer which continuously measures the atmospheric pressure. This measured reading can be used to convert the internal (or external if present) pressure sensor reading from natively absolute to gauge or natively gauge to absolute. These pressure sensor modes are referred to as 'Pseudo-gauge' (natively absolute sensor to a gauge indication) and 'Pseudo-abs' (natively gauge sensor to absolute indication) respectively.

The hydraulic variants do not contain the barometer as it is not usual to require gauge readings at the higher pressure at which these hydraulic variants operate. Therefore, the hydraulic variants do not support 'Pseudo-gauge' or 'Pseudo-abs' ranges.


6.2.3.5 Sealed Gauge Pressure Range

Hydraulic variants with internal or external absolute pressure sensors up to 10 bar and above, can use an atmospheric reading to convert the sensor reading to gauge by taring the atmospheric pressure value. This sensor mode is referred to as 'Sealed Gauge'. When a supported absolute pressure sensor is connected and detected and the pressure function is configured on either channel, a pop-up window is displayed giving the option to use the sensor in absolute or sealed gauge mode.

How to configure an External Sensor as a Sealed Gauge





The **EXT** Pressure function must be configured in one of the channels and you need to go into Calibrator to trigger this popup message.

Step 1		<p>Switch on the instrument and select the Calibrator icon and when the popup window appears select YES. If the instrument is already switched on select the CH1 or CH2 channel.</p>
--------	---	--



INFORMATION If NO is selected, the sensor will be used in its native form - as an Absolute pressure sensor.

Step 2		<p>Make sure that the pressure port is open to atmosphere and proceed when the pressure reading is stable. Select ✓ to confirm.</p>
Step 3		<p>Make sure that Sealed Gauge is correctly configured on the desired channel.</p>

Chapter 6. Calibrator Tasks

How to configure an Internal Sensor as a Sealed Gauge



INFORMATION The INT Pressure function must be configured in one of the channels and you need to go into Calibrator to trigger this popup message.

Step 1		Select YES .
--------	--	---------------------



INFORMATION If NO is selected the sensor will be used in its native form - an Absolute pressure sensor.

Step 2		Make sure that the pressure port is open to atmosphere. When the pressure reading is stable, select the ✓ icon.
Step 3		Make sure that Sealed Gauge is correctly configured on the desired channel.




6.2.4 Sum

Sum is a pressure related function which allows the internal pressure reading from the instrument to be combined with the pressure reading from an external sensor. An external pressure sensor must be connected to see the resulting reading on the **Calibrator Main** screen.



The **SUM** function is only available on **CH1**. If the **SUM** function is selected on **CH1**, the **INT** Pressure function or **EXT** Pressure function cannot be configured on **CH2**.

Note: Care should be taken, when both sensors are not gauge, to make sure the contribution from atmospheric pressure has been considered.

To configure a pressure measurement reading using the **Sum** function:

Step 1		Tap the CH1  icon to select Channel 1 or push the related softkey.
Step 2		Select FUNCTION from the Channel Setup menu.

Chapter 6. Calibrator Tasks






Step 3		<p>Select Sum from the channel FUNCTION menu.</p> <p>Select ✓ to confirm. The CH Setup screen will appear again.</p>
Step 4		<p>Check that the desired configuration appears in the CH Setup menu.</p> <p>Select ↶ to go back to the Calibrator Main screen.</p>

6.2.5 Difference




Difference is a pressure related function: this allows the difference between the internal pressure sensor reading and the external pressure sensor reading to appear on the calibrator task screen. An external pressure sensor must be connected to see the resulting pressure reading.

Note: Be careful when both sensors are not the same type (absolute/gauge), to make sure to compensate for the contribution from atmospheric pressure.

To configure a pressure measurement reading using the **Difference** function:

Step 1		Tap the CH1  icon to select Channel 1 or push the related softkey.
Step 2		Select FUNCTION from the Channel Setup menu.
Step 3		Select Difference from the FUNCTION menu. Select INT-EXT or EXT-INT as desired. Select  to confirm.





Chapter 6. Calibrator Tasks

Step 4		<p>Check that the desired configuration appears in the CH Setup menu.</p> <p>Select  to return to the Calibrator Main screen.</p>
Step 5		<p>Confirm that the Difference function is correctly configured on the desired channel.</p> <p>The Difference DIFF icon together with the function name, will be Pressure (INT-EXT) or (EXT-INT) depending on the priority chosen. The FS values of both the internal sensor and the external sensor will also be displayed. The sensor type field will also be updated where required.</p>




6.2.6 Barometer

The internal Barometer can measure a range of 750 to 1150 mbar. The **Barometer** function allows the measured atmospheric pressure to be displayed on the **Calibrator Main** reading screen as a primary reading. The internal barometer is only available in the pneumatic variant.

To configure a pressure measurement reading using the Barometer function:

Step 1		Select the CH1 or CH2 icon as desired.
Step 2		Select FUNCTION from the Channel Setup menu to show the CH1 Function screen.
Step 3		<p>Select Barometer in the channel FUNCTION menu.</p> <p>Select the Tick  button to confirm the selection.</p>





Chapter 6. Calibrator Tasks

Step 4		<p>Confirm that the INT Barometer function appears in the CH Setup menu.</p> <p>Select the Back  icon to go to the Calibrator Main Screen.</p>
Step 5		<p>Check that the Barometer function is correctly configured in the desired channel window.</p>




6.2.7 Observed

The **Observed** function is a non-measured function and has a range of +/- 999999.9. It allows manual entry of an observed reading from an external measuring and indicating device. It is often used in conjunction with a second measured function on another channel to record the relationship between the two readings.

To configure a channel using the **Observed** function:


Step 1		Select the CH1 or CH2 as desired.
Step 2		Select FUNCTION from the Channel Setup menu.
Step 3		<p>Select Observed from the channel FUNCTION menu.</p> <p>Select the Tick  button to confirm the selection.</p>

Chapter 6. Calibrator Tasks

Step 4		<p>Check that the Observed function appears in the CH Setup menu.</p> <p>Select  to return to the Calibrator Main screen.</p>
Step 5		<p>The Observed message will appear in the top left corner of the screen display.</p> <p>To select a different unit of measurement, refer to Section 6.1.1.2 on page 67 for instructions.</p>

6.2.8 RTD

The RTD function enables temperature or resistance measurements to be on the **Calibrator** main reading screen as a primary reading when the RTD-Probe is connected to the DPI 610E via the RTD-Interface (or RTD-Interface-IS).



When the RTD-Interface connection is detected, the sensor  icon is shown in the status bar and the “Connected” text briefly appears, to confirm successful connection. Upon disconnection, the sensor icon will disappear and the “Disconnected” text briefly appears, to confirm the connection has been lost.

6.2.9 Current




The current measurement range: +/- 55 mA.
The DPI 610E can measure or source electrical current expressed in milliamps (mA). Only **CH2** can do this. When using the **CH2 Current** function, there is the additional option to use the internal 10 V (non-IS instruments only) or 24 V power supply provided by DPI 610E or to use an external power supply for the device under test.










6.2.9.1 Current Measure

It is necessary to use the correct terminals to configure the **Current Measure** function:

Step 1	<div> </div>	<p>Use the diagram on the left to make the necessary connections for Current Measure when the 24V internal power supply is not used (the Off option is selected in Step 4).</p> <p>Use the diagram on the left to make the necessary connections for Current Measure using the internal 24 V supply.</p>
--------	---	--

Chapter 6. Calibrator Tasks





Step 2		Select the CH2 channel.																								
Step 3		Select FUNCTION from the CH2 Setup screen.																								
Step 4	 <table border="1"> <thead> <tr> <th>FUNCTION</th><th>DIRECTION</th><th>POWER</th></tr> </thead> <tbody> <tr> <td>None</td><td>Measure</td><td>Off</td></tr> <tr> <td>Current</td><td>Source</td><td>24V</td></tr> <tr> <td>Voltage</td><td></td><td></td></tr> <tr> <td>Millivolts</td><td></td><td></td></tr> <tr> <td>Pressure</td><td></td><td></td></tr> <tr> <td>Barometer</td><td></td><td></td></tr> <tr> <td>Observed</td><td></td><td></td></tr> </tbody> </table>	FUNCTION	DIRECTION	POWER	None	Measure	Off	Current	Source	24V	Voltage			Millivolts			Pressure			Barometer			Observed			<p>Select Current > Measure > then select one of the following: 10 V for measure with internal 10 V Loop Power supply (only for non-IS units) OR 24 V for measure with internal 24 V Loop Power supply.</p> <p>Select ✓ to confirm the selection. If Off is selected the electrical connections will not be the same as for when 24 V or 10 V is selected (see Step 1).</p>
FUNCTION	DIRECTION	POWER																								
None	Measure	Off																								
Current	Source	24V																								
Voltage																										
Millivolts																										
Pressure																										
Barometer																										
Observed																										
















<p>Step 5</p>	<div data-bbox="312 210 831 663"> <p>CH2 Setup</p> <p>> FUNCTION  Current (24V)</p> <p>PROCESS None</p> <p>UNITS mA</p> <p>RESOLUTION 6 Digits</p> <p>CONFIGURATION</p> </div> <div data-bbox="312 707 820 1160"> <p>INT Pressure</p> <p>21.5340</p> <p>FS: 35.0000 Gauge bar</p> <p></p> <p> Current 24V ON</p> <p>5.0791</p> <p>FS: 55.0000 mA</p> </div> <div data-bbox="836 591 927 663">  </div> <div data-bbox="836 707 911 1160"> <p>CH1 </p> <p></p> <p>CH2 </p> <p></p> </div>	<p>This screen will have only “Current” as the Function when Off is selected. When 24V is selected, “Current (24V)” will appear.</p> <p>Select the Back  icon to go to the Calibrator Main Screen.</p> <p>The Calibration screen will show “24V ON” in the CH2 screen area. If Off has been selected, only “Current” will be in the top of this area.</p>
---------------	--	---

Chapter 6. Calibrator Tasks

6.2.9.2 Current Source


To configure the **Current Source** function:

<p>Step 1</p>	<div data-bbox="411 320 734 768"></div> <div data-bbox="406 855 761 1303"></div>	<p>Use the diagram on the left to make the necessary connections for Current Source when the 10V/24V internal power supply is not used (when the Off option is selected in Step 4).</p> <p>Use the diagram on the left to make the necessary connections for Current Source using the internal 10 V or 24 V supply.</p>
<p>Step 2</p>	<div data-bbox="274 1384 888 1836"></div>	<p>Select the  CH2 channel.</p>

Step 3	 <p>CH2 Setup</p> <p>> FUNCTION  Voltage</p> <p>PROCESS None</p> <p>UNITS V</p> <p>RESOLUTION 6 Digits</p> <p>04 MAY 2022 14:28 </p> <p></p>	<p>Select FUNCTION from the Channel Setup menu.</p>																								
Step 4	 <p>CH2 Function 1/2</p> <table border="1"> <thead> <tr> <th>FUNCTION</th><th>DIRECTION</th><th>POWER</th></tr> </thead> <tbody> <tr> <td>None</td><td>Measure</td><td>off</td></tr> <tr> <td>Current</td><td>Source</td><td>24V</td></tr> <tr> <td>Voltage</td><td></td><td>10V</td></tr> <tr> <td>Millivolts</td><td></td><td></td></tr> <tr> <td>Pressure</td><td></td><td></td></tr> <tr> <td>Barometer</td><td></td><td></td></tr> <tr> <td>Observed</td><td></td><td></td></tr> </tbody> </table> <p>04 MAY 2022 14:28 </p> <p></p> <p></p> <p></p>  <p>CH2 Setup</p> <p>> FUNCTION  Current (24V)</p> <p>PROCESS None</p> <p>UNITS mA</p> <p>RESOLUTION 6 Digits</p> <p>04 MAY 2022 14:28 </p> <p></p>	FUNCTION	DIRECTION	POWER	None	Measure	off	Current	Source	24V	Voltage		10V	Millivolts			Pressure			Barometer			Observed			<p>Select Current > Source > then select one of the following: 10 V for measure with internal 10 V Loop Power supply (only for non-IS units) OR 24 V for measure with internal 24 V Loop Power supply.</p> <p>Select  to confirm the selection. If Off is selected the electrical connections will not be the same as for when 24 V or 10 V is selected (see Step 1).</p> <p>This screen will have only “Current” as the Function when Off is selected. When 24V is selected, “Current (24V)” will appear. When 10V is selected, “Current (10V)” will appear.</p> <p>Select the Back  icon to go to the Calibrator Main screen</p>
FUNCTION	DIRECTION	POWER																								
None	Measure	off																								
Current	Source	24V																								
Voltage		10V																								
Millivolts																										
Pressure																										
Barometer																										
Observed																										

Chapter 6. Calibrator Tasks

Direct Input of Current Value



The DPI 610E can provide electrical current accurately within the 0 to 24 mA range. The diagram on the left shows the terminal connections for this configuration.

You can directly input the current value to be sourced. The Touchscreen or the Navigation Pad can then be used to input this current value:




	<p>Use the Touchscreen to set the source current</p> <p>Tap in the Current Value field. Enter the required current source value using the UP/DOWN arrow icons on the left of the field.</p>
	<p>Use the Navigation Pad to set the source current</p> <p>Press the DOWN button to select the CH2 window area.</p> <p>Press the RIGHT button until the source value is outlined in bold.</p> <p>Press the OK (Enter) button to show the source value entry screen. Enter the new value using the onscreen keyboard, and press the Tick ✓ softkey to confirm.</p>
<p>INFORMATION Once a target current source value is set, the displayed value will start to flash on the main reading screen. Once the setpoint has been reached, the source value will stop flashing and remain steady.</p>	

Source Automation Options










The other methods to set the current source output are:

1. Nudge (manual)
2. Span Check (manual or automated)
3. Percent Step (manual or automated)
4. Defined Step (manual or automated)
5. Ramp (automated).

These methods are explained in this chapter, however, the Configuration Options must first be set before these methods can be used. Make sure the type of test has been selected (See Section 3.2 on page 44), to make available the required screens.













Step 1		<p>Tap on the CH2 window (anywhere except the Units area) or, if using the navigation keypad, press the DOWN button to select CH2, then press the OK button to expand the channel window.</p>
Step 2		<p>Select the Tool options  icon to show the Source Automation screen.</p>

Chapter 6. Calibrator Tasks

Step 3	   	<p>Select the desired option from the Source Automation screen, for example: NUDGE.</p>
Step 4	   	<p>If required, select the Edit  softkey to configure the selected automation. Note: Different automation options will have different configuration parameters.</p>

1. NUDGE

This is the default **Source Automation** option. It allows the source value to be incremented or decremented by a defined step size value. This can be achieved in the current source channel window by:

<p>Step 1</p>		<p>To use the Navigation Pad When using the keypad, press the DOWN button to select the CH2 window and Enter  to enlarge the window. If necessary use the up  or down  screen keys to increase or decrease the current value. Press the Tool  icon to show the Source Automation menu.</p> <p>Press the Edit  softkey to show the Nudge Automation menu. Go to step 2 to change the settings if required.</p> <p>To use the screen From the Source Automation menu select the NUDGE radio button and then the Edit  softkey to show the Nudge Automation menu. The Nudge automation settings will appear. Go to Step 2 to change the settings if required.</p> <p>Click the Proceed  softkey to activate the option and return to the Calibrator screen.</p>
<p>Step 2</p>		<p>To change the step size, select the STEP SIZE row to show an onscreen keypad, enter the new value using the onscreen or Navigator keys.</p> <p>Select the Tick  icon/softkey to save the new values or the Back  icon if you do not want to save the new values. For a description of SCALING refer to Section 6.3.6 on page 123.</p> <p>Select the Proceed  softkey to use the selected automation option and its automation settings.</p>





Chapter 6. Calibrator Tasks


2. SPAN CHECK

Span Check is normally used to check the span of a device under test by providing the minimum current output corresponding to the device's zero or negative full-scale, and the maximum current output corresponding to the positive full-scale of the device under test. For most current output devices, this minimum and maximum values are 4 and 20 mA respectively. These are the default values for the Span Check automation.

The **SPAN CHECK** function allows a 2-point span check. **LOW** (minimum) and **HIGH** (maximum) span values can be set. The **DWELL** time is the interval to wait at each Span Point before changing to the other span point and vice versa.

To change the **LOW** or **HIGH** span values or the **DWELL** time:

Step 1		<p>From the Source Automation screen tap the SPAN CHECK radio button to show the Span Check Automation screen.</p> <p>If you want to view or edit the SPAN CHECK automation settings, go to Step 2. Otherwise, select the Proceed  softkey to activate the automation option and return to the Calibrator screen.</p> <p>If required, select the Edit  softkey to change the selected automation values.</p>
Step 2		<p>Select the parameter value to be changed.</p> <p>Enter the new value using the onscreen or Navigator keys.</p> <p>For a description of Scaling refer to Section 6.3.6 on page 123.</p>

<p>Step 3</p>		<p>The Calibrator screen will have two additional icons indicating that the Span Check mode is active, and the Auto-repeat operation is available.</p>
---------------	---	---


LOW value - is the first current source value to be set using this option.





HIGH value - is the maximum current source value set-point using this option.

DWELL - the time interval which can be set to wait at the low value before changing to the high value and vice versa.

SCALING - refer to Section 6.3.6 on page 123 for a description of the use of Scaling.

After selection of **Span Check** automation, the **Span Check**  icon appears at the top right of the **CH2** window in the calibrator screen.








The Span check can be done manually by using the **UP** and **DOWN** nudge buttons to switch between the **LOW** and **HIGH** source values. It can also be automated by pressing the automation **Play**  softkey.

The **Auto-repeat**  icon also appears next to the **Span Check** automation  icon, as the **Span Check** cycle is automatically repeated when using the automation **Play**  softkey, until manually stopped. To stop the automation at any time, press the **Cancel**  softkey.

Chapter 6. Calibrator Tasks

3. PERCENT STEP

The **PERCENT STEP** function allows the source value to be incremented in steps that correspond to a set percentage of the span. The **LOW**, **HIGH** and **STEP SIZE** value can be set as well as the option to auto-repeat this automation process.

Step 1		<p>From the Source Automation screen tap the PERCENT STEP radio button. If you want to view or edit the PERCENT STEP automation settings, go to Step 2. Otherwise, select the Proceed  softkey to activate the automation option and return to the Calibrator screen.</p> <p>If required, select the Edit  softkey to change the selected automation values.</p>
Step 2		<p>Select the parameter value to be changed. Enter the new value using the onscreen or Navigator keys. For a description of Scaling refer to Section 6.3.6 on page 123.</p>
Step 3		<p>The Calibrator screen will display the Percent Check  icon and the Auto-repeat  operation if enabled.</p>

LOW value - is the first current source value to be set using this option.


HIGH value - is the maximum current source value set-point using this option.




STEP SIZE value - is the magnitude of each step increment or decrement. When using this option, it is expressed as a percentage. The resulting mA step size will be based on the step size percentage of the **LOW** and **HIGH** value.




DWELL - time interval which can be set to wait at each set-point value before changing to the next value.

AUTO-REPEAT - the tickbox option which allows the automation cycle to be repeated indefinitely until manually stopped.

SCALING - refer to Section 6.3.6 on page 123 for a description of the use of Scaling.




When selected, the **Percent Step**  icon appears at the top right of the **CH2** window in the calibrator screen.

The **Percent Step** sequence can be done manually by using the **UP**  and **DOWN**  nudge buttons to increase and decrease the source values. It can also be automated by pressing the automation **Play**  softkey.





If selected in the configuration, the **Auto-repeat**  icon appears next to the **Percent Step** automation  icon. The automation cycle is automatically repeated until manually stopped. To stop the automation at any time, press the **Cancel**  softkey.

4. DEFINED STEP

The **DEFINED STEP** function allows incremental source values using a defined step size within the span limits. The **LOW**, **HIGH** and **STEP SIZE** value can be set as well as the option to auto-repeat the automation process.

<p>Step 1</p>		<p>From the Source Automation screen tap the DEFINED STEP radio button to show the Defined Step Automation menu. If you want to view or edit the DEFINED STEP automation settings, go to Step 2. Otherwise, select the Proceed  softkey to activate the automation option and return to the Calibrator screen.</p> <p>If required, select the Edit  softkey to change the selected automation settings.</p>
---------------	---	--

Chapter 6. Calibrator Tasks

Step 2		<p>Tap or select the parameter value to be changed. Enter the new value using the onscreen or Navigator keys. For a description of Scaling refer to Section 6.3.6 on page 123.</p>
Step 3		<p>The Calibrator screen will display the Defined Step  icon, and if the Auto-repeat  icon is available for use.</p>


LOW value - is the first current source value to be set using this option.


HIGH value - is the maximum current source value set-point using this option.

STEP SIZE value - is the magnitude of each step increment or decrement. When using this option, it is expressed as mA.

DWELL - time interval which can be set to pause or wait at each set-point value before changing to the next value.

AUTO-REPEAT - the tickbox option which allows the automation cycle to be repeated indefinitely until manually stopped.

When selected, the **Defined Step**  icon appears at the top right of the **CH2** window in the Calibrator screen.









The **Defined Step** sequence can be done manually by using the **UP** and **DOWN** nudge buttons to increment and decrement the source values. It can also be automated by pressing the automation **Play**  softkey.

If selected in the configuration, the **Auto-repeat**  icon appears next to the **Defined Step** automation  icon. The automation cycle is automatically repeated until manually stopped.

To stop the automation at any time, press the **Cancel**  softkey.

5. RAMP

The **RAMP** function allows the source value to be automatically incremented from a defined **START** value to a defined **END** value within a specified time period in both increasing and decreasing direction. The **TRAVEL** time can be set to define the period of time it takes the value to go from **START** to **END** (and vice versa).

Step 1		<p>From the Source Automation screen tap the RAMP radio button to show the Ramp Automation menu.</p> <p>If required, select the Edit  softkey to change the selected automation settings.</p> <p>Click the Proceed  icon to activate the option and return to the Calibrator screen.</p>
Step 2		<p>Tap or select the parameter value to be changed.</p> <p>Use the onscreen keypad to change the value.</p> <p>For a description of Scaling refer to Section 6.3.6 on page 123.</p> <p>Select the Tick icon  to set the new values.</p>
Step 3		<p>The Calibrator screen will display the Ramp  icon and the Auto-repeat  icon (if enabled).</p>

START value - is the first current source value to be set using this option.


END value - is the maximum current source value set-point using this option.


Chapter 6. Calibrator Tasks

TRAVEL - time required for the current source value to ramp from the **START** value to the **END** value. This automatically calculates the required step size to be used to achieve the travel time.

DWELL - time interval which can be set to pause or wait at the end of each direction or travel before changing to the opposite direction of travel.

AUTO-REPEAT - the tickbox option that allows the automation cycle to be repeated indefinitely until manually stopped.

When selected, the **Ramp**  icon appears at the top right of the **CH2** window in the **Calibrator** screen.

The Ramp sequence is not manual and hence the **UP** and **DOWN** nudge buttons are not usable with this option. It is automated by pressing the automation **Play**  softkey.

If selected in the configuration, the **Auto-repeat**  icon appears next to the **Ramp** automation  icon. The automation cycle is automatically repeated until manually stopped.

To stop the automation at any time, press the **Cancel**  softkey.

6.2.10 Voltage

	<p>For the DPI 610E instrument voltage is measured in Volts (V) or milliVolts (mV) and is a function of CH2 only. When the Voltage function is selected, the Direction is automatically set to Measure, as the Source option is not supported by the DPI 610E.</p> <p>The supported voltage range is -30 V to 30 V.</p> <p>When using the Voltage function, there is the additional option to use the internal 10 V (non-IS units only) or 24 V power supply provided by DPI 610E or to measurement of the voltage input from a source that is powered external to the unit.</p> <p>Terminal connections for measurement of voltage are shown in the diagram on the left.</p>
--	--


6.2.10.1 Voltage Measure - Configuration


Step 1		<p>From the Calibrator screen, select the channel 2 Setup screen (either press the screen icon or press the softkey.)</p>
Step 2		<p>Select FUNCTION from the CH2 Setup screen.</p>


Chapter 6. Calibrator Tasks


Step 3


CH2 Function		
FUNCTION	DIRECTION	LOOP
None	Measure	Off
Current		24V
Voltage		10V
Millivolts		
Pressure		
Barometer		
Observed		








04 MAY 2022 14:28 



Select **Voltage** > **Measure** then select one of the following:
Off for measurement without internal loop power supply OR
10 V for measure with internal 10 V loop power supply (only for non-IS units) OR
24 V for measure with internal 24 V loop power supply.


Select the Tick  icon to confirm the selection and configure the instrument.

Check that Voltage mode is active.

Select the **Back**  icon to show the **Calibration** screen.

Check that Voltage is shown in screen.




6.2.11 Millivolts Measure - Configuration



Voltage can also be measured in millivolts (mV) and is a function of **CH2** only. When the **Millivolts** function is selected, the **Direction** is automatically set to **Measure** as the **Source** option is not supported by the DPI 610E. The supported millivolts range is -2000 mV to 2000 mV. When using the **Millivolts** function, there is the additional option to use the internal 10 V (non-IS units only) or 24 V power supply provided by DPI 610E or to measure the millivolts input from a source that is powered external to the unit. Terminal connections for measurement of millivolts are shown in the diagram on the left.

Step 1		<p>From the Calibrator screen, select the Channel 2 CH2 Setup (either press the screen icon or press the softkey.)</p>
Step 2		<p>Select FUNCTION from the CH2 setup screen.</p>

Chapter 6. Calibrator Tasks

Step 3	 <p>CH2 Function 1/2</p> <table border="1"> <thead> <tr> <th>FUNCTION</th> <th>DIRECTION</th> <th>POWER</th> </tr> </thead> <tbody> <tr> <td>None</td> <td>Measure</td> <td>Off</td> </tr> <tr> <td>Current</td> <td></td> <td>24V</td> </tr> <tr> <td>Voltage</td> <td></td> <td>10V</td> </tr> <tr> <td>Millivolts</td> <td></td> <td></td> </tr> <tr> <td>Pressure</td> <td></td> <td></td> </tr> <tr> <td>Barometer</td> <td></td> <td></td> </tr> <tr> <td>Observed</td> <td></td> <td></td> </tr> </tbody> </table> <p>04 MAY 2022 14:28</p>	FUNCTION	DIRECTION	POWER	None	Measure	Off	Current		24V	Voltage		10V	Millivolts			Pressure			Barometer			Observed			<p>Select Millivolts > Measure then select one of the following: Off for measurement without internal loop power supply OR 10 V for measure with internal 10 V loop power supply (only for non-IS units) OR 24 V for measure with internal 24 V loop power supply.</p> <p>Select the Tick ✓ icon to confirm the selection and configure the instrument.</p>
	FUNCTION	DIRECTION	POWER																							
	None	Measure	Off																							
Current		24V																								
Voltage		10V																								
Millivolts																										
Pressure																										
Barometer																										
Observed																										
 <p>CH2 Setup</p> <p>> FUNCTION ← Millivolts</p> <p>PROCESS None</p> <p>UNITS mV</p> <p>RESOLUTION 6 Digits</p> <p>04 MAY 2022 14:28</p>	<p>Check that Voltage mode is selected.</p> <p>Select the Back ↶ icon to show the Calibrator screen.</p>																									
 <p>INT Pressure</p> <p>1.4712</p> <p>FS: 35.0000 Gauge bar</p> <p>← Millivolts</p> <p>5.0125</p> <p>FS: 2000.0000 mV</p> <p>04 MAY 2022 14:28</p>	<p>Check that Millivolts appears on the screen.</p>																									

6.2.12 HART



The DPI 610E can use the **HART** (Highway Addressable Remote Transducer) communication protocol and allows basic HART operation and configuration on HART supported devices. The HART bi-directional communications technology works as a master/slave protocol. When the DPI 610E connects to the HART device, the DPI 610E acts as the master and the HART device, the slave. The DPI 610E supports commonly used functions from the Universal and Common Practice commands specified in HART revision 5, 6 and 7. (See more about HART in Chapter 12 on page 230).

The HART function is only available on **CH2**. As it utilizes the current loop signal for its communication, the DPI 610E can provide 10 V/24 V loop power supply to the HART device if required.




The DPI 610E also offers an optional 250-ohm resistor that provides the voltage drop required for the HART communication when an external HART resistor is not available.

The HART resistor can be enabled (and disabled) from the **CH2 Setup** window.


To select the **HART** function:

<p>Step 1</p>		<p>From the Calibrator screen, select the channel 2 CH2 Setup icon (either tap the screen icon or press the softkey.)</p>
<p>Step 2</p>		<p>Select FUNCTION from the CH2 Setup screen.</p>

Step 3



Select **None** in the **FUNCTION** column and tap the page down softkey to view the second page of **CH2** functions. Tap **HART** on the second screen to view two more selection columns. Select the required options in the

columns and then select the Tick  icon to confirm the selection and configure the instrument.

The **CH2 Setup (HART)** configuration screen will appear. Make more selections on this screen or select the **Back** icon to show the **Calibration Main** screen.

For more details on how to set up the **HART** application and the **HART** device, see Chapter 12 on page 230.


To cancel the **HART** function, to enable the selection of another function, use the procedure given in Section 12.2 on page 234 to return to the **Configuration** screen.

6.3 Process Options

6.3.1 Tare



The Tare function is used to set the channel readings to a temporary zero. When Tare is active, the primary reading value is deducted from subsequent reading values until Tare is disabled. The initial reading will be approximately zero. The use of the Tare function therefore makes clear any difference in new measured values.

For example, if the reading from the internal pressure sensor is 21.4985 bar at the time Tare is enabled, the reading becomes approximately 0.000 as the value 21.4985 is captured and subtracted from true reading and the resulting value is then displayed. Whenever Tare is active,






the Tare symbol  will appear in the relevant channel window to indicate it is in operation.

Note: **Tare** is only available for **Measure** functions except for **Barometer** and **HART**.

To enable the Tare function:

Step 1		Select the desired channel.
Step 2		Select PROCESS .


Chapter 6. Calibrator Tasks

Step 3		<p>Select the TARE Checkbox. Tap on the Checkbox or use the Navigation Pad buttons to move to the TARE row and press the Pad's Enter button.</p> <p>Select the Back ↩ icon to go back to the Channel Setup screen.</p>
Step 4		<p>Check that the TARE  icon is in the CH Setup screen, to confirm that Tare is enabled.</p> <p>Select the Back ↩ icon.</p>
Step 5		<p>Check that the TARE  icon appears in the relevant channel window and the channel reading is zero or close to zero.</p>



INFORMATION When Tare is disabled, the primary reading returns to displaying the true measured value.



6.3.2 Min/Max/Mean

The **Min/Max/Mean** function provides the minimum, maximum and average of the primary reading from the time it is enabled. It is continuously updated as the reading values change and is displayed in addition to the live primary reading. When enabled, the **Min/Max/Mean** status  icon is displayed. The relevant channel will need to be expanded to view the additional information (refer to “Maximize and Minimize Channel Window” on page 65 for how to expand the window).









INFORMATION The Min/Max/Mean function is only applicable to Measure functions with the exception of HART.


To enable the **Min/Max/Mean** function:

Step 1		Select the desired channel.
Step 2		Select PROCESS .

Chapter 6. Calibrator Tasks

Step 3		<p>Select the MIN/MAX/MEAN Checkbox and then select the Back icon.</p>
Step 4		<p>Check that Min/Max/Mean is enabled in the Channel Setup screen. (The Min/Max/Mean  icon will appear as the PROCESS option).</p> <p>Select the Back  icon.</p>
Step 5		<p>Check that the Min/Max/Mean  icon appears on the relevant channel window.</p> <p>INFORMATION To view Min/Max/Mean information maximize the relevant channel window. See “Maximize and Minimize Channel Window” on page 65 for details.</p>

Step 6



Min/Max/Mean information appears in the maximized channel window.

Chapter 6. Calibrator Tasks

6.3.3 Filter



The **Filter** function allows a low pass band filter to be applied to the channel readings. The purpose of this filter is to achieve a more stable measurement reading over a noisy signal.










INFORMATION The Filter function can be applied on all functions except HART.

When the **Filter** process option is in enabled, the **Filter** status icon is displayed in the relevant channel.

To enable the **Filter** function:

<p>Step 1</p>		<p>Select the desired channel.</p>
<p>Step 2</p>		<p>Select PROCESS.</p>

Step 3		<p>Tap the FILTER Checkbox (put a tick mark in it) and then select the Back  icon.</p>
Step 4		<p>The FILTER  icon should appear in the PROCESS row, to show that FILTER is enabled in the Channel Setup menu (as the PROCESS Option.)</p> <p>Select the Back  icon to go back to the Calibration Main screen.</p>
Step 5		<p>Check that the FILTER  icon appears on the relevant channel window. (The FILTER icon will appear as the PROCESS option).</p>

Chapter 6. Calibrator Tasks

6.3.4 Flow



The **Flow** function enables the square root of the measured pressure value to appear as the primary reading.








INFORMATION The Flow process option is only supported by pressure functions i.e. Internal Pressure, External Pressure, Sum and Difference.

When enabled the **Flow** status icon  appears.

To enable the Flow function:

Step 1		Select the desired channel.
Step 2		Select PROCESS .

Step 3		<p>Tap the FLOW Checkbox (put a tick mark in it) and then select the Back icon.</p>
Step 4		<p>The FLOW  icon should appear in the PROCESS row, to show that FLOW is enabled in the Channel Setup menu (as the PROCESS Option.) Select the Back icon to go back to the Calibration Main screen.</p>
Step 5		<p>Check that the FLOW  icon appears in the relevant channel window.</p>

Chapter 6. Calibrator Tasks





6.3.5 Alarm



This process option provides a visual indication of when a user-set alarm limit is exceeded.









INFORMATION The user Alarm option is available with all Measure functions except for Barometer and HART.

To enable and configure the user Alarm option:

Step 1		Select the  or  icon as the desired channel.
Step 2		Select PROCESS .

Step 3	<div></div>	<p>Tap the ALARM area or use the Navigation Pad buttons to select it. The Alarm screen appears.</p>
Step 4	<div></div>	<p>Use the procedures given below to set the LOW and HIGH values for alarm activation.</p> <p>Use the Navigation button to move to the LOW option, press the Navigation Enter button to show an onscreen keypad. Use the keypad to enter the value for the lower end of normal range condition. Select the Tick softkey to confirm the value.</p> <p>Note: By default, the LOW (zero or negative full-scale) range value of the selected measure function is populated.</p> <p>Select the HIGH option and enter the value for the highest end of normal range condition. Select the Tick softkey to confirm the value.</p> <p>Note: by default, the HIGH (positive full-scale) range value of the selected measure function is populated.</p> <p>Use the Navigation Pad to select the ALARM row. Press the Enter button in the pad to insert a tick into its checkbox or tap in the checkbox. Press the Tick softkey to confirm the alarm settings and return to the PROCESS options screen.</p> <p>Note: To disable the Alarm, select the ALARM Checkbox to remove the Tick mark.</p>

Step 5	<div> </div>	<p>The values displayed in the ALARM row, switch between the LOW and HIGH values.</p> <p>Press the Back softkey to return to the Channel Setup screen.</p> <p>The ALARM  icon appears, to show that the PROCESS option is enabled.</p>
Step 6		<p>When the Alarm is enabled, the ALARM  icon appears in the relevant channel window.</p> <p>If the measured value falls outside the normal range condition, the alarm will be triggered.</p> <p>An alarm condition is indicated by both the ALARM  icon and the measured reading flashing within the relevant channel.</p> <p>When the measured value falls within the normal specified range condition, the icon and measured value will stop flashing.</p>

6.3.6 Scaling



This process option provides a method of configuring custom measurement units, by the use of the original units of the Functions. Scaling provides two pairs of values that define the linear relationship between the original measurement unit and the configured custom unit.



INFORMATION The Scaling option is available with all measure and source functions except for Observed and HART.

There are two methods to activate and configure the Scaling option.

6.3.6.1 First Scaling Method

<p>Step 1</p>		<p>Select the ^{CH1} or ^{CH2} icon for the desired channel.</p>
<p>Step 2</p>		<p>Select PROCESS.</p>






Chapter 6. Calibrator Tasks



Step 3	<div><div>CH2 Process</div><div><div>> TARE</div><div>MIN/MAX/MEAN</div><div>FILTER</div><div>ALARM</div><div>SCALING</div></div><div><div><input type="checkbox"/></div><div><input type="checkbox"/></div><div><input type="checkbox"/></div><div>Off</div><div>55.0 mA = 100.0 %</div></div></div> <div>04 MAY 2022 14:28 </div>
--------	--

↩

<p>Step 4</p>	<div data-bbox="311 573 825 1030"><p>CH2 Scaling</p><table><tr><td>> MEASURED VALUE 1</td><td>0.000mA</td></tr><tr><td>DISPLAYED VALUE 1</td><td>0.000%</td></tr><tr><td>MEASURED VALUE 2</td><td>24.000mA</td></tr><tr><td>DISPLAYED VALUE 2</td><td>100.000%</td></tr><tr><td>UNIT LABEL</td><td>%</td></tr></table><p>04 MAY 2022 14:28 </p></div> <div data-bbox="836 837 916 1016"> </div>	> MEASURED VALUE 1	0.000mA	DISPLAYED VALUE 1	0.000%	MEASURED VALUE 2	24.000mA	DISPLAYED VALUE 2	100.000%	UNIT LABEL	%	<p>Use the buttons on the Navigation Pad to move to the required row and press the Enter button to show a screen keypad. Tap or use the Navigation buttons (press the Enter button to enter each number) to select each keypad number. To confirm the complete number, press the Tick softkey.</p> <p>MEASURED VALUE 1: a minimum value within the measurement/source range of the selected function. By default, this is populated as the zero or negative full-scale value of the measurement/source function.</p> <p>DISPLAYED VALUE 1: a minimum value equivalent to the minimum measured value expressed as the custom unit. By default, the value populated is 0(%).</p> <p>MEASURED VALUE 2: a maximum value within the measurement/source range of the selected function. By default, this is populated as the positive full-scale value of the measurement/source function.</p> <p>DISPLAYED VALUE 2: a maximum value equivalent to the maximum measured value expressed as the custom unit. By default, the value populated is 100(%).</p> <p>UNIT LABEL: this is a free text field where the custom unit can be named. It is limited to a maximum of six characters. The default custom unit label is “%”.</p> <p>The custom label uses this relationship formula:</p> $Displayed\ value_x = \frac{Displayed\ Value_2 - Displayed\ Value_1}{Measured\ Value_2 - Measured\ Value_1} \times Measured\ Value_x$ <p>Note: The measured values are in the original units e.g. mA and displayed values are in the custom label units e.g. “%”.</p> <p>When the scaling parameters have been configured, select the Tick softkey to confirm the changes and return to the PROCESS screen. The updated Channel Scaling parameters appear in the Scaling fields.</p>
> MEASURED VALUE 1	0.000mA											
DISPLAYED VALUE 1	0.000%											
MEASURED VALUE 2	24.000mA											
DISPLAYED VALUE 2	100.000%											
UNIT LABEL	%											
<p>Step 5</p>	<p>Press the Back button in the Channel Process screen to show the Channel Setup screen.</p>											







Chapter 6. Calibrator Tasks

Step 6	 	<p>To enable or use the custom units: select UNITS to show the channel Units screen.</p> <p>Tap or select the Custom radio button. Select the Tick softkey to confirm the selection and return to the Channel Setup screen.</p>
Step 7		<p>The Scaling  icon will appear in the PROCESS field and the custom unit label will appear in the UNITS field.</p> <p>Select the Back  softkey to return to the Calibrator screen.</p>

<p>Step 8</p>		<p>The Scaling  icon will be in the relevant channel window and the UNITS field will show the configured custom label. In addition, the full-scale value will be expressed as its equivalent in the custom unit. Check that the minimum and maximum displayed values correspond with the minimum and maximum measured values.</p>
---------------	---	--

Chapter 6. Calibrator Tasks

6.3.6.2 Second Scaling Method

Step 1		Select the ^{CH1}  or ^{CH2}  icon for the desired Setup channel. Select the UNITS field in the channel Setup screen (Refer to steps 1 to 4 in Section 6.3.6.1).
Step 2		Select the Custom option.
Step 3		Select the Tool  softkey to view and/or change the Scaling parameters which configure the custom unit. For details on how to configure the parameters, see Section 6.3.6.1 for Method 1.

7. Utilities

Pressure functions provide utilities or tests, which are:

- Leak Test
- Switch Test
- TX Simulator
- Relief Valve Test.

The **Tasks** menu gives access to these utilities. Only pressure measure functions are supported with a utility function.

When the Leak Test, Switch Test and Relief Valve Tests are done, there is the option to save the test results in the DPI 610E. These result files are in the CSV format and can be viewed when transferred to a PC (See Section 5.3.1 on page 56). As a result, the Data logging application does not support these tests.


The Transmitter Simulation (TX SIM) utility is supported by Data logging.

7.1 Leak Test

Leak Testing is usually done to make sure that the pressurised equipment or system and its associated components do not leak. When a Device Under Test (DUT) is connected to the DPI 610E pressure test port either directly or using hoses and auxiliary connections, it is good practice to check for any possible leaks before commencing calibration or any other tests.



In a Leak Test, pressure (or vacuum) is applied to the system (typically not exceeding 10% of the sensor working pressure) and any change in this pressure is recorded over the duration of the test.


To configure and run a Leak Test:


Step 1		Tap on the Tasks icon on the Dashboard to select the menu.
--------	---	---

Step 2

Tasks	
P - I	> Leak Test
P - P	Switch Test
P - V	Tx Sim
I - P	Relief Valve
P-Display	




04 MAY 2022 14:28 


From the **Tasks** menu, select **Leak Test** from the Task list. Tap the **Leak Test** option again if using the touchscreen or press the Navigation pad **OK**  button to launch the **Leak Test** utility.

Note: If no compatible function is configured on **CH1**, the **Internal Pressure** function will be used automatically to run the Leak Test.

Step 3



On the Leak test screen, **CH1** will automatically be maximized to show the

relevant test details. The **Leak**  icon will appear below the Function name field. The **WAIT TIME** and **TEST TIME** are the two parameters for setting up the Leak test and these are in the channel window. They use the HH:MM:SS format.

To enter a value into either of the parameters, tap the **WAIT TIME** or **TEST TIME** text to show an onscreen keypad. Use this keypad to enter the required value.

WAIT TIME - Before starting a Leak test a period of time may be required to allow the pressurized system to settle before the actual test is started. This time is referred to as **WAIT TIME** on the DPI 610E and the default **WAIT TIME** is 1 minute (00:01:00). This time value can be changed to any value between 0 seconds (00:00:00) up to 60 minutes (01:00:00).

TEST TIME - This is the period over which the DPI 610E is testing for change in pressure i.e., leaks. The default **TEST TIME** is 1 minute (00:01:00) and this time value can be changed to any value between 1 second (00:00:01) and 480 minutes (08:00:00).

These time settings can be quickly accessed if using the touchscreen, by tapping the relevant fields on the channel window. Another way to access these settings is by pressing the **Tool**



















softkey.

The **Leak Test Setup** screen will provide the options for both the **WAIT TIME** and the **TEST TIME**. Press the **Back** softkey to return to the **Leak Test** screen.

Step 4

After the Leak Test times have been set, pressurize the system to the desired pressure using the DPI 610E pump.

<p>Step 5</p>	<div data-bbox="272 210 786 663"></div> <div data-bbox="799 461 876 539"></div> <div data-bbox="799 602 876 651"></div>	<p>Select the PLAY  softkey to begin the task. (This icon will change to a STOP  icon after selection).</p> <p>Note: the displayed WAIT TIME and TEST TIME settings will be cleared.</p> <p>Note: If a WAIT TIME has been set, a “Waiting” countdown begins from the WAIT TIME value down to zero. This potentially gives enough time for the pressure to stabilize.</p> <p>After the WAIT time has elapsed, the test begins. The Start pressure value is recorded on the screen at the start of the test. A “Testing” countdown begins from the TEST TIME value down to zero.</p>
	<div data-bbox="272 781 786 1234"></div> <div data-bbox="799 1032 876 1111"></div> <div data-bbox="799 1173 876 1223"></div>	<p>When the TEST TIME has elapsed, the End pressure value is also recorded and the Leak Rate per minute is calculated and appears as the Leak Rate test result.</p>

Step 6			<p>If required, the test result can be saved by selecting the Save  softkey before exiting the test screen. A keypad appears on the screen. Use this keypad if you want to enter a new name for the results file.</p>
			
			<p>The default result filename will be the DPI 610E date and time stamp. Select the Tick softkey to confirm a different filename and complete the save process.</p>
			
			

Note: Section 9.6.2, “How to use a PC to view Data Log files in the DPI 610E,” on page 168. Result files are stored within the internal memory of the DPI 610E. (See Chapter 14, “Files System,” on page 290.) Only the list of test result files can be viewed on the device. Details of the files can only be accessed when the files are opened on a PC.

7.2 Switch Test

The DPI 610E can test pressure switches or pressure devices with switch contacts.



Pressure switches open or close an electrical circuit when a configured setpoint pressure level is reached and/or exceeded.





Pressure switches commonly have two types of contact which are: normally open or normally closed. When a pressure switch is normally open, it means that the state of the switch contacts, when pressurised within normal operating limits, is Open. When the pre-set setpoint pressure is reached, the micro-switch is triggered (Actuation) and the contacts change state from open to closed. When the pressure returns within normal operating limits, the switch contacts are reset (De-actuation) i.e., change back to the normal open state.



For a normally closed switch the reverse is the case. At the switch point (Actuation), the state changes from Closed to Open and at the reset point (De-actuation), it returns to the closed state.

The difference between the switch point and reset point is called Hysteresis.

To configure and do a Switch test:

Step 1		Tap on the Tasks icon on the Dashboard to select the menu.
Step 2		Tap the Switch Test two times if using the touchscreen or press the OK button to launch the utility.

Step 2 Cont'd		<p>The Calibrator screen will be configured with the Switch Test data. The Pressure related function is configured on CH1 while the Switch Test data are in the CH2 window.</p> <p>Note: if no compatible function is configured on CH1, the Internal Pressure function will be used automatically to run the Switch Test.</p>
Step 3	Open the DPI 610E pressure line by loosening the pressure release knob. Check that the pressure indicates a value around zero if using a gauge sensor or around 1 bar if using an absolute sensor.	
Step 4	Connect the pressure switch or device to the test port securely.	
Step 5	<p>Connect test leads from the pressure switch contacts to the \pm mA/Vin ports on the DPI 610E as shown in the connection diagram below.</p> 	
Step 6	<p>Select the PLAY  softkey to begin the Switch Test. (This icon will change to a STOP  icon after selection). At this point the normal state is detected i.e. If open, it is identified as Normally open (NO) in the test window. Vice versa, if a closed circuit is detected, the switch will be identified as Normally closed (NC) for the duration of the test.</p>	



Step 7	Close the pressure line by fully closing the pressure release knob. Check there are no leaks.
Step 8	<div data-bbox="272 259 877 719"> </div> <div data-bbox="272 1070 877 1529"> </div> <p>Slowly start to pressurize the system. If the trip or actuation point is known and it is safe to do so, the pump may be used to quickly ramp up the pressure close to the setpoint and then the volume adjuster can be used to slowly increase the pressure closer to the setpoint.</p> <p>Once the switch is actuated, the actuation pressure is recorded in the switch test channel window. The state icon for the actuation is also displayed i.e. icon of a switch open or a switch closed.</p> <p>Increase the pressure a little more and allow to settle.</p> <p>Gradually start to reduce the pressure using the volume adjuster. At the switch reset (De-actuation) point, the pressure is recorded and the switch state icon at this point is displayed.</p> <p>The test is concluded with the Hysteresis value calculated and displayed. This completes the switch test cycle.</p> <p>If required, the test result can be saved by selecting the Save  softkey before exiting the test screen.</p> <p>A keypad appears on the screen. Use this keypad if you want to enter a new name for the results file.</p> <p>If the results are saved, the test details will be cleared, and the test will be restarted.</p> <p>If the results are not saved, a new switch test cycle can be set up ready to be run. To do this, carefully vent the system (open the pressure release knob) and then select the Restart  softkey.</p>






Note: Result files are stored within the internal memory of the DPI 610E. See Chapter 14 (File System). Only the list of test result files can be viewed on the device. Details of the files can only be accessed when the files are opened on a PC (See Section 9.6.2, “How to use a PC to view Data Log files in the DPI 610E,” on page 168).

7.3 TX (Transmitter Simulation) Simulator

The DPI 610E provides a current output (current source) which is proportional to the pressure measured and indicated by the DPI 610E. This utility is normally used by the DPI 610E to simulate a pressure transmitter and it configured by specifying the transfer function parameters of the current output transmitter to be simulated.





To configure and run the Transmitter Simulation mode:

Step 1		Tap on the Tasks icon on the Dashboard to select the menu.
Step 2		From the Tasks menu, select Tx Sim from the Task list. Tap the Tx Sim option again if using the touchscreen or press the Navigation pad OK button to start the utility.







Step 3		<p>The Calibrator screen will be configured with the transmitter simulation details. CH1 will be configured with the internal pressure function while CH2 will be configured with Current source in simulation mode. The TX Sim  icon will be displayed within the CH2 window under the Function name field.</p> <p>Note: In TX Sim mode, the current output is automatically determined, and source based on the transfer function characteristic configured.</p>
Step 4		<p>To configure the simulated transmitter: Tap in the CH2 area to maximize the CH2 window and select the Tool  softkey.</p> <p>Select and edit the START and END values of the Input channel i.e., the Pressure channel. Default values are the zero (or Negative full-scale) and the Positive full-scale of the internal pressure sensor respectively.</p> <p>Select and edit the Start and End values of the OUTPUT channel i.e., the current source channel. Default values are 0 and 24 mA.</p> <p>There is also the option for the DPI 610E to provide power i.e., 10V or 24V. The default setting is Off (no power provided by the DPI 610E).</p> <p>Press the Back  softkey.</p>

7.4 Relief Valve Test

This mode is used when testing vacuum relief valves, which open to prevent an excessive internal vacuum pressure and close when the system returns to normal operating pressure conditions. Relief Valve Test result files are stored within the internal memory of the DPI 610E. See Chapter 14 (File System). Only the list of test result files can be viewed on the device. Details of the files can only be accessed when the files are opened on a PC (See Section 9.6.2, “How to use a PC to view Data Log files in the DPI 610E,” on page 168). To configure and run a Relief Valve test:

Step 1		Tap on the Tasks icon on the Dashboard to select the menu.
Step 2		From the Tasks menu, select Relief Valve from the Task list. Tap the Relief Valve option again if using the touchscreen or press the Navigation pad OK button to launch the utility.
Step 3		The Calibrator screen will be configured with the Relief Valve Test details. The CH1 window will automatically become larger to display the test details. Note: the default Relief Valve mode is Rising. To change the Relief Valve type, select the Tool  softkey and select the required type. Select the Tick softkey to confirm and return to the Calibrator screen. The relevant Relief Valve type icon will be displayed in the channel window under the Function name field.
Step 4	Vent the pressure on the DPI 610E by opening the pressure release knob fully.	

Chapter 7. Utilities

Step 5	Connect the Device Under Test (DUT) securely to the pressure test port of the DPI 610E. Refer to “Attach Device Under Test” on page 28 for instructions.	
Step 6	Seal the pressure system by closing the pressure release valve securely. For location of this valve refer to “Parts” on page 19.	
Step 7	<p>Select the PLAY  softkey to start the Relief Valve test. The display will start to show the Opening and Closing values.</p> <p>If in Rising Relief Valve mode, the Opening pressure is continually updated as the maximum pressure detected once the test has started. The closing pressure is continually updated as the minimum pressure detected each time a new maximum pressure is recorded.</p> <p>If in Falling Relief Valve mode, the reverse is the case i.e., the Opening pressure is continually updated as the minimum pressure detected once the test has started. The Closing pressure is continually updated as the maximum pressure detected each time a new minimum pressure is recorded.</p> <p>Assuming the Rising Relief Valve mode is used, gradually increase the pressure using the pump or the volume adjuster towards the Relief valve setpoint or blow down pressure. Around the setpoint mark, observe the pressure reading when it stops increasing with any further generated pressure. The Opening pressure value should not increase any further and will remain unchanged. This is recorded as the final opening pressure. Stop generating pressure at this stage and allow the pressure to settle. When the pressure settles below the setpoint mark, the valve will close, and the pressure reading will settle at minimum value which is recorded as the final closing pressure.</p>	
Step 8		<p>When the Open and Close pressures are stable, select the Stop  icon softkey to end the test.</p> <p>The results of the Relief Valve test can be saved by selecting the Save  softkey.</p>
Step 9		<p>The default result file name will be the DPI 610E current date and time stamp. This can be renamed if required. Select the Tick softkey to confirm the Result file name and complete the save operation.</p> <p>If the results are saved, the test details will be cleared, and the test will be restarted.</p> <p>If the results are not saved, a new test cycle can be set up ready to be run. To do this, carefully vent the system (open the pressure release knob) and then select the Restart  softkey.</p>

8. External Sensors

8.1 PM700E

8.1.1 Overview

The PM700E external remote sensors extend the pressure measurement capability of a DPI 610E unit. These sensors provide pressure measuring capability from 25 mbar up to 1400 bar, with ranges available in absolute, gauge and differential models. PM700E sensors are available for both commercial and hazardous area environments. Any number of remote sensors can be individually used with a single DPI 610E, because all sensors hold their own calibration data.



PM700E (Gauge, Absolute)



PM700E (Differential)

8.1.2 Media Compatibility

Care must be taken to observe media compatibility when using the PM700E. Sensor variants up to and including 3.5 bar, have exposed diaphragms, while 7 to 1400 bar variants are diaphragm isolated.

Table 8-1: Pressure and Media Compatibilities


Pressure FS	Media Compatibility
0 to 3.5 bar	Non-condensing dry gases with 316L Stainless Steel, Pyrex, Silicon, Gold, Aluminium, Glass, Silicon Dioxide and RTV Adhesive
Differential sensor reference port	Non-condensing dry gases with 316L and 304 Stainless Steel, Pyrex, Silicon, Glass, Silicon Dioxide and RTV Adhesive
7 to 200 bar	316L Stainless Steel and Hastelloy C276
350 to 1400 bar	Inconel 625 and 17-4PH Stainless Steel


Chapter 8. External Sensors

8.1.3 Setup

Each PM700E sensor is supplied with a 2.9m (9.5 feet) PM700E-CABLE. This cable is for connection of the sensor to the “EXT SENSOR” port on the side of the DPI 610E. Align the pin/slot arrangement at the female end of the cable connector with the male connector end of the sensor. The cable connector should push in with little force when it is correctly aligned. Proceed to complete the connection by rotating the locking collar until hand tight. Similarly, align the male end of the cable to the port on the DPI 610E and tighten in the same way.



The DPI 610E automatically detects any connection to a PM700E sensor. Upon successful connection of a recognised and supported sensor, a “Connected” status indication will appear for a few seconds in the status bar. Also, the screen will show an **External Sensor** icon  until the sensor is disconnected (see bottom left of screen image below). When the sensor is disconnected, a “Disconnected” status indication appears for a few seconds in the status bar and then the external sensor icon disappears.



8.1.4 The Zero Function

Note: It is recommended that all gauge sensors are zeroed at the beginning of each day before use.



INFORMATION The Zero function is only available on gauge sensors. It is not possible to apply total vacuum to absolute sensors, because they can only measure atmospheric pressure. Refer to “The Zero Function” on page 76 for more information about the use of this function.

8.1.5 Available External Pressure Sensors

Only the external pressure sensors in Table 8-2 are compatible with the DPI 610E type of instrument.




Table 8-2: External Pressure Sensors for DPI 610E Range

Pressure Range	Gauge	Absolute	Differential	Barometric
25 mbar / 10 in H ₂ O / 2.5 kPa	008G	-	008L	-
70 mbar / 1 psi / 7 kPa	01G	-	01L	-
200 m bar / 3 psi / 20 kPa	02G	-	02L	-
350 m bar / 5 psi / 35 kPa	03G	03A	03L	-
700 m bar / 10 psi / 70 kPa	04G	04A	04L	-
1 bar / 15 psi / 100 kPa	05G	05A	05L	-
750 - 1150 m bar / 11 - 17 psi / 75 - 115 kPa (Barometric)	-	-	-	05B
2 bar / 30 psi / 200 kPa	07G	07A	07L	-
3.5 bar / 50 psi / 350 kPa	08G	08A	-	-
7 bar / 100 psi / 700 kPa	10G	10A	-	-
10 bar / 150 psi / 1000 kPa	11G	11A	-	-
20 bar / 300 psi / 20 MPa	13G	13A	-	-
35 bar / 500 psi / 2 MPa	14G	14A	-	-
70 bar / 1000 psi / 7 MPa	16G	16A	-	-
100 bar / 1500 psi / 10 MPa	165G	165A	-	-
135 bar / 2000 psi / 13.5 MPa	17G	17A	-	-
200 bar / 3000 psi / 20 MPa	18G	18A	-	-
350 bar / 5000 psi / 35 MPa	-	20A	-	-
700 bar / 10 000 psi / 70 MPa	-	22A	-	-
1000 bar / 15 000 psi / 100 MPa	-	23A	-	-
1400 bar / 20 000 psi / 140 MPa	-	24A	-	-

Chapter 8. External Sensors

8.1.6 Configuration of an External Pressure Sensor

To configure a channel with the external remote pressure reading:

Step 1		Select the desired channel (channel 1 in this example).																								
Step 2		Select FUNCTION from the Channel Setup screen.																								
Step 3	 <table border="1"><thead><tr><th>FUNCTION</th><th>SENSOR</th><th>RANGE</th></tr></thead><tbody><tr><td>None</td><td>INT</td><td>Normal</td></tr><tr><td>Pressure</td><td>EXT</td><td>Pseudo</td></tr><tr><td>Sum</td><td></td><td></td></tr><tr><td>Difference</td><td></td><td></td></tr><tr><td>Barometer</td><td></td><td></td></tr><tr><td>Observed</td><td></td><td></td></tr><tr><td>RTD</td><td></td><td></td></tr></tbody></table>	FUNCTION	SENSOR	RANGE	None	INT	Normal	Pressure	EXT	Pseudo	Sum			Difference			Barometer			Observed			RTD			<p>Select Pressure > EXT > Normal or Pseudo.</p> <p>Select the Tick icon to confirm the selections and show the Channel Setup screen.</p> <p>Refer to “Normal and Pseudo Pressure Range” on page 78 for more information about the use of Normal and Pseudo sensor values.</p>
FUNCTION	SENSOR	RANGE																								
None	INT	Normal																								
Pressure	EXT	Pseudo																								
Sum																										
Difference																										
Barometer																										
Observed																										
RTD																										

The **EXT**ernal pressure function is similar to that of the **INT**ernal pressure function because it supports all the Calibrator task features associated with that of the internal pressure e.g., sensor zero, pseudo-range, leak test, switch test, relief valve etc.


If a channel is configured with the **External Pressure** function without a sensor connected, the primary reading in that channel window will be appear as “- - - -”.

If the external sensor is disconnected while the function is in use an error message may appear.

PM 700E External Remote sensors with DK481 firmware version 2.00.00 and above are fully supported for use with the DPI 610E. Sensor validation is done each time a connection is detected.


If a channel is configured for External Pressure and an unsupported sensor is detected (for example a PM 700E sensor with firmware older than 2.00.00), a warning message appears


stating the sensor is not supported and the status bar will have the sensor icon  in it.



The readings from the sensor will appear as normal when configured on the Calibrator screen however, sensor calibration will not be supported using the DPI 610E. All PM700E sensors etched with a part number ending in “-3” have the correct firmware installed.


If a channel is configured for External Pressure and an unrecognised sensor is detected, a warning message appears stating the connected sensor is not compatible and the sensor icon

 will appear in the status bar.




Chapter 8. External Sensors

Each time a PM 700E sensor is connected or when the DPI 610E is powered on with the sensor connected, the calibration status is checked. If the days remaining from the current DPI 610E system date to the calibration-due date of the sensor is less than 30 days, an on-screen message appears, to inform the user.



If the days remaining is 0 or less, an on-screen message appears, stating calibration is due when the sensor is detected either at power up or when the DPI 610E is already in operation. In addition, a message text "CAL DUE" will permanently be on the status bar until the sensor is disconnected or the sensor has been calibrated.



8.2 RTD Probe and Interface

8.2.1 Overview

The DPI 610E can be configured to display readings from the RTD-INTERFACE, which is a remote adapter interface and the RTD-PROBE (or any other compatible probe). Temperature measurements can be displayed as resistance or temperature units. The RTD-PROBE and RTD-INTERFACE are available in both safe and hazardous area models. The RTD-PROBE is fitted with a 15 cm (6") class-A PT100 probe. The model names are as follows:

Table 8-3: RTD- Model Names

	Safe Area	Hazardous
RTD Interface	RTD-INTERFACE-485	RTD-INTERFACE-IS
RTD Interface with probe	RTD-PROBE-485	RTD-PROBE-IS

The RTD-PROBE/RTD-INTERFACE connects to the DPI 610E with the supplied 2.9m (9.5 feet) cable. The RTD-INTERFACE is supplied with a field-rewireable M12 connector to allow for connection by User 2,3 or 4-wire RTDs.



8.2.2 Temperature Considerations

Careful consideration must be taken when using the RTD-INTERFACE and the RTD-PROBE, or any specialist RTD probes, that the environment and process temperatures do not exceed the specified limits for each RT component as detailed in the table below.

Table 8-4: RTD-Temperature Specifications


		RTD Sensor Type	Temperature Range
Measuring temperatures		IO-RTD-PRB150	-5°C to 200°C (when used with appropriate extension cable)
		RTD-INTERFACE (BODY)	-10°C TO 50°C
		RTD-PROBE	-10°C TO 50°C when directly plugged in to RTD-INTERFACE
			-10°C TO 50°C when using supplied cable
		SPECIALIST RTD PROBE (Not supplied by Druck)	The capability of the RTD-INTERFACE (resistance range) with a suitable extension cable and suitable probe is 0 to 400Ω which equates to -250°C to +650°C for a PT100 probe.

Chapter 8. External Sensors

8.2.3 Setup

Connect the RTD-PROBE to the RTD-INTERFACE by screwing the probe end into the connection on the RTD-INTERFACE, if a direct connection is required. The 2 m (6.6 feet) M12 extension cable (IO-RTD-M12EXT) can be used to extend the connection between the RTD-INTERFACE and the RTD-PROBE. If using a compatible RTD not supplied by Druck, use the M12 field wireable connector (IO-RTD-M12CON) to connect the RTD probe to the RTD-INTERFACE.


Note: The pin numbering is printed on the rear of the connector body.




RTD M12 Connector Pinout

With the supplied RS485 sensor cable, align the pin/slot arrangement at the female end of the cable connector with the male connector end of the sensor. The cable connector should push in slightly with little force when it is correctly aligned. Proceed to complete the connection by rotating the swivel connector fully until hand tight. Similarly, align the male end of the cable to the port on the DPI 610E and tighten in the same way.






The DPI 610E automatically detects any connection to the RTD-INTERFACE. Upon successful connection of a recognised and supported sensor, a “Connected” status indication appears for a few seconds in the status bar. Also, the external sensor icon  will be permanently displayed until the sensor is disconnected. When the sensor is disconnected, a “Disconnected” status indication appear for a few seconds in the status bar and the external sensor icon will disappear.



If a channel is configured with a RTD function without a sensor connected, the primary reading in that channel window will be displayed as “- - - -”. If the external sensor is disconnected while the function is in use an error message may appear. The full-scale value of the RTD probe is displayed as well as the RTD probe type.



Chapter 8. External Sensors

8.2.4 Configuration of a channel for a RTD sensor

Step 1		Select the desired channel (channel 1 in this example).
Step 2		Select FUNCTION from the Channel Setup screen.
Step 3		Select RTD and select the Tick icon to confirm the selections and show the Channel Setup screen.


Step 4		To configure the RTD measurement as resistance or temperature, select the RTD Mode option from the CH Setup screen and press the Enter key in the Navigation Pad.
Step 5		Tap in the radio button for Resistance or Temperature. Select the Tick icon to confirm the selected RTD MODE and to go back to the channel Setup screen. The RTD Profile can now be selected if necessary.

Chapter 8. External Sensors


8.2.5 RTD Profiles

The full-scale value of the RTD probe is displayed as well as the RTD probe type. When the RTD function is selected, the desired RTD profile might need to be configured by:

- Tapping on the currently saved RTD profile field in the **Channel Setup** screen.





- Using the keypad to move the selector icon to the **RTD Profile** row and pressing the **ENTER** button to show a list of the available profiles.



The default profile set is the “Default EU” option or PT100-PA-392, which is based on the European standard (DIN/IEC 60751) for Class A Platinum RTDs. There is also a “Default US” or PT100-PD-385, which is based on the American standard. The Default EU and Default US profile options are pre-defined and cannot be edited or deleted.

However, up to eight Custom profiles can be created by populating the user profile files available with the required coefficients, temperature range and label.

Tap on the desired profile to select it. Tap on the **View**  icon softkey to view or/and edit the coefficients and parameters within the profile. Alternatively, use the **UP/DOWN** Navigation Pad buttons to select the required profile and press the **View** softkey to view or/and edit the coefficients and parameters within the profile.



To edit any of the parameters:

- Tap on the value field of the desired parameter:
 - Use the **UP/DOWN** buttons to move the selector icon to the required parameter to change. Press the **Enter** button to enter the edit screen of the parameter. Press or tap the **Tick** icon softkey to accept and save the new values.

It is possible to copy the parameters saved in any of the profiles to a custom profile. Note the Default EU and Default US profiles cannot be overwritten but can be copied into any of the custom profiles. Custom profiles are saved in the RTD-INTERFACE not on the DPI 610E.


Table 8-5: RTD Profile parameters


Parameter	Description
Identifier	Give the custom profile a unique label
RTD Type	Select from 2, 3, 4 wire RTD configuration. 4-wire is default.
Coefficient Format	Select from Callendar-Van Dusen equation formats or use the ITS90 equation format.
Coefficient R0	Resistance at 0°C
Coefficient 1 (a, A, Alpha)	First coefficient value
Coefficient 2 (b, B, Beta)	Second coefficient value
Coefficient 3 (c, C, Delta)	Third coefficient value
Min. Temperature	Minimum temperature
Max. Temperature	Maximum temperature


When all parameter fields are filled, use the **Back** softkey to go back to the **RTD Profile** screen.

8.2.5.1 To copy a RTD profile

Select the desired profile:



Once selected, tap, or press the **Copy**  icon softkey and then select the desired destination profile, for example: Profile 1.



8.2.5.2 RTD Units


When in Resistance mode, the only units available to select are Ohms (Ω) and Custom units. In Temperature mode, select from $^{\circ}\text{C}$, $^{\circ}\text{F}$ or Custom units. Refer to Section 6.3.6 on page 123 for information about Custom units.

9. Data Log

The **Data Log** function records instrument readings (measured or sourced) so that they can be reviewed or analyzed. The following options are available under the **Data Log** menu:

Option	Description
Setup	Set up data log
Files	View and delete data log files

To access Data Log:



9.1 Data Log Setup Menu

The following options are available under the **Setup** menu:

Option	Description
FILENAME	Change file name
TRIGGER	Set Data Log trigger
TIME INTERVAL	Set Data Log time interval
LOG DURATION	Set Log duration
DATA POINTS	Set Data Log points










Note: Select the **TRIGGER** mode first (See Section 9.2, “TRIGGER Menu,” on page 158) before setting the filename of the data log.



TIME INTERVAL, **LOG DURATION** and **DATA POINTS** are only listed in the **Data Log Setup** menu when **TRIGGER** is set to **PERIODIC** (See Section 9.2 on page 158).

Chapter 9. Data Log

9.1.1 How to set the Data Log Filename

To set the Data Log filename:

Step 1	 	Select SETUP from the Data Log screen.
Step 2	  	Select FILENAME from the Data Log Setup screen. Note: TIME INTERVAL , LOG DURATION and DATA POINTS are only listed on the Data Log Setup screen when TRIGGER is set to periodic.
Step 3	   	Select the Eraser to delete the default data log file name. Note: The default data log file name format is: [YYYY-MMM-DD_HH-MM-SS].

Step 4		<p>Use the keypad to enter the new Data Log filename.</p> <p>Note: Only a maximum of 20 characters and symbols is available.</p> <p>Select ✓ to confirm the new file name.</p>
Step 5		<p>Check that the new filename appears in the Data Log Setup screen.</p> <p>Note: TIME INTERVAL, LOG DURATION and DATA POINTS are only listed on the Data Log Setup screen when TRIGGER is set to Periodic.</p>

9.2 TRIGGER Menu

The **TRIGGER** menu allows the user to select the type **Data Log Trigger** requirement. The following options are available under the **TRIGGER** menu:

Option	Description
KEY PRESS	Data Log triggered by a key press
PERIODIC	Periodic Data Log




Figure 9-1: Data Log Trigger Menu

When **KEY PRESS** is selected, no more settings will be required to set up the data log. Click the **Tick ✓** icon to return to the **Data Log Setup** screen: select **FILENAME** if a new name for the data log file is needed (See Section 9.1.1 on page 156 for the procedure). Refer to Section 9.4 on page 164, to continue the instructions for **KEY PRESS** data logging.

When the **PERIODIC** trigger is selected, more recording options become available for configuration.

9.3 Periodic Trigger Options


The options **TIME INTERVAL**, **LOG DURATION** and **DATA POINTS** are only available for use when **PERIODIC** is the trigger mode for recording data results.



9.3.1 TIME INTERVAL

When a Periodic trigger is selected, the option to set the Periodic interval is available from the **Data Log Setup** screen. The interval determines how long each data point is logged and it is expressed as HH:MM:SS.S. The supported time interval range is between 00:00:00.2 to 23:59:59.9. The minimum interval supported is dependent on the functions configured in the Calibrator channels. See table below.

Function	Minimum Interval (HH:MM:SS.S)
Internal Barometer	00:00:05.0
Internal Pressure	00:00:00.2
External Sensor (Pressure and RTD)	00:00:00.2
Current / Voltage / Millivolt Measure	00:00:00.5
Current Source	00:00:01.0
HART	00:00:00.5

9.3.1.1 How to set the TIME INTERVAL

Step 1		Select TIME INTERVAL from the Data Log Setup screen.
--------	---	--



Step 2		<p>Use the keypad to set the LOG INTERVAL. Select ✓ to confirm.</p> <p>Note: The time interval must be entered in the [HH:MM:SS.S] format in the range [00:00:01] to [23.59.9].</p>
Step 3		<p>Check that required interval appears in the TIME INTERVAL row of the Data Log Setup screen.</p>


9.3.2 LOG DURATION

When a Periodic trigger is selected, the option to set the Data Log Duration is available from the **Data Log Setup** screen. The log duration determines the period over which the logging will take place i.e., start to end. It is expressed as HH:MM:SS. The supported time interval range is between 00:00:01 to 999:59:59.

Note: The time interval value must always be less than the **LOG DURATION** value.

9.3.2.1 How to set the LOG DURATION


Step 1		<p>Select LOG DURATION from the Data Log Setup screen.</p>
Step 2		<p>Use the onscreen keypad to set the LOG DURATION value.</p> <p>Select ✓ to confirm.</p> <p>Note: The time interval must be entered in the [HHH:MM:SS] format in the range [000:00:01] to [999:59:59].</p>



Step 3		Check that required duration appears in the LOG DURATION section of the Data Log Setup screen.
--------	---	--

9.3.3 DATA POINTS

When a Periodic trigger is selected, the **Data Log Setup** screen shows the number of configured data points. The number of data points is directly linked to the time interval and the log duration configured. For example, if a time interval of 10 seconds (00:00:10.0) and log duration of 1 minute (000:01:00) is configured, the number of data points displayed in the setup menu will be 6. Each time the time interval or log duration value is changed, the number of data points is automatically adjusted. Alternatively, the periodic data log can be configured by specifying the number of data points required and the time interval or sampling frequency. From the previous example, if the number of data points is changed from 6 to 5, the log duration will automatically adjust to 50 seconds (000:00:50) based on the unchanged time interval of 10 seconds and the new number of required data points.









9.3.3.1 How to set the DATA POINTS





Step 1		Select DATA POINTS from the Data Log Setup screen
--------	---	---

Step 2		<p>Use the keypad to set the number of data points.</p> <p>Select ✓ to confirm.</p>
Step 3		<p>Check that required number of data points appears in the DATA POINTS field of the Data Log Setup screen.</p>

9.4 Setting up Manual Data Logging







The **KEY PRESS** option (see Section 9.2 on page 158) is a manual data trigger. Use the following steps to continue with a **KEY PRESS** triggered Data Log session:

Step 1		<p>Select the Proceed  icon in the Data Log Setup screen.</p>
Step 2		<p>The Calibration main screen appears.</p> <p>Press the KEY PRESS RECORD  icon to start the data logging session.</p>
Step 3		<p>The Data Log Status  icon will appear in the status bar until the logging is complete.</p> <p>Press the Start Logging Data  icon to log data when wanted.</p> <p>To temporarily stop the testing press the Hold  icon. To restart the testing press the Hold icon again.</p>

Step 4		<p>To stop data logging completely press the Stop  icon.</p>
Step 5		<p>A popup message appears that requests confirmation that the data log session is to end. Select OK to end the session or CANCEL to continue. If you select OK, another popup message will appear to confirm the data log file has been saved.</p>
		<p>It is not possible to change the channel configuration once data logging has begun. If at any point during data logging, the user selects the Dashboard, some applications that may interfere with the logging, will be disabled. Such applications will have a slash across the icon on the Dashboard.</p>

9.5 Setting up Periodic Data Logging




The **PERIODIC** option is a time-based data trigger (see Section 9 on page 155, Section 9.2 on page 158 and Section 9.3 on page 159). Use the following steps to continue with a **PERIODIC** triggered Data Log session:

Step 1		<p>After selecting the PERIODIC Data Log mode and the values of the PERIODIC options, select the Proceed  icon in the Data Log Setup screen. The Calibrator main screen appears.</p>
Step 2		<p>To start the periodic logging, select the Periodic Data Log  softkey. This is similar to the icon for the Key Press Data Log icon except it has a clock in its center rather than an addition sign.</p> <p>At this point, the Data Log Status  icon appears in the status bar until the logging is complete. Periodic logging is automatic, based on the configurations in the Setup menu. At the end of the session, a popup message appears, to confirm that data logging is complete. The file is saved automatically.</p>
		<p>It is not possible to change the channel configuration once data logging has begun. If at any point during data logging, the user selects the Dashboard, some applications that may interfere with the logging, will be disabled. Such applications will have a slash across the icon on the Dashboard.</p>

9.6 Viewing & Deleting Data Log files

9.6.1 Viewing Data Log Files

To view the **Data Log** files:

Step 1		Select FILES in the Data Log screen.																								
Step 2	 <table border="1"> <thead> <tr> <th>FILENAME</th><th>CH1</th><th>CH2</th></tr> </thead> <tbody> <tr> <td>> 2020-JAN-04_20-59-00</td><td>PInt</td><td>mA</td></tr> <tr> <td>2020-JAN-04_20-59-01</td><td>PInt</td><td>mA</td></tr> <tr> <td>2020-JAN-04_20-59-02</td><td>PInt</td><td>mA</td></tr> <tr> <td>2020-JAN-04_20-59-03</td><td>PInt</td><td>mA</td></tr> <tr> <td>2020-JAN-04_20-59-04</td><td>PInt</td><td>mA</td></tr> <tr> <td>2020-JAN-04_20-59-05</td><td>PInt</td><td>mA</td></tr> <tr> <td>2020-JAN-04_20-59-06</td><td>PInt</td><td>mA</td></tr> </tbody> </table>	FILENAME	CH1	CH2	> 2020-JAN-04_20-59-00	PInt	mA	2020-JAN-04_20-59-01	PInt	mA	2020-JAN-04_20-59-02	PInt	mA	2020-JAN-04_20-59-03	PInt	mA	2020-JAN-04_20-59-04	PInt	mA	2020-JAN-04_20-59-05	PInt	mA	2020-JAN-04_20-59-06	PInt	mA	Tap on (or use the Navigation Pad) to select the required Data Log file.
FILENAME	CH1	CH2																								
> 2020-JAN-04_20-59-00	PInt	mA																								
2020-JAN-04_20-59-01	PInt	mA																								
2020-JAN-04_20-59-02	PInt	mA																								
2020-JAN-04_20-59-03	PInt	mA																								
2020-JAN-04_20-59-04	PInt	mA																								
2020-JAN-04_20-59-05	PInt	mA																								
2020-JAN-04_20-59-06	PInt	mA																								
Step 3		Select the Clipboard icon on the Data Log File Summary .																								

Chapter 9. Data Log

Step 4

File 2022-JAN-04_20-59-00 001-010/010
CH0 Function=Plnt Neg PS=0.00000 Pos PS=200000 Unit=bar
SensorType=Abs Flow=0 MaxMinAvg=0 Filter=0 Tare=0
CH1 Function= mA Neg PS=-550000 Pos PS=550000 Unit= mA


#	Time	Plnt	mA	None	None
1	22:03:00	1.012544	5.60100		
2	22:03:01	2.012754	6.80700		
3	22:03:02	3.012827	7.40120		
4	22:03:03	4.012703	8.01700		
5	22:03:04	5.012753	9.62803		
6	22:03:05	4.003701	8.01010		
7	22:03:06	3.012034	7.43700		
8	22:03:07	2.012003	6.80100		
9	22:03:08	1.012006	5.61200		
10	22:03:09	0.010754	4.00200		

04 MAY 2022 14:28


View **Data Log** file.

9.6.2 How to use a PC to view Data Log files in the DPI 610E

Data log files are saved in CSV format in the DPI 610E internal memory. Use a micro-USB data cable to connect the DPI 610E device to the PC (See Section 9.7 on page 172). On the PC, the DPI610E memory appears as a mass storage device or drive within Windows File Explorer.





Double-click on the DPI 610E drive and select the **DataLog** folder from the root directory.





Right-click on the desired log file and choose a supported application to open the file and view the contents: Microsoft Excel is recommended.

> DPI610E (E:) > DataLog









Name	Date modified	Type
 2022-JUL-21_16-05-19.csv	21/07/2022 16:05	Microsoft Excel C...
 2022-JUL-21_16-13-43.csv	21/07/2022 16:13	Microsoft Excel C...

9.6.3 Deleting Data Log Files




9.6.3.1 To delete a single Data Log file

Step 1		Select FILES from the Data Log screen.																								
Step 2	 <table border="1"> <thead> <tr> <th>FILENAME</th><th>CH1</th><th>CH2</th></tr> </thead> <tbody> <tr> <td>> 2020-JAN-04_20-59-00</td><td>PInt</td><td>mA</td></tr> <tr> <td>2020-JAN-04_20-59-01</td><td>PInt</td><td>mA</td></tr> <tr> <td>2020-JAN-04_20-59-02</td><td>PInt</td><td>mA</td></tr> <tr> <td>2020-JAN-04_20-59-03</td><td>PInt</td><td>mA</td></tr> <tr> <td>2020-JAN-04_20-59-04</td><td>PInt</td><td>mA</td></tr> <tr> <td>2020-JAN-04_20-59-05</td><td>PInt</td><td>mA</td></tr> <tr> <td>2020-JAN-04_20-59-06</td><td>PInt</td><td>mA</td></tr> </tbody> </table>	FILENAME	CH1	CH2	> 2020-JAN-04_20-59-00	PInt	mA	2020-JAN-04_20-59-01	PInt	mA	2020-JAN-04_20-59-02	PInt	mA	2020-JAN-04_20-59-03	PInt	mA	2020-JAN-04_20-59-04	PInt	mA	2020-JAN-04_20-59-05	PInt	mA	2020-JAN-04_20-59-06	PInt	mA	Tap on (or use the Navigation Pad) to select the required Data Log file.
FILENAME	CH1	CH2																								
> 2020-JAN-04_20-59-00	PInt	mA																								
2020-JAN-04_20-59-01	PInt	mA																								
2020-JAN-04_20-59-02	PInt	mA																								
2020-JAN-04_20-59-03	PInt	mA																								
2020-JAN-04_20-59-04	PInt	mA																								
2020-JAN-04_20-59-05	PInt	mA																								
2020-JAN-04_20-59-06	PInt	mA																								

Chapter 9. Data Log






Step 3	<div><div><div>Data Log File1/3</div><table><thead><tr><th>FILENAME</th><th>CH1</th><th>CH2</th></tr></thead><tbody><tr><td>>2020-JAN-04_20-59-00</td><td>PInt</td><td>mA</td></tr><tr><td>2020-JAN-04_20-59-01</td><td>PInt</td><td>mA</td></tr><tr><td>2020-JAN-04_20-59-02</td><td>PInt</td><td>mA</td></tr><tr><td>2020-JAN-04_20-59-03</td><td>PInt</td><td>mA</td></tr><tr><td>2020-JAN-04_20-59-04</td><td>PInt</td><td>mA</td></tr><tr><td>2020-JAN-04_20-59-05</td><td>PInt</td><td>mA</td></tr><tr><td>2020-JAN-04_20-59-06</td><td>PInt</td><td>mA</td></tr></tbody></table><div>04 MAY 2022 14:28</div></div><div>   </div></div>	FILENAME	CH1	CH2	>2020-JAN-04_20-59-00	PInt	mA	2020-JAN-04_20-59-01	PInt	mA	2020-JAN-04_20-59-02	PInt	mA	2020-JAN-04_20-59-03	PInt	mA	2020-JAN-04_20-59-04	PInt	mA	2020-JAN-04_20-59-05	PInt	mA	2020-JAN-04_20-59-06	PInt	mA	Select the 'single' trash icon on the Data Log File screen.
FILENAME	CH1	CH2																								
>2020-JAN-04_20-59-00	PInt	mA																								
2020-JAN-04_20-59-01	PInt	mA																								
2020-JAN-04_20-59-02	PInt	mA																								
2020-JAN-04_20-59-03	PInt	mA																								
2020-JAN-04_20-59-04	PInt	mA																								
2020-JAN-04_20-59-05	PInt	mA																								
2020-JAN-04_20-59-06	PInt	mA																								
Step 4	<div><div><div>Data Log File1/3</div><table><thead><tr><th>FILENAME</th><th>CH1</th><th>CH2</th></tr></thead><tbody><tr><td>>2020-JAN-04_20-59-00</td><td>PInt</td><td>mA</td></tr><tr><td>2020-JAN-04_20-59-01</td><td>PInt</td><td>mA</td></tr><tr><td>2020-JAN-04_20-59-02</td><td>PInt</td><td>mA</td></tr><tr><td>2020-JAN-04_20-59-03</td><td>PInt</td><td>mA</td></tr><tr><td>2020-JAN-04_20-59-04</td><td>PInt</td><td>mA</td></tr><tr><td>2020-JAN-04_20-59-05</td><td>PInt</td><td>mA</td></tr><tr><td>2020-JAN-04_20-59-06</td><td>PInt</td><td>mA</td></tr></tbody></table><div>04 MAY 2022 14:28</div></div><div>   </div></div>	FILENAME	CH1	CH2	>2020-JAN-04_20-59-00	PInt	mA	2020-JAN-04_20-59-01	PInt	mA	2020-JAN-04_20-59-02	PInt	mA	2020-JAN-04_20-59-03	PInt	mA	2020-JAN-04_20-59-04	PInt	mA	2020-JAN-04_20-59-05	PInt	mA	2020-JAN-04_20-59-06	PInt	mA	Select OK to confirm.
FILENAME	CH1	CH2																								
>2020-JAN-04_20-59-00	PInt	mA																								
2020-JAN-04_20-59-01	PInt	mA																								
2020-JAN-04_20-59-02	PInt	mA																								
2020-JAN-04_20-59-03	PInt	mA																								
2020-JAN-04_20-59-04	PInt	mA																								
2020-JAN-04_20-59-05	PInt	mA																								
2020-JAN-04_20-59-06	PInt	mA																								




9.6.3.2 To delete all Data Log files

Step 1		Select FILES from the Data Log screen.																								
Step 2	 <table border="1"> <thead> <tr> <th>FILENAME</th><th>CH1</th><th>CH2</th></tr> </thead> <tbody> <tr><td>> 2020-JAN-04_20-59-00</td><td>PInt</td><td>mA</td></tr> <tr><td>2020-JAN-04_20-59-01</td><td>PInt</td><td>mA</td></tr> <tr><td>2020-JAN-04_20-59-02</td><td>PInt</td><td>mA</td></tr> <tr><td>2020-JAN-04_20-59-03</td><td>PInt</td><td>mA</td></tr> <tr><td>2020-JAN-04_20-59-04</td><td>PInt</td><td>mA</td></tr> <tr><td>2020-JAN-04_20-59-05</td><td>PInt</td><td>mA</td></tr> <tr><td>2020-JAN-04_20-59-06</td><td>PInt</td><td>mA</td></tr> </tbody> </table>	FILENAME	CH1	CH2	> 2020-JAN-04_20-59-00	PInt	mA	2020-JAN-04_20-59-01	PInt	mA	2020-JAN-04_20-59-02	PInt	mA	2020-JAN-04_20-59-03	PInt	mA	2020-JAN-04_20-59-04	PInt	mA	2020-JAN-04_20-59-05	PInt	mA	2020-JAN-04_20-59-06	PInt	mA	Select the 'double' trash icon on the Data Log summary screen.
FILENAME	CH1	CH2																								
> 2020-JAN-04_20-59-00	PInt	mA																								
2020-JAN-04_20-59-01	PInt	mA																								
2020-JAN-04_20-59-02	PInt	mA																								
2020-JAN-04_20-59-03	PInt	mA																								
2020-JAN-04_20-59-04	PInt	mA																								
2020-JAN-04_20-59-05	PInt	mA																								
2020-JAN-04_20-59-06	PInt	mA																								
Step 3		Select OK to confirm.																								

9.7 How to transfer a Data Log file

Data Log files can be copied from the DPI 610E internal memory to an external device. This device can either be a micro-USB memory stick or an external PC.

Step 1		<p>Select the Settings icon  on the Dashboard. Press the Home button  if necessary, to show the Dashboard. To select, tap on the icon or press the softkey on the right of icon.</p>
Step 2	 	<p>The General Settings screen appears. Select the USB option. Push a micro-USB memory stick into the USB port located behind a rubber flap at the end of the instrument. Use a USB port converter if only a standard USB memory stick is available. If the Data Log file is to be copied to the memory of an external PC, connect a micro-USB data cable to the USB port.</p>

Step 4		<p>Click on MASS STORAGE to select the option.</p> <p>Select ✓ to confirm the selection.</p>
Step 5	<p>Connect the DPI 610E to the PC using the micro-USB data cable. The PC should automatically detect the DPI610E which should appear as a Mass Storage drive (default name is DPI610E)..</p>  <p>Note: You may need to have USB access enabled on your PC to use this feature.</p>	
Step 6	<p>When the copy process is confirmed, remove the cable from the DPI 610E. .</p> 	

10. Analysis

10.1 Overview

The **Analysis** application calibrates the transfer characteristic of a device under test. This is done by using readings from the two channels. One channel acts as the Input channel and the other channel as the Output channel.

The Input channel provides a measure of the input signal to the device under test (DUT). For example, if calibrating a pressure transmitter, the Input channel could be the DPI 610E Internal Pressure which measures the supplied pressure to the DUT.

The Output channel measures the output signal from the DUT. If calibrating a 4 to 20 mA process transmitter, the output channel would be the Current Measure.

By default, the Analysis application uses the functions and measurement units set up in CH1 as the Input and the function set up in CH2 as the output. This means that the required functions for analysis must be selected in the Calibrator screen before starting the Analysis application (Refer to “Calibrator Tasks” on page 64 for more details.)

There is however the option to toggle between Input and Output selection for both functions.

For the Analysis application to run, both channels must be enabled with a valid function i.e., any function option except “None”.

At each test point value, the Analysis function calculates the difference of each Output channel to the ideal transfer characteristic and compares this to a user specified tolerance limit. This deviation is calculated and can be displayed in different user defined formats. In addition, the tolerance test result is shown as a **Pass** or **Fail**.

10.2 Analysis Application

Select the **Analysis** icon on the Dashboard to start the Analysis application.





Figure 10-1: Instrument Dashboard

10.3 Setup

The **Analysis Setup** screen shows the selected **CH1** and **CH2** calibrator functions and units. The required functions needed in the Analysis application, need to be selected in the Calibrator application prior to running Analysis. For example, to run analysis on a pressure transmitter with a 4 to 20 mA output, **CH1** can be configured to **INT Pressure** and **CH2** to **Current Measure** (with 10/24 V power if required). Select the required types of measurement units.

Analysis: Setup		INP
	INPUT	OUTPUT
FUNCTION	INT Pressure	Current
UNITS	bar	mA
START	> 0.0000	0.0000
END	1000.0000	1000.0000
LINEARITY	Linear	
ERROR TYPE	% Span	
TOLERANCE	0.100%	
04 MAY 2022 14:28		

Figure 10-2: Analysis Function screen

The **INPUT** and **OUTPUT** functions can be interchanged using the toggle  softkey.

10.3.1 START/END Values

The measurement range for the input and output channels is defined by setting a **START** (Low) and **END** (High) value for each channel. The default values displayed are usually the negative and positive full-scale values of the related function. When Current Measure is selected, the default **START** and **END** values, are 4 and 20 mA. When entering **START** and **END** values, any value entered which falls outside the full-scale limits of the selected function will be rejected.

10.3.2 LINEARITY

The transfer characteristic from **INPUT** signal to the **OUTPUT** signal can be either:

- Linear - when the transfer characteristic is a directly proportional relationship.
- Square Root - when the transfer characteristic has a square-root relationship. This is commonly found in flow sensors.

The default mode is Linear.

Chapter 10. Analysis

10.3.3 ERROR TYPE

The error or deviation from the transfer characteristic can be calculated and expressed in any of the following options:

- % Span - a percentage of the Output signal span.
- % Full Scale - a percentage of the Output signal full-scale.
- % Reading - a percentage of the Output signal reading.
- Fixed - absolute measurement units of the Output signal.

The default option is % Span.

10.3.4 TOLERANCE


Use this option to define the tolerance or test limit values for the calculated result error or deviation from the transfer characteristic. The tolerance value is expressed either as a percentage (%) or as an absolute or fixed measurement unit e.g., mA. This is reliant on the Error type selected.

The default tolerance value is 0.1%.

10.4 Analysis Function


Set the **Input** and **Output** channel and error analysis parameters as described in “Analysis Application” on page 174.


Select the **Play**  button to start.



The **Analysis** main screen window displays the following:

1. The deviation tolerance type.
2. The error/deviation value of the output channel from the ideal transfer characteristic.
3. A live indication of the tolerance result status icon which is one of the following:

PASS  - the currently measured output value lies within the specified tolerance limits.


FAIL  - the currently measured output value lies outside the specified tolerance limits.




The screen is in two sections. Each section displays information for a channel and is either the **Input** or **Output** channel.

To test the full range of the Device Under Test (DUT):

- Step the input signal value through its range. In the example screen shot, step the internal pressure generated by using the DPI 610E pump from the lower range of the DUT to the full-scale pressure value.
- At each setpoint step, check the Analysis status at the top of the screen for the deviation.
- When the test is complete, exit the Analysis screen using the **Back** button.

10.4.1 DATA LOGGING within Analysis

Checking a DUT in the Analysis application can be documented using the Datalog. To use this feature, select the **Data Log**  icon. For more information on **Data Log**, see Chapter 9 on page 155. When using **Data Log** in the Analysis application, only the **Key Press** trigger mode is available.

- Enter the required **Data Log** file name.
- Select the **Play**  softkey to proceed.
- At each **Setpoint** step (or when desired), press the “Add Datapoint”  softkey to capture the current analysis data displayed by the screen.
- When the testing is complete, press the **Back**  icon to exit the Datalog and Analysis application.

Datalog files can be accessed via the **Data Log** application (Refer to “Data Log” on page 155).

11. Documenting

11.1 Overview


Use the Documenting application to do documented calibration of Device Under Test (DUT) equipment or of assets using defined test procedures.

Test procedures can be created within the Documenting application and stored for future use.

When test procedures are used to calibrate DUTs, the test details and results of the calibration are saved in DPI 610E memory. This data can also be transferred to a PC for further analysis or post calibration tasks.


A calibration certificate template wizard is provided by Druck to transform the data into a professional looking format for printing or filing purposes. The related Excel Macro file is available on: [Druck.com/DPI610E](https://druck.com/DPI610E) as “Druck DPI610E Calibration Template”.

11.1.1 How to start the Documenting application








	<p>Select the Documenting softkey from the Dashboard. This will show the Procedures screen.</p>
--	---





11.2 Internal Procedures

11.2.1 How to select the INTERNAL PROCEDURES mode.

<p>Step 1</p>		<p>To view, create or run internal procedures, select the INTERNAL PROCEDURES softkey from the Procedures screen. This will show a list of available internal procedure files.</p>
---------------	---	--

11.2.2 How to create an Internal Procedure

Step 1		<p>This screen appears after INTERNAL PROCEDURES has been selected from the Procedures screen (see Section 11.2.1 on page 178).</p> <p>The Internal Procedure Files screen shows the list of available internal procedure files. The number of Assets on which each procedure has been run and calibration results saved will also be shown alongside the Procedure file name. See Section 11.2.3 on page 187 on how to run a test procedure.</p> <p>If no procedures have been created or saved, the Internal Procedures screen will be blank.</p> <p>Select the New Procedure  Softkey to start the Procedure Creation wizard.</p> <p>Note: Functions on CH1 and CH2 configured in Calibrator, will be used as the input and output functions when creating an internal procedure.</p>
Step 2		<p>Enter a filename for the test procedure or use the default filename which is based on the system date and time stamp.</p> <p>Note: A maximum of 20 characters is supported for the filename.</p> <p>Select the Tick  softkey to confirm and show the Create Procedure screen.</p>
Step 3		<p>Select the type of calibration required. Proportional is the default option.</p> <p>Press the Next  softkey to proceed or the Previous  softkey to go back one step.</p>

		<p>This is the test procedure setup screen that has the following sections that are critical to the procedure:</p> <ol style="list-style-type: none"> 1. Input 2. Output 3. Test Points 4. Tolerance. <p>These details are auto populated based on the current Calibrator configuration, parameters configured in the Analysis application setup and other default settings. Details of each section is given in the following steps.</p>
Step 4		<p>INPUT: The input refers to the test input signal to the Device Under Test (DUT). The input function type, the sensor type (where applicable), the range, and the measurement units all appear in this section.</p> <p>By default, the Function (and hence Sensor type) set up in CH1 is configured as the input with the selected Units. These are read-only and not editable in the procedure creation wizard. If any changes are required, these must be done in Calibrator prior to the use of the Documenting application.</p>
		<p>The input range is auto populated by default with the full sensor range related to the Function. Only the range can be edited and must be within the full sensor range. Set the START and END values of the input range if different to the values displayed.</p> <p>Note: It is possible using the Toggle  softkey to swap the Input and Output functions i.e., use the original Input function as the Output function and vice versa.</p>

Step 4
Cont'd

Procedure: 2022-MAY04_14-28-03 / OUTPUT

> FUNCTION	Current
UNITS	mA
SENSOR	
START	4.0000 ✓
END	20.0000 ✓

04 MAY 2022 14:28

OUTPUT: The Output refers to the output signal from the Device Under Test (DUT). By default, the **FUNCTION** (and hence **SENSOR** type) set up in **CH2** is configured as the output with the selected **UNITS**. These are read-only and not editable in the procedure creation wizard. If any changes are required, these must be done in Calibrator prior to using the Documenting application.

The output range is auto populated by default with the full sensor range related to the Function. Only the range can be edited and must be within the full sensor range. Set the **START** and **END** values of the input range if different to the values displayed.

Note: It is possible using the **Toggle** softkey to swap the Input and Output functions i.e., use the original Input function as the Output function and vice versa.

Procedure Output

START VALUE	4.00
-------------	------

mA

1	2	3	X
4	5	6	
7	8	9	
.	0	±	

CLR

04 MAY 2022 14:28

TEST POINT: This refers to input points at which the device under test (DUT) is tested and its calibration data recorded.

POINTS UP & POINTS DOWN



The number of calibration points must be specified within the specified Input range. This can be specified as **POINTS UP** i.e. direction from **START** range value to **END** range value or/and **POINTS DOWN** i.e. direction from **END** range value to **START** range value.



The default setting is 2 POINTS UP and 0 POINTS DOWN. This means there will be two test points - the first test point will be the Input Start value and the second will be the Input End value.

Procedure: 2022-MAY04_14-28-03 / TEST POINT

> POINTS UP	2 ✓
POINTS DOWN	0 ✓
LINEARITY	Linear ✓
TEST POINT TOLERANCE	0.000 ✓

04 MAY 2022 14:28

		<p>Set the desired number of points UP and DOWN if different from that displayed. Either UP or DOWN values must be between 0 and 25.</p> <p>Note: There must be a minimum of 2 points UP and maximum of 25 test points in total (i.e., UP and DOWN combined). For each Points UP and DOWN setting, the resulting test point values are calculated and can be viewed by selecting the View softkey.</p>
<p>Step 4 Cont'd</p>		<p>In the Test Point screen, it is possible to manually adjust each test point if required by selecting the relevant test point box and changing the value. As shown in the screen below.</p>

Step 4 Cont'd		<p>Linearity – the relationship between the input and output can also be specified i.e., either Linear or Square Root transfer function.</p> <p>The default is Linear.</p> <p>The use of a square root function is necessary for pressure transmitters that measure fluid flow. This fluid flow produces pressure readings that do not follow a linear relationship.</p>
		<p>TOLERANCE – this is the maximum deviation or permissible error margin for each input test point in the calibration. It is specified as a percentage of the Input range.</p> <p>The default test point tolerance value is 5% and can be changed if required.</p>

Step 5

Procedure: 2022-MAY-04_14-28-03 / TOLERANCE

> PASS/FAIL0.100%

ADJUSTMENT0.050%

ERROR TYPE% Span

04 MAY 2022 14:28

%Error

0.25

0.20

0.15

0.10

0.05

0.00

-0.05

-0.10

-0.15

-0.20

-0.25

0

20

40

60

80

100

80

60

40

20

0 %

Testpoints

Fail

Adj.

Pass

Adj.

Fail

TOLERANCE: This section refers to the deviation on the output signal or result with respect to each input signal setpoint applied.

Step 5
Cont'd

Procedures

RESULT TOLERANCE 0.10000 %

1 2 3
4 5 6
7 8 9
. 0 CLR

04 MAY 2022 14:28

PASS/FAIL (or Result Tolerance) (P/F): This sets the maximum deviation that determines if the result (output) at each test point is within specification (**PASS**) or out of specification (**FAIL**). It is expressed as a percentage of the output or in fixed measurement units depending on the tolerance type. The default value is 0.1% (based on % FS).

Procedures

ADJUSTMENT TOLERANCE 0.05000 %

1 2 3
4 5 6
7 8 9
. 0 CLR

04 MAY 2022 14:28

This screen is for the **ADJUSTMENT** value in the **Procedure: PT_1/Tolerance** screen on the previous page. **ADJUSTMENT (Tolerance):** This sets the maximum deviation within the **PASS/FAIL** tolerance which indicates that the Device Under Test (DUT) is close to out of specification limits. Hence the **ADJUSTMENT** tolerance value must be less than the **PASS/FAIL** tolerance value to be captured. If an **ADJUSTMENT** tolerance is not required, the adjustment tolerance value can be equal to the **PASS/FAIL** tolerance. The default value is 0.07% (based on % FS).

Procedures

☒ % **SPAN**

☐ % **FULLSCALE**

☐ % **READING**

☐ **FIXED**

04 MAY 2022 14:28

Use this screen to set the way the maximum deviation is calculated. The four options for this calculation are given by the graph in the next row.

ERROR TYPE (Tolerance): this specifies the way the maximum deviation is calculated and expressed. Options include:

- %FS (Percent of Full-scale)
- %Span (Percent of Span)
- %Percent of reading)
- %Fixed (Measurement units).

See Section 10.3.3 on page 176 for more details.

The default is % Full-scale (%FS).

Step 6

Procedure: 2022-MAY04_14-28-03

INPUT

> Pressure **INT** mbar

Gauge 0.000 To 1000.000

OUTPUT

Current **←** mA

4.000 To 20.000

TEST POINT

Up:2 Linear

Down:0 Tol:0.000%

TOLERANCE

% Span

P/F:0.100%

ADJ:0.050%

04 MAY 2022 14:28




INP

OUT



When the details of the test are completed, press the **Save** softkey to save the procedure.

The test procedure after being saved, becomes immediately available for use.

11.2.3 How to start a Test Procedure

Step 1		<p>Once the test procedure has been saved successfully, it is available to be used immediately by selecting the Play  softkey.</p>
Step 2		<p>The test procedure can also be selected from the Internal Procedure Files screen. Select a test procedure, for example, File 2, by tapping in the row or using the Navigation pad.</p>

11.2.4 How to delete a Test Procedure





	<p>Tap or use the Navigation pad buttons to select the row that has the test procedure file name: in this example, File 2.</p> <p>Tap or use the softkey to select the Delete  icon, to delete the file name from the list. Note: When a Test Procedure is deleted, any asset data saved as part of the procedure file will also be deleted.</p>
---	---

Chapter 11. Documenting

11.2.5 Starting a Test Procedure

When a test procedure has been created and saved in DPI 610E memory, it can be run by selecting the **Play** softkey. Additional data about the DUT, Environment and User is required each time the test procedure is run.

11.2.5.1 DUT data

Step 1		Enter the following data about the Device Under Test: ASSET ID (Mandatory) – This is a unique tag or device reference that is given to the asset or DUT. This ID will be used as the default result filename when the calibration is completed. Maximum number of characters: 31. SERIAL NUMBER (Optional) – the serial number of the asset or DUT. Leave blank if not known. Maximum number of characters: 50. MANUFACTURER (Optional) – the manufacturer of the asset or DUT. Maximum number of characters: 30. MODEL (Optional) – the model's name or number of the asset or DUT. Maximum number of characters: 30. LOCATION (Optional) – the physical location of the asset or DUT. Maximum number of characters: 50.
		
		When the required fields have data in them select the Next  screen icon to go to the next step.

11.2.5.2 Environment and User ID data

Step 1

2022-MAY-04_14-28-03

> AMBIENT TEMPERATURE 20.00°C

AMBIENT PRESSURE 1011.55mbar

AMBIENT HUMIDITY 67.90%

USER ID

04 MAY 2022 14:28



Procedures

AMBIENT TEMPERATURE 20.0 °C

1 2 3

4 5 6

7 8 9

. 0 ±

CLR

04 MAY 2022 14:28



Procedures

AMBIENT PRESSURE 1013 mbar

1 2 3

4 5 6

7 8 9

. 0 ±

CLR

04 MAY 2022 14:28



If required, enter the following ambient environment and user details.

AMBIENT TEMPERATURE – Enter the ambient temperature value where the test is being done. Temperature units available are °C or °F. Use the



Toggle softkey to switch between these units. The unit conversion will be done automatically: 20°C is the default ambient temperature value. Any value entered must be between -100 to +100 °C (-148 to 212 °F).





AMBIENT PRESSURE – Enter the ambient pressure value (or pressure of the day) where the test is being done. Pressure units available are mbar, psi

or in Hg. Use the **Toggle** softkey to switch between these units. The unit conversion will be done automatically. For DPI 610E pneumatic variants, the default ambient pressure value is obtained from the internal barometer sensor. On hydraulic variants, the default ambient pressure value is 1013 mbar. Any value entered must be between 800 to 1200 mbar (11 to 18 psi or 23 to 36 in Hg).

AMBIENT HUMIDITY – Enter the ambient humidity value where the test is being done. The default value is 70%. Any value entered must be between 0 and 100%.

Chapter 11. Documenting




<p>Step 1 Cont'd</p>		<p>USER ID – enter the User ID of the person doing the test procedure. Maximum number of characters: 20.</p> <p>Select the Tick ✓ softkey to save the User ID entry or select the Back ↶ softkey to return to the previous screen without saving.</p>
<p>Step 2</p>		<p>After the Environment and User ID data have been entered, select the Proceed > softkey to continue.</p> <p>A popup message will appear to prompt the user to check all the details are correct. Select the OK button to clear the message. This provides a checkpoint where the user may go back and check all the details of the test procedure are correct.</p>



Step 2 Cont'd		<p>When ready to start the test, press the Proceed  softkey to continue.</p>
Step 3		<p>When the test configuration is complete, connect the Device Under Test (DUT) if not done already. A popup message will appear, to prompt the user to make this connection. Select OK only when the DUT has been connected successfully. The screen in Step 5 will appear.</p>
Step 4		<p>The DPI 610E does a verification check to make sure the test requirements and the DUT connected match. At this stage any discrepancies will be identified, and the relevant popup message appears. For example, if a pressure sensor (DUT) is connected that is a different sensor type to that which the test specifies. Another example is if the DUT connected has an incompatible pressure range to that which is specified for the test.</p>

The next section describes the components of the **Documenting Main** screen.










11.3 The Documenting Main Screen




This section describes the different elements of the **Documenting Main** screen.

	<p>The title bar contains information about:</p> <ul style="list-style-type: none"> • Number of steps the test requires and what the current step is e.g., Step 1 of 2. • The input test point value to apply e.g., Go to 0.000 bar. • Completion status at the end of the test.
	<p>This screen shows the sensor information and readings for Input and Output. The top channel displays the Input information and the bottom channel, the Output.</p> <p>In the output section, the Error Type appears below the reading on the right side of the window e.g., % Span in the example screen.</p>
	<p>The error and tolerance indicator is for both the input and the output.</p> <p>The specified tolerance value is on either side of the zero mark. This value is based on the Error Type and hence is expressed as a % unless the Fixed units Error type is selected, which in this case is expressed as the Output measurement units.</p> <p>The calculated live error is displayed below the zero mark in both input and output channels. A marker is also displayed to indicate the approximate error value point with respect to the specified tolerance and tolerance line.</p> <p>Note: if the marker is not visible, check the error value as it most likely means the error is too large to be visible on the error and tolerance indicator.</p>





 <p>STEP1 DF 2: Go to 0.0000 bar</p> <p>INT Pressure bar</p> <p>0.1811</p> <p>FS: 35.0000 INPUT</p> <p>-0.0504</p> <p>Current mA</p> <p>4.1521</p> <p>FS: 55.0000 % Span</p> <p>-0.100 0 +0.100</p> <p>-0.1504</p> <p>04 MAY 2022 14:28</p>	<p>Select the Add Test Point  softkey to capture the datapoint.</p>
--	---






11.4 Documenting Settings

Step 1	    	<p>If additional test procedure setup is required before documenting begins, select the Setup  softkey.</p>
Step 2	  	<p>Pressure Sensor Type For pressure calibrations, if a different pressure sensor type is to be used from that which was used to create the test procedure, it is possible to change the sensor configuration to match.</p> <p>Note: This applies to the INT and EXT Pressure functions used as the Input or/and Output only.</p> <p>For example, if a gauge pressure sensor is specified in the test procedure and the available pressure sensor is an absolute pressure sensor, the absolute pressure sensor can be configured to pseudo gauge (pneumatic variants only) or sealed gauge (hydraulic variants only).</p> <p>To use PSEUDO RANGE, select the relevant pseudo-range option from the settings screen. The tick-box is ticked when enabled and unticked when disabled.</p>

<p>Step 3</p>		<p>Pressure Sensor Function</p> <p>For pressure-to-pressure calibrations i.e., INT pressure and EXT pressure, it is possible to swap the assignments of the sensors as Input and Output by the use of the Toggle  softkey. Care must be taken to make sure the sensor type and range are compatible with that specified in the test.</p>
		<p>10 V/24 V Power</p> <p>Select the required option from the settings screen. The tick-box is enabled when it has a tick mark and disabled when it does not have a tick mark.</p> <p>Note: These options are only available when electrical functions are used in the test procedure.</p>

11.5 Running a Test Procedure







Step 1		<p>Using the step instructions in the title bar, go to (or input) the Step 1 setpoint value displayed.</p> <p>In this example, apply 0.0000 bar using the DPI 610E pump and/or volume adjuster. When the value is within the test point tolerance limits, select the Add Test Point  softkey to capture the datapoint.</p>
Step 2		<p>A popup message window appears that shows the Pass/Fail status of both the input (test point) and the output (result) and requires confirmation to log the calibration data point. Select OK to accept and log the reading or Cancel to abort.</p>
Step 3		<p>Go to the next step setpoint as shown in the title bar and repeat the previous step.</p> <p>Repeat until all steps have been completed and logged.</p>

Step 4		<p>After the last calibration data point has been logged, the Tick softkey will replace the Add Test point softkey. The title bar will show Procedure complete, together with a PASS/FAIL.</p> <p>Select the Tick  softkey to confirm completion of the calibration.</p>
Step 5		<p>The following screen is the CALIBRATION REMARKS screen.</p> <p>Enter any comments worth noting relating to the calibration procedure just completed. This step is optional, and the CALIBRATION REMARKS field can be left blank.</p> <p>Maximum number of characters: 50.</p> <p>Select the Save  softkey to save the CALIBRATION REMARKS and continue.</p>
Step 6		<p>The next screen is the Procedure result summary screen. This screen gives details of the test procedure just completed.</p>

11.6 Post Examination of Test Procedure Results






Step 1	<div> <div>Summary: 2022-MAY-04_14-28-03</div> <div> <div>ASSET ID* DRU099</div> <div>INPUT - SENSOR TYPE Gauge</div> <div>OUTPUT - SENSOR TYPE n/a</div> <div>> AS FOUND ADJUST, 04 MAY 2022</div> <div>AS LEFT PASS, 04 MAY 2022</div> <div>04 MAY 2022 14:28 </div> </div> <div> </div> </div>	<p>Note: When a test procedure is done on a new Asset for the first time, there will be no As-Found or As-Left results. When no As-Found or As-Left results are detected for a particular asset, the calibration data will be automatically saved as As-Found.</p> <p>If As-Found or As-Left results file is detected, then at the end of the test procedure there is the option to save the results as As-Found or As-Left. Selecting As-Found will overwrite any existing As-Found data. If no As-Left data is detected, and save as As-Left is selected, then a new As-Left results file is saved. If As-Left data file exists already, then the file is overwritten if As-Left option is selected.</p>
Step 2	<div> <div>Summary: 2022-MAY-04_14-28-03</div> <div> <div>ASSET ID* DRU099</div> <div>INPUT - SENSOR TYPE Gauge</div> <div>OUTPUT - SENSOR TYPE n/a</div> <div>> AS FOUND ADJUST, 04 MAY 2022</div> <div>AS LEFT PASS, 04 MAY 2022</div> <div>04 MAY 2022 14:28 </div> </div> <div> </div> </div>	<p>On the Test Procedure Summary screen, the option to re-run the test procedure using the same test details and device under test (DUT) details is provided by using the Play softkey.</p> <p>If you wish to exit, use the Back softkey to return to the Internal Files Procedure menu.</p>

11.7 Making an adjustment on the Device Under Test (DUT)

Step 1		<p>If at the end of the test procedure, an adjustment is required. For example, if the end result of the test procedure is a Fail. Then it is possible to perform and verify an adjustment using the Analysis  softkey.</p>
Step 2		<p>Make the necessary adjustment to the DEVICE UNDER TEST (DUT) and check the output signal through its entire calibration range to ensure it is within spec before repeating the calibration test procedure. When the adjustment is complete, select the Back  softkey to return to the Procedure Summary screen.</p>
Step 3		<p>The test procedure may now be done again after adjustment. Select the Play  softkey or icon to do this.</p>

11.8 How to redo a Test Procedure





The instructions in this section relate to doing a Test Procedure again for an existing asset or Device Under Test (DUT).

Step 1		<p>Select the desired test procedure file from the list in the Internal Procedures Files screen.</p>
Step 2		<p>Select the Briefcase (Assets)  softkey to view the asset details which the test procedure has been done on.</p>
Step 3		<p>On the Assets screen, view all assets that this specific test procedure has been done on and logged. Note: Up to 25 Assets and results can be saved for each calibration test procedure. To redo the test procedure on the selected asset or Device Under Test (DUT). Select the Play  softkey from this menu screen.</p>







Step 4	<div> <div>File 1: DRU099</div> <div> <div>> AS FOUND</div> <div>ADJUST</div> <div>20 DEC 2022</div> </div> <div> <div>AS LEFT</div> <div>ADJUST</div> <div>20 DEC 2022</div> </div> <div>04 MAY 2022 14:28 </div> </div> <div> </div>	<p>To view As-Found or/and As-Left calibration results, select the desired Asset filename by tapping once to select and a second time to open.</p> <p>Any available results associated with that test procedure and asset will appear on the screen.</p>
--------	---	--

11.9 How to View Test Results.








Step 1	<div> <div>Summary: 2022-MAY-04_14-28-03</div> <div> <div>ASSET ID*</div> <div>DRU099</div> </div> <div> <div>INPUT - SENSOR TYPE</div> <div>Gauge</div> </div> <div> <div>OUTPUT - SENSOR TYPE</div> <div>n/a</div> </div> <div> <div>> AS FOUND</div> <div>ADJUST, 04 MAY 2022</div> </div> <div> <div>AS LEFT</div> <div>PASS, 04 MAY 2022</div> </div> <div>04 MAY 2022 14:28 </div> </div> <div> </div>	<p>Results can be viewed immediately after the test procedure is complete, by tapping on the required result (i.e., As-Found or As-Left) from the procedure SUMMARY screen.</p> <p>The results can also be viewed by selecting the relevant Test Procedure file and required asset file.</p>
--------	---	---

<p>Step 2</p>	 	<p>The calibration test procedure results show the following:</p> <ul style="list-style-type: none"> • Result type – As-Found or As-Left • Date/Time – the date and time stamp the calibration procedure was completed • Details of the input and output function i.e., Function name and measurement units • Data details including: <ul style="list-style-type: none"> • Input Expected • Input (Actual) • Output • Calculated Error • Pass or Fail status for each test point • Pass or Fail Status overall. <p>To view Calibration remarks relating to the test, select the Clipboard  softkey.</p>
<p>Step 3</p>		<p>Results can also be viewed when the test procedure is selected, the device under test is selected and then the relevant test result i.e., As-Found or As-Left.</p>

11.10 Deleting Asset Data

Step 1		   	<p>Select the required test procedure. Select the required asset to be deleted.</p> <p>Select the Delete  softkey.</p> <p>Note: All asset data will be deleted.</p>
--------	---	--	--

11.11 How to use the Calibration Certificate Wizard

Step 1		   	<p>When an As-Found or As-Left asset or Device Under Test (DUT) result is viewed, it is possible to create a certificate document, using the calibration and test procedure details.</p> <p>Select the QR code softkey to access the QR code for the calibration certificate template.</p> <p>This template transforms the raw calibration procedure result data to a formatted calibration certificate document.</p>
			<p>Download the certificate template either using the URL or QR code provided.</p>

Chapter 11. Documenting

Step 3

Step 4

CALIBRATION CERTIFICATE																																																																																				
<div><div>Select CSV</div><div>Add Logo</div><div>Export</div><div>Reset</div></div>																																																																																				
<div><div><div>DEVICE UNDER TEST</div><div><div>Device Identifier</div><div>TH02343</div></div><div><div>Serial Number</div><div>4575262335</div></div><div><div>Manufacturer</div><div>Druck</div></div><div><div>Model</div><div>DPH610E</div></div><div><div>Sensor Type</div><div>Gauge</div></div></div><div><div>CALIBRATION</div><div><div>Date of Calibration</div><div>01-Jun-22</div></div><div><div>Operator</div><div>Robert Smith</div></div><div><div>Location</div><div>Global Star Lab</div></div><div><div>Ambient Temperature</div><div>20.00 °C</div></div><div><div>Ambient Pressure</div><div>1005.82 mbar</div></div><div><div>Ambient Humidity</div><div>70.00%</div></div></div></div> <div><div><div>TEST EQUIPMENT</div><div><div>MAIN CALIBRATOR</div><div><div>Manufacturer</div><div>Druck</div></div><div><div>Model</div><div>DPH610E-PC-140</div></div><div><div>Serial Number</div><div>12121908</div></div><div><div>Date of Calibration</div><div>15-Mar-22</div></div><div><div>Calibration Interval</div><div>450 days</div></div></div><div><div>ADDITIONAL SENSORS 1</div><div><div>Manufacturer</div><div>Druck</div></div><div><div>Model</div><div>DPH610E-PC-140</div></div><div><div>Serial Number</div><div>12222043</div></div><div><div>Date of Calibration</div><div>2-MAR-2022</div></div><div><div>Sensor Type</div><div>Gauge</div></div><div><div>RANGE</div><div>-1.00 to 35.00 bar</div></div></div></div><div><div><div>RANGE</div><div><div>Input</div><div>0.00000 to 24.00000 bar</div></div><div><div>Output</div><div>0.00000 to 240.00000 mV</div></div><div><div>Relationship</div><div>Linear</div></div></div><div><div>TOLERANCE</div><div><div>Test Point</div><div>5.00 %span</div></div><div><div>Pass/Fail</div><div>0.10 % span</div></div><div><div>Adjustment</div><div>0.07 % span</div></div></div></div><div><table><tr><td></td><td></td><td></td><td></td><td></td><td>Result:</td><td>PASS</td></tr><tr><td>#</td><td>Expected Input</td><td>Actual Input</td><td>Expected Output</td><td>Actual Output</td><td>Error</td><td>Status</td></tr><tr><td></td><td>CH1</td><td>CH1</td><td>CH2</td><td>CH2</td><td></td><td></td></tr><tr><td></td><td>bar</td><td>bar</td><td>mV</td><td>mV</td><td>mV</td><td></td></tr><tr><td>0</td><td>0</td><td>-0.0031</td><td>-0.0032</td><td>0.0087</td><td>0.00625</td><td>PASS</td></tr><tr><td>1</td><td>1</td><td>1.00821</td><td>10.08206</td><td>10.01069</td><td>-0.02985</td><td>PASS</td></tr><tr><td>2</td><td>2</td><td>2.0072</td><td>20.072</td><td>20.01846</td><td>-0.02231</td><td>PASS</td></tr><tr><td>3</td><td>3</td><td>3.00761</td><td>30.07608</td><td>30.03322</td><td>-0.01786</td><td>PASS</td></tr><tr><td>4</td><td>4</td><td>4.00949</td><td>40.09486</td><td>40.04515</td><td>-0.02071</td><td>PASS</td></tr><tr><td>5</td><td>5</td><td>5.00428</td><td>50.04277</td><td>50.05528</td><td>0.00521</td><td>PASS</td></tr><tr><td>6</td><td>6</td><td>6.0072</td><td>60.07204</td><td>60.06263</td><td>-0.00392</td><td>PASS</td></tr><tr><td>7</td><td>7</td><td>7.00299</td><td>70.02946</td><td>70.07331</td><td>0.0827</td><td>PASS</td></tr></table></div></div>						Result:	PASS	#	Expected Input	Actual Input	Expected Output	Actual Output	Error	Status		CH1	CH1	CH2	CH2				bar	bar	mV	mV	mV		0	0	-0.0031	-0.0032	0.0087	0.00625	PASS	1	1	1.00821	10.08206	10.01069	-0.02985	PASS	2	2	2.0072	20.072	20.01846	-0.02231	PASS	3	3	3.00761	30.07608	30.03322	-0.01786	PASS	4	4	4.00949	40.09486	40.04515	-0.02071	PASS	5	5	5.00428	50.04277	50.05528	0.00521	PASS	6	6	6.0072	60.07204	60.06263	-0.00392	PASS	7	7	7.00299	70.02946	70.07331	0.0827	PASS
					Result:	PASS																																																																														
#	Expected Input	Actual Input	Expected Output	Actual Output	Error	Status																																																																														
	CH1	CH1	CH2	CH2																																																																																
	bar	bar	mV	mV	mV																																																																															
0	0	-0.0031	-0.0032	0.0087	0.00625	PASS																																																																														
1	1	1.00821	10.08206	10.01069	-0.02985	PASS																																																																														
2	2	2.0072	20.072	20.01846	-0.02231	PASS																																																																														
3	3	3.00761	30.07608	30.03322	-0.01786	PASS																																																																														
4	4	4.00949	40.09486	40.04515	-0.02071	PASS																																																																														
5	5	5.00428	50.04277	50.05528	0.00521	PASS																																																																														
6	6	6.0072	60.07204	60.06263	-0.00392	PASS																																																																														
7	7	7.00299	70.02946	70.07331	0.0827	PASS																																																																														

Connect the DPI 610E to a PC using a compatible data micro-USB cable.

Note: Make sure the USB setting is in Storage mode (See Section 4.3 on page 47).

Open the Calibration Certificate Template file and click on the **Select CSV** cell.

Select the required asset result file from the DocData folder in the DPI 610E mass storage drive in File Explorer and select **Open**.

The calibration data and test procedure data will be populated in the template format.

To add a logo, select the **Add Logo** cell, and select the desired logo image and select **OK** to use.

When the calibration certificate document has been formatted and edited to suit the user requirements, it can then be exported as a PDF file using the **Export** button on the template CSV and selecting a destination file path for it to be saved.

11.12 Remote Documenting

Remote documenting is a documenting feature that allows test procedures created in our 4Sight2 software to be downloaded and run on the DPI 610E to calibrate devices under test.






4Sight2 offers easy-to-use, cost effective and scalable calibration management with full integration with Druck Calibrators, to provide seamless communication, end-to-end automation, paperless calibration process and increased efficiency.

The 4Sight2 software is available on the Druck website www.druck.com/4sight2 and is free to download and use (trial or Freemium version).

To download test procedures from 4Sight2 on to the DPI 610E, connect the instrument to the PC using the USB data cable supplied.

Chapter 11. Documenting


11.12.1 Setup and Connection.

Step 1		Select the Settings  softkey on the Dashboard.
Step 2		Select the USB option.
Step 3		Select the VIRTUAL COMMS PORT radio button if it is not already selected. Select the Tick  softkey to confirm completion of the selection.


The 4Sight2 software and the Druck CommServer must install correctly for the DPI 610E to successfully connect to the 4Sight2 software.

Start the 4Sight2 application on your system.


From the 4Sight2 Dashboard, select the **Assets** tab to access **Asset and Work List** information. Select the **Work List** tab to view the calibrations required to be completed. (For more information on how to create Assets or Work List items, please refer to the 4Sight2 Calibration Management Software User Manual 123M3138).



From the 4Sight2 work list, select calibration procedure(s) to be done. Select the **Portables** calibration type option and press the **Send** button.



Next, navigate to the **Calibration** tab and click **Portable Calibration**. The calibration procedure(s) selected in the previous step should be listed in the Portable Calibration list.



Select the desired procedure to proceed. Ensure the Port is set to **USB**. If the **Test Equipment** drop-down box is empty, select **Get Connected Test Equipment**. This will start the connection to the DPI 610E.

Chapter 11. Documenting

Portable Calibration

1 Select Test Equipment

2 Send/Receive

Select Test Equipment

Port *
USB

Test Equipment *
Filter
DPI610E-PC-14G -- 12121922

Get Connected Test Equipment

Cancel Calibration Reset Erase Test Equipment Memory

Continue

<< Previous Next >>

Note: If any errors connecting to the DPI 610E come up during this process, ensure the DPI 610E is plugged in and in (VCP) Virtual Communications Port mode. If the Druck Comms Server is not installed and running, the connection cannot be established.



Upon successful connection to the DPI 610E test equipment, select the **Test Equipment** drop down box to select the detected device denoted by its model and serial number.

Create the Test Equipment profile by filling the resulting popup screen and click **Create** to complete.

Create Test Equipment

Warning Test equipment not present in 4Sight2 application

Location : 4SightEnterprise ▾

Name * Pressure Calibrator	Serial Number 12121922	
Manufacturer Druck ▾	Model DPI610E-PC-14G ▾	
Calibrator Type * Secondary Standard ▾	Purchased * 10/11/2022 	Last Calibration 8/31/2022 
Calibration Interval 365 Days	Grace Period * 30 Days	
Firmware Version DK0492 V 02.00.01	Owner approver ▾	
Asset Number DRUCK007	Certificate Number	

Cancel Create

Select the **Continue** button to proceed.

Next, set the Ambient / Environmental parameters where the calibration will be done. This can still be modified on the DPI 610E at the start of the actual calibration.

Select the Calibration Test Procedure(s) to be sent to the DPI 610E and click **Send to Test Equipment**.

The process is completed with a **"Success"** indication under the **Operation Status** tab.

Portable Calibration

Select Test Equipment
2 Send/Receive

Send/Receive
<< Previous Next >>

DPI610E-PC-14G -- 12121922

ENVIRONMENT

Ambient Pressure *
1013 Unit *
mbar

Relative Humidity *
70 %RH

Temperature *
20 Unit *
°C

CALIBRATION(S)

(0) Total Items - (1) Selected

Selected (1)	Range	Tag	Location	Result Available ↓	Filename	Procedure	Operation Status
<input checked="" type="checkbox"/>	Filter	Filter	Filter	Filter	Filter		
<input checked="" type="checkbox"/>	0 to 2 bar		Test1	No	Pressure Transmitter_85	5 Points Up ⓘ	Success

Rows per page: 10 1 - 1 of 1 |< < > >|


Processed 1 of 1










Cancel Calibration
Close
Receive from Test Equipment
Send to Test Equipment

Note: tests that have special or Asian characters in the file name and notes cannot be uploaded to the 610E. Accented characters in the file name may be replaced by alternative characters without the accent symbols.

Chapter 11. Documenting

11.12.2 Running 4sight (Remote) Calibration Test Procedures







On the DPI 610E, select **REMOTE PROCEDURES** from the Procedures menu and tap again (or press the Enter  button if using the navigation keypad) to open.







Step 1	 	On the DPI 610E, select REMOTE PROCEDURES from the Procedures menu.
Step 2	   	<p>Select the desired Remote test procedures from the Remote Procedure Files screen.</p> <p>Use the  icon to show the next page of files.</p> <p>Use the  icon to set the order in which the files are listed.</p> <p>Tap on the row to open the procedure (or use the Enter  button in the Navigation pad).</p>

















There are two types of remote test procedures supported by the DPI 610E:






1. Linear or Proportional Test Procedure.
2. Switch Test Procedure.

11.13 Linear / Proportional Test Procedure




Step 1		<p>When a proportional test procedure is selected from the Remote Procedures menu, the test procedure file details are displayed as shown in the figure. At this point, only the Device Under Test (DUT) serial number information can be modified. Make sure that the details are correct, then select the Next  softkey to view the test information</p>
Step 2		<p>Make sure that all the test information is correct, then press the Play  softkey to start the calibration procedure. See Section 11.2.2, "How to create an Internal Procedure," on page 179.</p>
Step 3		<p>Examine and change, if necessary, the environment details and user ID. Press the Next  softkey to go to the next step.</p>














<p>Step 4</p>	 	<p>The next screen that appears shows WARNING NOTES and the PRE-CALIBRATION NOTES as configured in 4Sight2.</p> <p>This screen shows read-only information for the user doing the test.</p> <p>Select the Next  softkey.</p> <p>A popup message appears and requests confirmation that the Test details are correct. Select the OK button to remove this popup.</p>
<p>Step 5</p>		<p>The choice available now is either to go back to the test information by the use of the Back  softkey, or if the test details are acceptable, select the Proceed  softkey to show the test screen.</p>







Step 6	    	<p>On the test screen, follow the instructions on the top bar, to complete the calibration test procedure. Refer to Section 11.5 on page 196 for an example of how to run a test procedure.</p> <p>Note: See Section 11.3, “The Documenting Main Screen,” on page 192 for more information about the test screen and Section 11.4, “Documenting Settings,” on page 194 for more information about the additional settings available.</p>
Step 7	   	<p>After the last calibration data point has been logged, the Tick  softkey replaces the Add Test Point  softkey. The title bar will show Procedure complete with the overall test result status. Select the Tick  softkey to confirm completion of the calibration.</p>
Step 8	  	<p>This is the POST CALIBRATION screen that gives the necessary information to know after the calibration ends. This information is read-only and configured with 4Sight2.</p> <p>Select the Next  softkey to show the CALIBRATION REMARKS screen.</p>







Step 9		<p>Enter comments that relate to the calibration procedure just completed. This step is optional, and the CALIBRATION REMARKS field can be left blank. Maximum number of characters: 50.</p> <p>Select the Save  softkey to save the CALIBRATION REMARKS and continue.</p>
Step 10		<p>Note: When a test procedure is done on a new Asset for the first time, there will be no As-Found or As-Left results. When no As-Found or As-Left results are detected for a particular asset, the calibration data will be automatically saved as As-Found.</p> <p>If only an As-Found results file is detected, then at the end of the test procedure, the results will be automatically saved as As-Left.</p> <p>If both As-Found and As-Left results files already exist when the test procedure is run again, then the As-Left results file is overwritten.</p> <p>On the Test Procedure SUMMARY screen, the option to re-run the test procedure using the same test details and device under test (DUT) details is provided by using the Play  softkey.</p> <p>If you wish to exit, use the Back  softkey to return to the Remote Procedure menu.</p>





11.14 Switch Test Procedure

Step 1	 <p>1.12+mA+-+Switch</p> <p>> SERIAL NUMBER DR5637-6836A ✓</p> <p>LOCATION</p> <p>INPUT - SENSOR TYPE Gauge</p> <p>OUTPUT - SENSOR TYPE n/a</p> <p>AS FOUND ADJUST 20 DEC 2022</p> <p>AS LEFT PASS 20 DEC 2022</p> <p>04 MAY 2022 14:28 [Battery Icon]</p>	<p>When a Switch Test procedure is selected from the Remote Procedures menu, the test procedure file details are displayed as shown in the figure. At this point, only the Device Under Test (DUT) SERIAL NUMBER information can be modified.</p> <p>Make sure that the details are correct, then select the Next  softkey to view the test information.</p>
Step 2	 <p>1.12+mA+-+Switch 1/3</p> <p>START 50.000 bar</p> <p>END 0.000 bar</p> <p>REPEAT CYCLE 10</p> <p>SWITCH TRIP Falling</p> <p>INITIAL STATE Normally Closed</p> <p>04 MAY 2022 14:28 [Battery Icon]</p> <p><i>Step 2 procedure continues on next page</i></p>	<p>The Switch Test information is given by three screen pages that detail the following settings as configured in 4Sight2:</p> <p>START - required start-pressure value for the switch test before pressure ramp.</p> <p>END - required end-pressure value for the switch test.</p> <p>REPEAT CYCLE - number of consecutive switch test cycles required to be completed in the test procedure.</p> <p>SWITCH TRIP - the direction of pressure designed to cause a trip of the pressure switch.</p> <p>INITIAL STATE - the initial or normal state of the pressure switch in its normal operating pressure condition (deactuated state). This is either Normally Open or Normally Closed.</p>

<p>Step 2 Cont'd</p>	       	<p>ACTUATE POINT - expected actuating or trip point of the pressure switch DUT.</p> <p>DEACTUATE POINT - Expected deactuating or reset point of the pressure switch DUT.</p> <p>TOLERANCE (ACTUATE) - maximum deviation that determines if the actuating or trip pressure value of the pressure switch DUT is within specification (PASS) or out of specification (FAIL).</p> <p>TOLERANCE (DEACTUATE) - maximum deviation that determines if the deactuating or reset pressure value of the pressure switch DUT is within specification (PASS) or out of specification (FAIL).</p> <p>ADJUST (ACTUATE) - maximum deviation of the actuating or trip point pressure value within the PASS/FAIL tolerance which indicates that the pressure switch DUT is close to out of specification limits.</p> <p>ADJUST (DEACTUATE) - maximum deviation of the deactuating or reset point pressure value within the PASS/FAIL tolerance which indicates that the pressure switch DUT is close to out-of-specification limits.</p> <p>Check that all the test information is correct, then press the Play  softkey to start the calibration procedure. See Section 11.2.2, "How to create an Internal Procedure," on page 179.</p>
<p>Step 3</p>	  	<p>Examine and change, if necessary, the environment details and USER ID.</p> <p>Press the Next  softkey to go to the next step.</p>

<p>Step 4</p>		<p>??The next screen that appears shows WARNING NOTES and the PRE-CALIBRATION NOTES as configured in 4Sight2. This screen shows read-only information for the user doing the test.</p> <p>Select the Next  softkey to show the test screen.</p>
<p>Step 4</p>		<p>A popup message appears and requests confirmation that the Test details are correct. Select the OK button to remove this popup.</p>
<p>Step 5</p>		<p>The choice available now is either to go back to the test information by using the Back  softkey or the Proceed  softkey to show the test screen.</p>

<p>Step 6</p>	 	<p>On the test screen, follow the instructions on the top bar to complete the calibration test procedure. For a Switch Test procedure, the Ramp start and end pressure value will be displayed in the top bar.</p> <p>The top channel displays the Input pressure applied to the switch DUT and the bottom channel, displays the switch information. The live switch state is always displayed at the top of the switch channel. The switch test cycle status is shown at the top right corner of the switch channel. The switch test results show the following information for each test cycle:</p> <ul style="list-style-type: none"> • Actuation pressure value with PASS/FAIL status. • Deactuation pressure value with PASS/FAIL status. • Hysteresis value. <p>NOTE: See Section 11.3, “The Documenting Main Screen,” on page 192 for more information about the test screen and Section 11.4, “Documenting Settings,” on page 194 for more information about the additional settings available.</p> <p>To begin the Switch Test, make sure that the applied pressure is at the Ramp start value before selecting the Play  softkey.</p>
<p>Step 7</p>		<p>After the last switch test cycle has been completed, the Tick  softkey will replace the Add Test Point  softkey. The title bar will show Procedure complete with the overall test result status. Select the Tick softkey to confirm completion of the calibration.</p>

Step 8		<p>The POST CALIBRATION screen gives necessary information to know about after the calibration has been done. This information is read-only and configured within 4Sight2. Press the Next  softkey to go to the next screen.</p>
Step 9		<p>Enter required comments relating to the calibration procedure just completed into this screen. This step is optional: the CALIBRATION REMARKS field can be left blank. Maximum number of characters: 50.</p> <p>Select the Save  softkey to save the CALIBRATION REMARKS and continue</p>

Step 10

Summary: 1.12+mA+-+Switch

SERIAL NUMBER	DR5637-6836A
INPUT - SENSOR TYPE	Gauge
OUTPUT - SENSOR TYPE	n/a
> AS FOUND	ADJUST, 04 MAY 2022
AS LEFT	FAIL, 04 MAY 2022
04 MAY 2022 14:28 <div></div>	

The Procedure result **SUMMARY** screen. This screen shows details of the test procedure just completed.

Note: When a test procedure is done on a new Asset for the first time, there will be no **As-Found** or **As-Left** results. When no **As-Found** or **As-Left** results are detected for a particular asset, the calibration data will be automatically saved as **As-Found**.







If only an **As-Found** results file is detected, then at the end of the test procedure, the results will be automatically saved as **As-Left**.

If both **As-Found** and **As-Left** results files already exist when the test procedure is run again, then the **As-Left** results file is overwritten.

On the Test Procedure **SUMMARY** screen, use the **Play** softkey to do the test procedure again, using the same test details and device under test (DUT) details.





To exit, select the **Back** softkey to return to the **Remote Procedure** menu.

11.15 Making an adjustment on the Device Under Test (DUT)






Step 1		<p>If at the end of the test procedure, an adjustment is required. For example, if the end result of the test procedure is a Fail. Then it is possible to perform and verify an adjustment using the Analysis  softkey.</p>
Step 2		<p>Make the necessary adjustment to the DEVICE UNDER TEST (DUT) and check the output signal through its entire calibration range to ensure it is within spec before repeating the calibration test procedure. When the adjustment is complete, select the Back  softkey to return to the Procedure Summary screen.</p>
Step 3		<p>The test procedure may now be done again after adjustment. Select the Play  softkey or icon to do this.</p>

11.16 How to View Test Results

Tap on the required result row (e.g., **As-found** or **As-Left**) to see a screen of results immediately after the test procedure is finished.

Summary: 2022-MAY04_14-28-03		
ASSET ID*	DRU099	
INPUT - SENSOR TYPE	Gauge	
OUTPUT - SENSOR TYPE	n/a	
> AS FOUND	ADJUST, 04 MAY 2022	
AS LEFT	PASS, 04 MAY 2022	
04 MAY 2022 14:28 		

Results can also be viewed when the test procedure is selected and then the relevant test result i.e. As-Found or As-Left.

Step 1	Summary: 2022-MAY04_14-28-03		<p>If at the end of the test procedure, an adjustment is required. For example, if the result of the test procedure is a Fail. Then it is possible to perform and verify an adjustment using the Analysis  softkey.</p>
	ASSET ID* DRU099		
	INPUT - SENSOR TYPE Gauge		
	OUTPUT - SENSOR TYPE n/a		
	> AS FOUND ADJUST, 04 MAY 2022		
	AS LEFT PASS, 04 MAY 2022		
	04 MAY 2022 14:28 		

Step 2

Remote Procedure Files 1-5/9

> 1.12+mA+-+Switch		
100 mbar-A-SW-NO-R-1		
16.12.3+-10+Cycle+Switch_1039		
16.9.7+-Long+Cal+Notes_1031		
2.2+Pressure+-+mV_680		

04 MAY 2022 14:28



Use the icon to show the next page of files.

Use the icon to set the order in which the files are listed.

NOTE: Visual indication of test results are presented in the **Remote Procedures** menu next to each procedure filename. If no icons are present, it means no results are present for that test procedure. The first icon represents the **As-Found** result while second icon represents the **As-Left** result.

✓ - PASS INDICATION

✗ - FAIL INDICATION

- ADJUST INDICATION

100 mbar-A-SW-NO-R-1

> SERIAL NUMBER	DR5637-6836A
LOCATION	
INPUT - SENSOR TYPE	Gauge
OUTPUT - SENSOR TYPE	Gauge
AS FOUND ADJUST 20 DEC 2022	AS LEFT PASS 20 DEC 2022

04 MAY 2022 14:28

Step 3

100 mbar-A-SW-NO-R-1 001-002/002

AS FOUND
04-05-2022, 00:00:00
mbar, mbar, % Span

ADJUST







#	Exp. In	Act. In	Act. Out	Error	Pass/Fail
01	31928.00	25423.00	28520.00	6902.000	ADJUST
02	24596.00	3737.000	13261.00	10195.00	FAIL



04 MAY 2022 14:28









The calibration test procedure results for Proportional Test Procedure show the following:

- Test Procedure/Asset ID
- Result type - As-Found or As-Left
- Date/Time - the date and time stamp the calibration procedure was completed
- Input and Output measurement units
- Error type
- Test point #
- Expected input of each test point
- Actual input of each test point
- Calculated error or deviation
- Pass or Fail result status.

<p>Step 4</p>		<p>The calibration test procedure results for Switch Test Procedure show the following:</p> <ul style="list-style-type: none"> • Test Procedure/Asset ID • Result type - As-Found or As-Left • Date/Time - the date and time stamp the calibration procedure was completed • Switch Test Cycle number • Pressure measurement units • Initial Switch State • Actuation and Deactuation Pressure • Actuation and Deactuation Error • Actuation and Deactuation Result • Pass or Fail status for each test cycle. <p>NOTE: For Switch Test with multiple switch cycles, use the Page Down  softkey to view the test results of each cycle.</p>
<p>Step 5</p>	 <p><i>Step 5 continues on next page</i></p>	<p>To see CALIBRATION REMARKS or POST CALIBRATION NOTES that relate to the test, select the Clipboard  softkey from the results screen and select the desired option.</p> <p>Use the Page Down  softkey and Back  softkey to move between screen pages.</p>

Step 5 Cont'd	<div>100 mbar-A-SW-ND-R-1</div> <div>CALIBRATION REMARKS</div> <div>saved remarks</div>	
	<div>04 MAY 2022 14:28 </div>	

11.17 Deleting Remote Procedure Files

Step 1	 	<p>To delete Remote Procedure files, use the File System  softkey via the Dashboard. Select the Procedures folder and then the Remote sub-folder.</p>
Step 2		<p>From the list of procedure files, click on the desired file to delete and select the Single Delete  softkey to delete this file. To delete all files present, select the Delete All  softkey.</p>

11.18 Uploading Test Results To 4Sight2

To upload test results back to 4Sight2:

From the relevant Calibration screen in 4Sight2, select the desired calibration and click **Receive from Test Equipment**. Successful upload of results will be indicated with the Success text in the Operation Status area.

Portable Calibration

Select Test Equipment
2 Send/Receive

Send/Receive
<< Previous Next >>

DPI610E-PC-14G -- 12121922

ENVIRONMENT

Ambient Pressure *
1013 Unit *
mbar

Relative Humidity *
70 %RH

Temperature *
20 Unit *
°C

CALIBRATION(S)

(0) Total Items - (1) Selected

Selected (1)	Range	Tag	Location	Result Available ↓	Filename	Procedure	Operation Status
<input checked="" type="checkbox"/>	Filter	Filter	Filter	Filter	Filter	Filter	Filter
<input checked="" type="checkbox"/>	0 to 2 bar		Test1	Yes	Pressure Transmitter_85	5 Points Up ⓘ	Success

Rows per page 10 1 = 1 of 1 |< < > >|

Processed 1 of 1

Cancel Calibration
Close **Receive from Test Equipment** Send to Test Equipment

To review results, click on the toggle icon in the left-hand section of the screen to change from **Send/Receive** to **Review** mode.

- Dashboard
- Calibration
 - Portable Calibration
 - Manual Calibration
 - Real Time Calibration
- Assets
- Routines
- Procedures
- Test Equipment
- Resources
- System Management
- Help

Q

☐ All
Sort by
Test Name

Review ☒
Send/Receive ☐


4

0 to 2 bar
 Due on 07-Oct-2022
 Pressure Transmitter_85

▼

Chapter 11. Documenting

Select the calibration file to reveal details of the test and its results.



For additional information on how to analyse or process test data within 4Sight2, please refer to the 4Sight2 User Manual **123M3138**.

12. HART

12.1 HART® Application

The DPI 610E supports the HART® (Highway Addressable Remote Transducer) communication protocol and allows basic HART operation and configuration on HART supported devices. The HART bi-directional communications technology works as a master/slave protocol and when connecting the DPI 610E to the HART device, the DPI 610E acts as the master and the HART device, the slave. The DPI 610E supports commonly used functions from the Universal and Common Practice commands specified in HART revision 5, 6 and 7.



The HART function is only available on **CH2**. The function uses the current loop signal for its communication: the DPI 610E can provide a 24 V loop power supply to the HART Device if required. The DPI 610E also offers a 250-ohm HART resistor that provides the voltage drop required for the HART communication.






The DPI 610E can be used to communicate with HART devices as a:



Primary Master - the DPI 610E starts and controls all communications. The field device (slave) uses each command from the master device to make a change and/or send data back.

Secondary Master - the DPI 610E connects to an existing HART communications network. The Secondary Master communicates with the field device between Primary Master messages.





12.1.1 Starting the HART application (1st Method)

Step 1		<p>From the Calibrator screen: select the channel 2 CH2 Setup (either tap the screen icon or press the softkey.)</p> <p>Note: The HART function is only available on CH2.</p>
Step 2		<p>Select FUNCTION from the CH2 Setup screen.</p>


Step 3		<p>Select the Page Down  softkey to view the second page of CH2 functions.</p>
Step 4		<p>Select HART in the FUNCTION column. Choose the desired DIRECTION (Measure or Master). Select the loop POWER option (Off to use an external power supply or 24V to use the DPI 610E internal power supply).</p> <p>Select the Tick  icon to confirm the selection and configure the instrument.</p>
Step 5		<p>In the CH2 Setup screen, the HART function is displayed. The configuration status is also shown (i.e. HART device connected or disconnected). See Section 12.2 on page 234 for Configuration details.</p> <p>The 250-ohm HART resistor option allows the DPI 610E to provide the resistor internally when enabled (checkbox ticked). If the instrument is connected directly to a network, there must be a 250-ohm resistor connected in series with the loop power supply and the HART device. Here the HART resistor should be disabled in the setup (checkbox unticked).</p>




Step 6		<p>Note: the 250-ohm HART resistor is important in allowing communication with the HART device, as it provides enough impedance in the signal loop for the HART signal to develop.</p> <p>Select the Back  softkey to return to the Calibrator screen.</p> <p>HART is configured in CH2.</p>
--------	---	---

12.1.2 Starting the HART application (2nd Method)


Step 1		<p>From the Dashboard select the HART icon by tapping on the HART icon or using the keypad to select the icon and the OK button to launch the application. This second method is a quicker way to configure the channel with HART. However, the HART application will use the default or last saved configuration. If different settings are required, then use Method 1 to change as desired.</p>
Step 2		<p>Tap in the HART bottom screen area to enlarge the window and show the CH2 icon. Select this CH2  icon to show the CH2 Setup screen. You can follow the procedure in Section 12.1.1 on page 230 from step 2 forward to configure the HART function.</p> <p>Select the Configuration  softkey to establish communication between the instrument and the HART device.</p>

12.1.3 HART device electrical connection

Use the **Help**  button on the DPI 610E, to show information about the different electrical connections shown below. It could be necessary to use this button if this manual is not available.

 <p>The diagram shows the DPI 610E terminals on the left: mA+, Vin, mA-, and out. The mA+ terminal is connected to the mA- terminal through a switch. The mA- terminal is connected to the out terminal. The out terminal is connected to the TRANSMITTER. The TRANSMITTER is connected to the HART RESISTOR. The HART RESISTOR is connected to the mA+ terminal. The circuit is labeled with mA+, V_{in}, mA 24V, V_{out}, and TRANSMITTER. A note states: * IF HART RESISTOR NOT IN EXTERNAL LOOP. HART RESISTOR IN DPI 610E MUST BE ENABLED.</p>	<p>HART with internal 24 V loop power enabled. This is when the menu selection is: HART > Measure > 24V (see Step 4 page 231).</p>
 <p>The diagram shows the DPI 610E terminals on the left: mA+, Vin, mA-, and out. The mA+ terminal is connected to the mA- terminal through a switch. The mA- terminal is connected to the out terminal. The out terminal is connected to the TRANSMITTER. The TRANSMITTER is connected to the HART RESISTOR. The HART RESISTOR is connected to the +VE terminal of the 24 V LOOP POWER SUPPLY. The -VE terminal of the 24 V LOOP POWER SUPPLY is connected to the mA+ terminal. The circuit is labeled with mA+, V_{in}, mA 24V, V_{out}, TRANSMITTER, HART RESISTOR, +VE, 24 V LOOP POWER SUPPLY, and -VE. A note states: * IF HART RESISTOR NOT IN EXTERNAL LOOP. HART RESISTOR IN DPI 610E MUST BE ENABLED.</p>	<p>HART with external loop power (internal loop power disabled). This is when the menu selection is: HART > DIRECTION > Measure > Off (see Step 4 page 231).</p>
 <p>The diagram shows the DPI 610E terminals on the left: mA+, Vin, mA-, and out. The mA+ terminal is connected to the mA- terminal through a switch. The mA- terminal is connected to the out terminal. The out terminal is connected to the TRANSMITTER. The TRANSMITTER is connected to the HART RESISTOR. The HART RESISTOR is connected to the +VE terminal of the 24 V LOOP POWER SUPPLY. The -VE terminal of the 24 V LOOP POWER SUPPLY is connected to the mA+ terminal. The circuit is labeled with mA+, V_{in}, mA 24V, V_{out}, TRANSMITTER, HART RESISTOR, +VE, 24 V LOOP POWER SUPPLY, and -VE.</p>	<p>HART when connected to an external current loop. This is when the menu selection is: HART > DIRECTION > Master (see Step 4 page 231).</p>

12.2 HART Device Configuration

Step 1	<div></div>	<p>When the HART device has been physically connected to the DPI 610E (electrical connection), the loop current measured (Measure mode) or "secondary reading" of the connected HART device (Master mode), which will normally be the demanded current by the DPI 610E, is displayed as the secondary reading in the CH2 window. To establish communication between the instrument and the HART device, select the Configuration  softkey.</p> <p>Note: When the HART device has no communication with the DPI 610E, an animated set of dashed lines (-----) appears in the primary reading area.</p>
Step 2	<div></div>	<p>Alternatively, the Configuration menu can be accessed from the CH2 Setup screen.</p> <p>Note: If the HART application is already running, maximize the CH2 window to access the CH2 Setup softkey.</p>
Procedure continues with Step 3 on next page		

Step 3

Device Poll

☒ **USE ADDRESS 0 ONLY**

☐ **FIND FIRST DEVICE**

☐ **CHOOSE POLL ADDRESS** 3

☐ **DEFINE CUSTOM RANGE** 5-7

04 MAY 2022 14:28



Device Poll

☐ **USE ADDRESS 0 ONLY**

☐ **FIND FIRST DEVICE**

☒ **CHOOSE POLL ADDRESS** 3

☐ **DEFINE CUSTOM RANGE** 5-7

04 MAY 2022 14:28



Device Poll

POLL ADDRESS 3

123

456

789

.0+/-

×

CLR

14 JUN 2021 17:59



The connected **HART** device can be configured with its unique Poll Address. The configuration screen provides options for the **HART** device polling. Select one of the following Device Poll methods to use:

1. **USE ADDRESS 0 ONLY** - Searches for any connected devices with Poll Address 0 only.
2. **FIND FIRST DEVICE** – Searches the full Poll Address range (0 to 63) and identifies the first device found.
3. **CHOOSE POLL ADDRESS** – Searches a single user specified Poll Address.
4. **DEFINE CUSTOM RANGE** – Searches a user specified Poll Address range.

When the **CHOOSE POLL ADDRESS** is selected, the Poll Address number to search must be entered.

The default is 0.
To edit the Address value, select the **Edit** softkey and enter the desired

value. Press the **Tick** softkey to accept and the **Back** softkey to return to the **Device Poll** screen.

Note: A valid Poll Address value must be between 0 and 63).

Step 3 procedure continues on next page

Step 3
Cont'd

Device Poll


☐ USE ADDRESS 0 ONLY


☐ FIND FIRST DEVICE


☐ CHOOSE POLL ADDRESS 3

☒ DEFINE CUSTOM RANGE 5-7

04 MAY 2022 14:28








Poll Address Range

> ADDRESS RANGE START 5

ADDRESS RANGE STOP 7

04 MAY 2022 14:28



Device Poll


☐ USE ADDRESS 0 ONLY


☒ FIND FIRST DEVICE

☐ CHOOSE POLL ADDRESS 3




☐ DEFINE CUSTOM RANGE 5-7

04 MAY 2022 14:28






When the **DEFINE CUSTOM RANGE** option is selected, the Poll Address range must be specified. The default is 0 to 63.

To edit the Address range, select the **Edit**  softkey and enter the desired **START** and **END** value. Press the **Tick**  softkey to accept and the **Back**  softkey to return to the **Device Poll** menu.

Note: A valid Poll Address range must be between 0 and 63.

Once the desired Poll method has been set up, select the **Search**  softkey to begin.

Step 3 procedure continues on next page

Step 3
Cont'd

Device Poll: Scanning

POLL ADDRESS 0

Poll Search Criteria: Address 0

POLL	TAG	DESCRIPTOR
> 0	PT_1234567	WIKA PRESSURE

04 MAY 2022 14:28



In the **Device Poll** screen the following information is available:

1. In the Title bar, the Device Poll status is provided i.e., Scanning or Scan Complete.
2. Poll Address being currently searched.
3. Poll Search method or criteria.
4. Search result table which displays the Poll Address, Tag and Descriptor of the device when successfully found. It can display up to four found devices.

The scan can be aborted at any time if necessary, by using the **Stop** softkey.

Restart the scan by selecting the

Search softkey.

Step 4

Device Poll: Scan Complete

POLL ADDRESS 0

Poll Search Criteria: Address 0

POLL	TAG	DESCRIPTOR
> 0	PT_1234567	WIKA PRESSURE

04 MAY 2022 14:28



When the scan is complete or when the scan is aborted, any detected **HART** device(s) will be displayed in the table. If more than one device is displayed, select the desired device to connect to, by tapping the device details or using the navigation keypad.

Select the **Tick** softkey to connect to the selected device.

Device Poll: Scan Complete

POLL ADDRESS 0

Poll Search Criteria: Address 0

POLL	TAG	DESCRIPTOR
> 0	PT_1234567	WIKA PRESSURE

04 MAY 2022 14:28

CONNECT TO DEVICE

Connect to Device on Poll Address 0

OK Cancel



Select **OK** to connect to the selected device and return to the **Calibrator** screen or **CANCEL** to return to the **Device Poll** configuration screen.

Step 4 continues on next page

Chapter 12. HART

Step 4
Cont'd

The screenshot displays a device configuration interface with two main sections. The top section shows a pressure gauge labeled 'INT Pressure' with a large reading of '21.4607 bar'. Below the reading is a scale bar from '-FS' to '+FS' and the text 'FS: 35.0000 Gauge bar'. The bottom section shows another pressure gauge with a large reading of '5.0192 bar'. Below this reading is the text 'FS: 55.0000 Addr: 0 bar'. To the right of the gauges, there are several status indicators: 'CH1' with a gear icon, a pause button icon, 'HART' with a sine wave icon, and a curved arrow icon. At the bottom of the screen, there is a timestamp '04 MAY 2022 14:28' and a battery level indicator.

CH1

21.4607 bar

FS: 35.0000 Gauge bar





HART

5.0192 bar


FS: 55.0000 Addr: 0 bar

04 MAY 2022 14:28

12.3 HART Dashboard

Step 1		<p>From the Dashboard: select the Calibrator icon. The Calibration screen will appear: the CH2 is replaced by the HART icon.</p> <p>Note: for the HART softkey to appear in the next screen, the HART device must be connected successfully to the DPI 610E. See previous section.</p>
Step 2		<p>From the Calibrator screen: select the HART channel  icon (either tap the screen icon or press the softkey.)</p>
Step 3		<p>A screen of HART options appears. These options are described in the rest of this chapter.</p>

12.3.1 Unique ID



HART: Unique ID	
MANUFACTURER ID	Loading ...
DEVICE TYPE	Loading ...
DEVICE REVISION	0
PREAMBLES	0
SOFTWARE REVISION	0
HARDWARE REVISION	0
UNIVERSAL COMMAND REVISION	0
HART DEVICE ID	0


04 MAY 2022 14:28 

Figure 12-1: Unique ID screen

The **Unique ID** screen gives identity information about the connected **HART** device. This **HART** command gets the long address of the device plus other manufacturer information available and shows it in this screen.

The **PREAMBLES** data relates to the code that identifies the start and end of a data packet.

Note: this is a read-only screen.

12.3.2 Device Information



HART: Device Information	
> TAG	PT_1234567 
POLL ADDRESS	0 
DESCRIPTION	WIKI PRESSURE 
MESSAGE	TRIAL VER 
DATE	Loading ... 
PREAMBLES	0 

04 MAY 2022 14:28 

Figure 12-2: Device Information screen

The **HART: Device Information** screen displays editable information about the device. The information options available are shown in the Figure 12-2 above.

To edit any of the device information, select the option and enter the desired value or text. Select the **Tick** ✓ softkey to confirm and write this new change to the device

- Tag.


- Poll Address
- Description
- Message.

- Date.

Chapter 12. HART

- Preambles

The **PREAMBLES** data relates to the code that identifies the start and end of a data packet.

Note: The Device Information screen options are all user editable as indicated by the mini pencil  icon at the end of each option line.

12.3.3 Measure Variables




Figure 12-3: Measure Variables screen

This screen shows the following variables:

- HART PV (Primary variable)
- Loop Current (Output by HART device)
- % Range (Percentage - the current PV reading of the PV range)
- CH1 Primary (Primary reading on CH1)
- CH2 MA (Loop current measured by the DPI 610E).

12.3.4 Signal Condition






Figure 12-4: Signal Condition screen

This screen shows the following variables (variables with a pen  icon can be edited):

- PV Units (Measurement units the primary variable is displayed)
- PV LRV (Primary variable Lower Range Value)

- PV URV (Primary variable Upper Range Value)
- PV Damping (Primary variable damping value in seconds)
- PV Transfer Function (Primary function transfer function selection code)
- Write Protect (Write protect code).

12.3.5 Sensor Information

HART: Sensor Information	
SERIAL NUMBER	5634521
SENSOR UNITS	bar
LRL	0.000000
URL	10.000000
MINIMUM SPAN	0.010000
04 MAY 2022 14:28 	




Figure 12-5: Sensor Information screen

This screen shows the following variables:

- Serial Number
- Sensor Units
- LRL (Lower Range Limit)
- URL (Upper Range Limit)
- Minimum Span.

Note: This is a read-only screen.

12.4 HART Service Methods




Figure 12-6: Service Methods screen


The Service Methods available on the DPI 610E are:






- 1. **LOOP TEST**
- 2. **D/A OUTPUT TRIM** (page 246)
- 3. **PRESSURE ZERO TRIM** (page 250).

12.4.1 LOOP TEST

This method sets the output of the **HART** device to a user specified analog (current) value. It is useful in testing the integrity of the current loop and makes sure the system is functioning correctly. With the DPI 610E Loop test method, the user can force an output current between 4 and 20 mA for normal transmitter operation or <3.6 mA and >21 mA to verify failure alarm indication in the device and verify the A to D Trim. The actual current output from the HART device is measured by the mA input of the DPI610E calibrator.

To output a current:

Step 1		<p>Select LOOP TEST from the HART: Service Methods screen.</p> <p>In the Loop Test screen, select the Edit  softkey.</p>
--------	--	---

Step 2		<p>Enter the required output value and select the Tick ✓ softkey.</p>
Step 3		<p>On this screen, the current measured by the DPI 610E appears as the result of the forced current output from the HART device.</p> <p>Note: The signal measured by the DPI 610E is indicated by the , while that measured by the HART device is indicated by the  icon.</p>
Step 4		<p>Repeat as required with all the desired current output values and check the measured current value. To exit the loop test, select the Back ↶ softkey.</p>








Chapter 12. HART

12.4.2 D/A OUTPUT TRIM







The D/A trim will trim the analog current output for the HART device under test to be consistent with the mA measure input of the DPI610E calibrator. If required, a trim is performed at the low value point and/or the high value point which adjusts the transmitters digital to analog converter.





To perform a D/A Trim:

Step 1		<p>Select D/A OUTPUT TRIM from the HART: Service Methods screen (See Figure 12-6 on page 244.)</p> <p>The screen on the left is the first part of the D/A trim procedure which focuses on the Low (value) trim.</p> <p>The default Low Trim value is 4 mA. This value can be edited if required by selecting the Edit softkey (Step 2). If no change is required, select the Next softkey to proceed (Step 3).</p>
Step 2		<p>Enter the required Low Trim value and select the Tick softkey to confirm this value.</p>
Step 3		<p>The Low Trim value has been applied and the measured value now appears.</p> <p>Note: The signal measured by the DPI 610E is indicated by the icon , while that measured by the HART device is indicated by . Make sure that the reading is stable. To perform the trim at this point, select the Trim softkey.</p>
Step 3 continues on next page		

Step 3 Cont'd		<p>Select OK in the popup message window to accept the Trim. Or select CANCEL to return to the previous step.</p>
Step 4		<p>When the Low trim is complete, select the Next  softkey to proceed to the High Trim procedure or select the Back  softkey to exit.</p>
Step 5		<p>The second part of the D/A trim procedure focuses on the High (value) trim. The default High Trim value is 20 mA. This value can be edited if required by selecting the Edit  softkey (Step 6). If no change is required, select the Next  softkey to proceed (Step 7).</p>
Procedure continues on next page		

Chapter 12. HART

Step 6		<p>Enter the required High Trim value and select the Tick ✓ softkey to confirm.</p>
Step 7		<p>The High Trim value has been applied and the measured value is now displayed. Note: the signal measured by the DPI 610E is indicated by the icon , while that measured by the HART device is indicated by . Make sure that the reading is stable. To perform the trim at this point, select the Trim  softkey.</p>
Step 8		<p>Select OK in the popup message window to accept the Trim, or select Cancel to return to the previous step. The High Trim is complete, which finishes this stage of the D/A trim procedure. The final step of the procedure is to verify that the D/A trim adjustment is sufficient.</p>
Procedure continues on next page		








Step 9		<p>Select the Verification softkey to test if the adjustment has been sufficient.</p>
Step 10		<p>In the Verification screen, use the Edit  softkey to enter test current output values between 0 and 24 mA and check the measured values at each point.</p> <p>To exit the Verification screen, use the Back  softkey.</p>

Chapter 12. HART

12.4.3 PRESSURE ZERO TRIM

A Zero Trim is a method to cancel out zero-shift that could arise from sensor zero drift or change in installation orientation. It allows for the characterization data to be adjusted by correcting the zero (pressure) value when a “zero” input is applied.

Note: Zero trim should only ever be applied to Gauge or Differential pressure sensors.

Step 1		<p>Select PRESSURE ZERO TRIM from the HART: Service Methods screen (See Figure 12-6 on page 244). Make sure the HART device has a secure process connection to the DPI 610E.</p> <p>Apply 0 pressure using the pump/volume adjuster on the instrument or vent the system. Wait and make sure the reading is stable.</p> <p>Note: the signal measured by the DPI 610E is indicated by the icon , while that measured by the HART device is indicated by .</p> <p>Select the Trim  softkey.</p>
Step 2		<p>Select OK in the popup message window to accept the Trim, or select Cancel to return to the previous step.</p>
Step 3		<p>When the Zero Trim is complete, use the Back  softkey to exit or repeat the Trim if required.</p>





12.5 HART Error and Message Codes

Error Code	Description
0	Success
1	Undefined Error
2	Invalid Selection
3	Passed Parameter Too Large
4	Passed Parameter Too Large
5	Too few data bytes received
6	Device-specific Command Error
7	In Write Protect Mode
8-14	Multiple Meaning Warning
16	Access Restricted
17	Invalid Device Variable Index
18	Invalid Unit Code
19	Device Variable Index Not Allowed
20	Invalid Extended Command Number
21	Invalid I/O Card Number
22	Invalid Channel Number
23	Sub-device Response Too Long
24-27	Reserved Warning
28	Multiple Meanings Error
32	Device is Busy
33	Delayed Response Initiated
34	Delayed Response Running
35	Delayed Response Dead
36	Delayed Response Conflict
37-59	Reserved Error
60	Payload too Long
61	No Buffer Available
62	No Alarm/Event Buffers Available
63	Priority too low
64	Command Not Implemented
65-72	Multiple Meanings Error
96-111	Reserved Warning




Table 12-1: HART Error Codes

13. Instrument Calibration


13.1 How to show the Instrument Calibration screen

Step 1		<p>Select the Settings icon  on the Dashboard.</p> <p>Tap on the icon or press the softkey on the right of icon.</p>
Step 2		<p>Select ADVANCED at the bottom of the General Settings screen.</p> <p>Tap on ADVANCED or use the Navigation Pad to move to bottom row</p> <p>and press the Pad's Enter  key to select.</p>

How to show the Instrument Calibration screen

Step 3		<p>Use the onscreen keypad in the Advanced Menu screen to enter the PIN number (4321 is the default value until a custom PIN is selected) and then select the Tick ✓ icon.</p>
Step 4		<p>In the Advanced Menu screen, select CALIBRATION. Refer to Chapter 5, “Advanced Menu” on page 53, for instructions on how to use the other Advanced Menu options.</p>
Step 5		<p>Select INSTRUMENT in the Calibration screen to show the Instrument Calibration menu.</p>

Chapter 13. Instrument Calibration

Step 6		The different Instrument Calibration options are now available.
--------	---	--

13.1.1 The Instrument Calibration screen options

Option	Description
PERFORM CALIBRATION	Calibrate the instrument
INTERNAL PRESSURE SENSOR STATUS	View internal pressure sensor details
SET CALIBRATION DATE & INTERVAL	Set instrument date and interval
BACKUP CALIBRATION	Back up current calibration status
RESTORE CALIBRATION	Restore instrument to a previous calibration status
RESTORE FACTORY CALIBRATION	Return to the factory (default) calibration status

Note: The information in this chapter is for calibrating Internal and External sensors. The configuration of external sensors, to enable the DPI 610E to recognise and use external sensors, is explained in Chapter 8, “External Sensors” on page 141.

13.2 PERFORM CALIBRATION

The following functions are available in the **Perform Calibration** screen:

Function	Direction	Range
Current	Measure	20 mA 55 mA
	Source	24 mA
Voltage	Measure	20 V 30 V
	Source	10 V
Millivolts	Measure	200 mV 2000 mV
Pressure	Measure	Dependent on sensor fitted
Barometer	Measure	750 to 1150 mbar

Note: To access the **Perform Calibration** screen (Figure 13-1), select **PERFORM CALIBRATION** from the **Instrument Calibration** screen.

Note: The **Filter** process option must be **ON** for sensor calibration, see Section 6.3.3 on page 116 for the procedure.







Figure 13-1: Perform Calibration screen




13.2.1 Calibration - Electrical Functions

The editing of **Current**, **Voltage** and **Millivolts** options is similar in procedure. Therefore, on the following pages the procedure used for editing Current variables is the same as for Voltage and Millivolts. The **Pressure** and **Barometer** options are described separately.




Chapter 13. Instrument Calibration











To calibrate an electrical function (Current Measure is used in this example), make sure the electrical connection between the DPI 610E and the external calibrated equipment is correct (See Section 6.2.9 on page 89 for Current Measure electrical connection diagram).




Step 1		Select PERFORM CALIBRATION from the Instrument Calibration menu.
Step 2		Select a FUNCTION option (e.g., Current).
Step 3		Select a DIRECTION option if applicable (e.g., Measure).

Step 4		<p>Select a RANGE option if applicable (e.g., 20 mA).</p> <p>Select ✓ to confirm.</p>
Step 5		<p>This screen has three sections.</p> <p>The top two sections give:</p> <ul style="list-style-type: none"> The reference reading from external calibrated equipment. The measured (or sourced) reading from the DPI 610E. <p>The bottom section gives the following information:</p> <ol style="list-style-type: none"> Function minimum range (or negative full-scale) value. Function maximum range (or positive full-scale) value Calibration procedure step status (visual status boxes and text status) User instructions for each step of the procedure.
Step 6		<p>To start the calibration, apply nominal negative full-scale Current (approximately -20 mA) as per the displayed instruction. This is the Calibration point 1.</p> <p>When the measured Current reading is stable, select the Next → icon to continue.</p> <p>Note:</p> <ul style="list-style-type: none"> All electrical measure functions require a 3-point calibration. Current Source function requires a 2-point calibration. Voltage source function requires a 1-point calibration.

Chapter 13. Instrument Calibration




Step 7		<p>Enter the REFERENCE VALUE 1 value as displayed on the external calibrated equipment. Press the Tick ✓ softkey to confirm and return to the Calibration screen.</p>
Step 8		<p>Press the Next → softkey to complete Calibration point 1 and proceed to Calibration point 2.</p>
Step 9		<p>Apply Steps 6 to 8, but this time begin by applying the nominal zero Current (approximately 0 mA) to the DPI 610E. This completes Calibration point 2.</p>




Step 10	 	<p>Once again, apply Steps 6 to 8, but this time begin by applying the positive full-scale Current (approximately 20 mA) to the DPI 610E.</p> <p>Press the Next  softkey to complete Calibration point 3.</p>
Step 11	 	<p>A message window appears, requesting confirmation to perform the calibration adjustment based on the calibration points used in the procedure.</p> <p>Select OK to apply the calibration adjustment.</p> <p>Otherwise, select the Cancel button to return to the Calibration screen.</p>
Step 12	 	<p>If OK is selected, the CALIBRATION COMPLETE message appears in the status box, to confirm the adjustment has been made.</p> <p>At this stage, there are three icons for three ways to proceed. These are:</p> <ul style="list-style-type: none">  VERIFICATION softkey navigates to the Verification screen (see Step 13).  RESTART softkey allows the calibration procedure to be restarted if a repeat calibration is required.  BACK softkey exits the calibration procedure and returns the user to the Perform Calibration menu screen.

Step 13		<p>The Verification mode shows live reference and measured (or sourced) values. Here, different values or points within the measured (or sourced) range can be checked to verify the adjustment is satisfactory. Once verification is complete, select the Back  icon to exit the calibration procedure or select the Restart  softkey to repeat the calibration.</p>
---------	---	---






13.2.2 Calibration - Internal Pressure Sensor








To calibrate the internal pressure sensor of the DPI 610E, make sure the correct pressure connection is made from the test port and the external calibrated pressure source. This sensor calibration should only be done by approved service centres and personnel.

Step 1		<p>Select PERFORM CALIBRATION from the Instrument Calibration menu.</p>
Step 2		<p>Select Pressure function. Select  to confirm.</p>

Step 3		<p>This screen has three sections. The top two sections give:</p> <ul style="list-style-type: none"> • The reference reading from external calibrated equipment. • The measured (or sourced) reading from the DPI 610E. <p>The bottom section gives the following information:</p> <ol style="list-style-type: none"> 1. Function minimum range (or negative full-scale) value 2. Function maximum range (or positive full-scale) value 3. Calibration procedure step status (visual status boxes and text status) 4. User instructions for each step of the procedure.
Step 4		<p>To start the calibration, apply nominal negative full-scale or zero pressure as per the displayed instruction. This is Calibration point 1.</p> <p>When the measured Pressure reading is stable, select the Next icon to continue.</p> <p>Note: Pressure sensor calibration requires two valid calibration points.</p>
Step 5		<p>Enter REFERENCE VALUE 1 as displayed on the external calibrated equipment. Press the Tick ✓ softkey to confirm and return to the Calibration screen.</p>

Chapter 13. Instrument Calibration



Step 6		<p>Press the Next  softkey to complete Calibration point 1 and proceed to Calibration point 2.</p>
Step 7		<p>Apply Steps 4 to 6, but this time begin by applying the nominal positive full-scale pressure to the DPI610E.</p> <p>Press the Next  softkey to complete Calibration point 2 and proceed to Calibration point 3.</p>
Step 8		<p>A message window appears, requesting confirmation to perform the calibration adjustment based on the calibration points used in the procedure. Select OK to apply the calibration adjustment. Otherwise, select the Cancel button to return to the Calibration screen.</p>





<p>Step 9</p>		<p>If OK is selected, the CALIBRATION COMPLETE message appears in the status box, to confirm the adjustment has been made.</p> <p>At this stage, there are three icons for three ways to proceed. These are:</p> <ul style="list-style-type: none">  VERIFICATION softkey navigates to the Verification screen (see Step 13).  RESTART softkey allows the calibration procedure to be restarted if a repeat calibration is required.  BACK softkey exits the calibration procedure and returns the user to the Perform Calibration menu screen.
<p>Step 10</p>		<p>The Verification mode shows live reference and measured (or sourced) values.</p> <p>Here, different values or points within the measured (or sourced) range can be checked to verify the adjustment is satisfactory.</p> <p>Once verification is complete, select the Back  icon to exit the calibration procedure or select the Restart  softkey to repeat the calibration.</p>

Chapter 13. Instrument Calibration







13.2.3 Calibration – Internal Barometer










To calibrate the internal barometer sensor of the DPI 610E, make sure the correct pressure connection is made from the barometer port and the external calibrated pressure source. This sensor calibration should only be done by approved service centres and personnel.

Step 1		Select PERFORM CALIBRATION from the Instrument Calibration menu.
Step 2		Select Barometer function. Select ✓ to confirm.

<p>Step 3</p>		<p>The Calibration - Barometer screen has three sections.</p> <p>The top two sections give:</p> <ul style="list-style-type: none"> • The reference reading from external calibrated equipment • The measured (or sourced) reading from the DPI 610E. <p>The bottom section gives the following information:</p> <ol style="list-style-type: none"> 1. Function minimum range (or negative full-scale) value 2. Function maximum range (or positive full-scale) value 3. Calibration procedure step status (visual status boxes and text status) 4. User instructions for each step of the procedure. <p>To start the calibration, apply nominal negative full-scale or zero pressure as per the displayed instruction. This is Calibration point 1.</p> <p>When the measured Pressure reading is stable, select the Next  icon to continue.</p> <p>Note: Barometer sensor calibration requires two valid calibration points.</p>
<p>Step 4</p>		<p>Enter REFERENCE VALUE 1 as displayed on the external calibrated equipment. Press the Tick  softkey to confirm and return to the Calibration screen.</p>

Chapter 13. Instrument Calibration

Step 5		<p>Press the Next  softkey to complete Calibration point 1 and proceed to Calibration point 2.</p>
Step 6		<p>Apply Steps 3 to 5, but this time begin by applying the nominal positive full-scale pressure to the DPI 610E. When the measured Pressure reading is stable, select the Next  icon to continue. This completes Calibration point 2.</p>
Step 7		<p>After pressing the Next  icon from the previous step, a message window will appear. This window requests confirmation to perform the calibration adjustment based on the calibration points used in the procedure. Select OK to apply the calibration adjustment. Otherwise, select the Cancel button to return to the Calibration screen.</p>

Step 8	 	<p>If OK is selected, the CALIBRATION COMPLETE message appears in the status box, to confirm the adjustment has been made.</p> <p>At this stage, there are three icons for three ways to proceed. These are:</p> <ul style="list-style-type: none">  VERIFICATION softkey navigates to the Verification screen (see Step 9).  RESTART softkey allows the calibration procedure to be restarted if a repeat calibration is required.  BACK softkey exits the calibration procedure and returns the user to the Perform Calibration menu screen.
Step 9	 	<p>The Verification mode shows live reference and measured (or sourced) values.</p> <p>Here, different values or points within the measured (or sourced) range can be checked to verify the adjustment is satisfactory.</p> <p>Once verification is complete, select the Back  button to exit the Calibration procedure or select the Restart  softkey to repeat the calibration.</p>

13.3 INTERNAL PRESSURE SENSOR STATUS

The **Internal Pressure Sensor Status** screen (Figure 13-2) provides information about the instrument’s internal pressure sensor:




Figure 13-2: Instrument Status screen

To access the **Internal Pressure Sensor Status** screen (Figure 13-2), select **INTERNAL PRESSURE SENSOR STATUS** from the **Instrument Calibration** screen as shown below:

Step 1	A screenshot of the 'Instrument Calibration' screen. The screen has a black header with the title 'Instrument Calibration' in white. Below the header, the following options are listed: 'PERFORM CALIBRATION', '> INTERNAL PRESSURE SENSOR STATUS' (highlighted with a red rectangular box), 'SET CALIBRATION DATE & INTERVAL', 'BACKUP CALIBRATION', 'RESTORE CALIBRATION', and 'RESTORE FACTORY CALIBRATION'. At the bottom of the screen, there is a status bar showing the date and time '04 MAY 2022 14:28' and a battery level icon. A black curved arrow points from the right side of the screen towards the caption.	Select INTERNAL PRESSURE SENSOR STATUS from the Instrument Calibration screen.
--------	--	--

13.4 SET CALIBRATION DATE & INTERVAL

The following options are available in the **Instrument Calibration Date & Interval** screen:

Option	Description
LAST CALIBRATION	Set the date the instrument was last calibrated
CALIBRATION INTERVAL	Enable user notification by setting the number of days between the last calibration and the next scheduled calibration (default is 365 days)
CALIBRATION DUE	Enable user notification by setting a specific date to schedule next calibration (default is based on the date of the last calibration and the specified calibration interval)







Figure 13-3: Instrument Calibration Date & Interval screen

To access the **Instrument Calibration Date & Interval** screen (Figure 13-3), select **SET CALIBRATION DATE & INTERVAL** from the **Instrument Calibration** menu as shown below:





Chapter 13. Instrument Calibration

13.4.1 Change Last Calibration Date



Step 1		Select LAST CALIBRATION from the Instrument Calibration Date & Interval screen.
Step 2		Select the required day, month, and year, as required (see Chapter 1.19.3 on page 25). To change the value, select the row of the variable. Press the value on the left of the current value to decrease the value and the value on the right to increase the value. Repeat pressing of either left or right value decreases or increases the selected current value. Select ✓ to confirm the changes.

13.4.2 Change Calibration Interval

Step 1		<p>Select CALIBRATION INTERVAL from the Instrument Calibration Date & Interval screen.</p>
Step 2		<p>Enter a calibration interval between 7 and 548 (days).</p> <p>Select ✓ to confirm.</p>




Chapter 13. Instrument Calibration

13.4.3 Change Calibration Due Date

Step 1		Select CALIBRATION DUE from the Instrument Calibration Date & Interval screen.
Step 2		Select the required day, month and year, as required (see Chapter 1.19.3 on page 25). To change the value, select the row of the variable. Press the value on the left of the current value to decrease the value and the value on the right to increase the value. Repeat pressing of either left or right value decreases or increases the selected current value. Select ✓ to confirm the changes.

13.5 BACKUP CALIBRATION




The current calibration configuration can be saved in the form as a Backup file. This Backup file can be used to restore the instrument's calibration if necessary.

Step 1		<p>Select BACKUP CALIBRATION from the Instrument Calibration Date & Interval screen.</p> <p>Note: Only one user calibration configuration can be backed up at any one time.</p>
Step 2		<p>Select OK to confirm backup.</p>
Step 3		<p>Check that the CALIBRATION BACKUP notification appears. If the notification does not appear, repeat steps 1 and 2.</p>

13.6 RESTORE CALIBRATION




This function allows the user to restore a previous calibration configuration.

Note: A valid calibration backup file must exist, to enable this calibration restore feature to be available. See Section 13.5 on page 273 for how to create this file.

Step 1	 <p>The screenshot shows the 'Instrument Calibration' menu with options: PERFORM CALIBRATION, INTERNAL PRESSURE SENSOR STATUS, SET CALIBRATION DATE & INTERVAL, BACKUP CALIBRATION, > RESTORE CALIBRATION (highlighted with a red box), and RESTORE FACTORY CALIBRATION. The status bar at the bottom shows '04 MAY 2022 14:28' and a battery icon. A curved arrow points from the bottom right of the screen to the right.</p>	Select RESTORE CALIBRATION from the Instrument Calibration screen.
Step 2	 <p>The screenshot shows the 'Instrument Calibration' menu with the 'RESTORE CALIBRATION' dialog box open. The dialog box has a question mark icon, the title 'RESTORE CALIBRATION', and the text 'Restore to 04_DEC_2021_backup'. It has two buttons: 'OK' (highlighted with a red box) and 'Cancel'. The status bar at the bottom shows '04 MAY 2022 14:28' and a battery icon. A curved arrow points from the bottom right of the screen to the right.</p>	Select OK to confirm restore.
Step 3	 <p>The screenshot shows the 'Instrument Calibration' menu with the 'RESTORE CALIBRATION' dialog box open. The dialog box has an exclamation mark icon, the title 'RESTORE CALIBRATION', and the text 'Restore calibration successful 04_DEC_2021_current'. It has one button: 'OK'. The status bar at the bottom shows '04 MAY 2022 14:28' and a battery icon. A curved arrow points from the bottom right of the screen to the right.</p>	Check that the CALIBRATION RESTORE notification appears. If the notification does not appear, repeat steps 1 and 2.


13.7 RESTORE FACTORY CALIBRATION

The instrument has its factory calibration saved internally before it is delivered from our factory. If for any reason (for example, if an incorrect calibration adjustment has been made), the instrument needs its calibration resetting to the point at which it was shipped, the **Restore Factory Calibration** feature can be used

Step 1		<p>Select RESTORE FACTORY CALIBRATION from the Instrument Calibration screen.</p>
Step 2		<p>A valid factory calibration file will be automatically retrieved and displayed in the popup message. Select OK to confirm restore.</p>
Step 3		<p>Check that the FACTORY CALIBRATION RESTORE notification appears.</p>


13.8 EXTERNAL PRESSURE SENSOR CALIBRATION MENU

See Section 13.1 on page 252 for how to access the **Calibration** menu from the Dashboard.


Step 1		Select EXTERNAL PRESSURE SENSOR from the main Calibration screen. Note: To see the External Pressure Sensor option, the EXT Pressure function must be already configured in the Calibrator menu and the sensor connected successfully. See Section 8, “External Sensors,” on page 141.
--------	---	---

13.8.1 PERFORM CALIBRATION

To calibrate the external pressure sensor PM700E using the DPI 610E, make sure the correct pressure connection is made from the sensor and the external calibrated pressure source. Also, ensure the sensor is connected to the **EXT SENSOR** port on the DPI 610E using the sensor cable supplied. This sensor calibration should only be done by approved service centres and personnel.

Step 1		Select PERFORM CALIBRATION from the External Sensor Calibration menu screen.
--------	---	--

EXTERNAL PRESSURE SENSOR CALIBRATION MENU

Step 2		<p>The calibration procedure of the external PM700E sensor is like that of the DPI 610E internal pressure sensor. See Section 13.2.2, "Calibration - Internal Pressure Sensor," on page 260.</p>


13.8.2 VIEW EXTERNAL PRESSURE SENSOR STATUS

The **External Pressure Sensor Status** screen (Figure 13-4) provides information about the instrument's external pressure sensor.



Figure 13-4: External Pressure Sensor Status

To access the **External Pressure Sensor Status** screen:

Step 1		<p>Select VIEW SENSOR STATUS from the External Sensor Calibration screen.</p>

Chapter 13. Instrument Calibration

13.8.3 SET CALIBRATION DATE & INTERVAL

The **External (Pressure) Sensor Calibration Status (Date & Interval)** screen provides the following options:

Option	Description
LAST CALIBRATION	Set the date the instrument was last calibrated
CALIBRATION INTERVAL	Enable user notification by setting the number of days between the last calibration and the next scheduled calibration (default is 365 days)
CALIBRATION DUE	Enable user notification by setting a specific date to schedule next calibration (default is based on the date of the last calibration and the specified calibration interval)






Figure 13-5: External Sensor Calibration Date & Interval Screen

To access the **SET CALIBRATION DATE & INTERVAL** screen:

Step 1	A screenshot of the 'External Sensor Calibration' screen. The screen has a black header with the title 'External Sensor Calibration'. Below the header, there are three rows of text: 'PERFORM CALIBRATION', 'VIEW SENSOR STATUS', and '> SET CALIBRATION DATE & INTERVAL'. The third row is highlighted with a red border. At the bottom of the screen, there is a status bar showing a battery icon, the date and time '04 MAY 2022 14:28', and a signal strength icon. A large black arrow points from the right side of the screen towards the 'SET CALIBRATION DATE & INTERVAL' option.	Select SET CALIBRATION DATE & INTERVAL screen from the External Sensor Calibration screen.
--------	--	--

EXTERNAL PRESSURE SENSOR CALIBRATION MENU

13.8.3.1 Change LAST CALIBRATION Date



Step 1		<p>Select LAST CALIBRATION from the External Sensor Calibration Status screen.</p>
Step 2		<p>Select the required day, month, and year, as required (see Section 1.19.3, "Set Date, Time and Language," on page 25). To change the value, select the row of the variable. Press the value on the left of the current value to decrease the value and the value on the right to increase the value. Repeat pressing of either left or right value decreases or increases the selected value.</p> <p>Select ✓ to confirm the changes.</p>

13.8.3.2 Change CALIBRATION INTERVAL

Step 1	<div><div>External Sensor Calibration Status</div><div><div>LAST CALIBRATION</div><div>01 JAN 2021</div></div><div><div>> CALIBRATION INTERVAL</div><div>365 days</div></div><div><div>CALIBRATION DUE</div><div>04 DEC 2022</div></div></div> <div><div>04 MAY 2022 14:28</div><div></div></div> <div></div>	Select CALIBRATION INTERVAL from the External Pressure Sensor Status screen.
Step 2	<div><div>Instrument Calibration Interval</div><div><div>INTERVAL</div><div>365</div></div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div><div>6</div><div>7</div><div>8</div><div>9</div><div>0</div><div></div><div>CLR</div></div></div> <div><div>04 MAY 2022 14:28</div><div></div></div> <div></div>	Enter a calibration interval between 7 and 548 (days). Select ✓ to confirm.


EXTERNAL PRESSURE SENSOR CALIBRATION MENU

13.8.3.3 Change CALIBRATION DUE Date

Step 1		Select CALIBRATION DUE from the Instrument Calibration Date & Interval screen.
Step 2		Select the required day, month and year, as required (see Section 1.19.3, "Set Date, Time and Language," on page 25). To change the value, select the row of the variable. Press the value on the left of the current value to decrease the value and the value on the right to increase the value. Repeat pressing of either left or right value decreases or increases the selected current value. Select ✓ to confirm the changes.


13.9 EXTERNAL RTD SENSOR CALIBRATION MENU

Refer to Section 8 on page 141 for how to configure the DPI 610E to recognize and use an external RTD sensor. This is necessary to enable the DPI 610E user interface to show the RTD sensor calibration options.



Step 1		<p>Select EXTERNAL RTD SENSOR from the main Calibration menu.</p> <p>Note: To see the External RTD Sensor option, the RTD function must be already configured in the Calibrator menu and the sensor connected successfully. Use the cross-reference given at the top of this page for instructions.</p>
--------	---	---

13.9.1 PERFORM CALIBRATION







To calibrate the external RTD sensor using the DPI 610E, make sure the correct connection is made between the RTD & RTD-Interface and the external calibrated resistance/temperature source. Also, make sure the RTD-Interface is connected to the **EXT SENSOR** port on the DPI 610E using the sensor cable supplied. This sensor calibration should only be done by approved service centres and personnel in accordance with the instructions in Section 8 on page 141. To access the **External Sensor Calibration** (RTD) screen. Follow the steps below:

Step 1		<p>Select PERFORM CALIBRATION from the External Sensor Calibration screen.</p>
--------	---	--








EXTERNAL RTD SENSOR CALIBRATION MENU

<p>Step 2</p>		<p>This screen has three sections. The top two sections give:</p> <ul style="list-style-type: none"> • The reference reading from external calibrated equipment • The measured (or sourced) reading from the DPI 610E. <p>The bottom section gives the following information:</p> <ol style="list-style-type: none"> 1. Function minimum range (or negative full-scale) value 2. Function maximum range (or positive full-scale) value 3. Calibration procedure step status (visual status boxes and text status) 4. User instructions for each step of the procedure. <p>To start the calibration, apply nominal negative full-scale or zero value as per the displayed instruction. This is Calibration point 1. When the measured temperature or resistance reading is stable, select the Next icon to continue.</p> <p>Note: RTD sensor calibration requires two valid calibration points.</p>
<p>Step 3</p>		<p>Enter REFERENCE VALUE 1 as displayed on the external calibrated equipment. Press the Tick ✓ softkey to confirm and return to the Calibration screen.</p>

Chapter 13. Instrument Calibration

Step 4		<p>Press the Next  softkey to complete Calibration Point 1 and proceed to Calibration Point 2.</p>
Step 5		<p>Repeat Steps 2 to 4, but begin by applying the nominal positive full-scale resistance or temperature value to the DPI 610E. This completes Calibration Point 2.</p> <p>Press the Next  softkey to show the next screen.</p>
Step 6		<p>After pressing Next  from the previous step, a message window will appear, requesting confirmation to perform the calibration adjustment based on the calibration points used in the procedure. Select OK to apply the calibration adjustment. Otherwise, select the Cancel button to return to the Calibration screen</p>

EXTERNAL RTD SENSOR CALIBRATION MENU

Step 7		<p>If OK is selected, the CALIBRATION COMPLETE message appears in the status box, to confirm the adjustment has been made.</p> <p>At this stage, there are three icons for three ways to proceed. These are:</p> <ul style="list-style-type: none">  VERIFICATION softkey navigates to the Verification screen (see Step 8).  RESTART softkey allows the calibration procedure to be restarted if a repeat calibration is required.  BACK softkey exits the calibration procedure and returns the user to the Perform Calibration menu screen.
Step 8		<p>The verification mode shows live reference and measured (or sourced) values.</p> <p>Here, different values or points within the measured (or sourced) range can be checked to verify the adjustment is satisfactory.</p> <p>Once verification is complete, select the Back  icon to exit the calibration procedure or select the Restart  softkey to repeat the calibration.</p>

Chapter 13. Instrument Calibration

13.9.2 SET CALIBRATION DATE & INTERVAL

The **External (RTD) Sensor Calibration Status** screen has the following options:

Option	Description
LAST CALIBRATION	Set the date the instrument was last calibrated
CALIBRATION INTERVAL	Enable user notification by setting the number of days between the last calibration and the next scheduled calibration (default is 365 days)
CALIBRATION DUE	Enable user notification by setting a specific date to schedule next calibration (default is based on the date of the last calibration and the specified calibration interval). This is View Only - this variable cannot be changed on this screen.






Figure 13-6: External Sensor Calibration (Date & Interval) Status Screen

To access the **External RTD Calibration Date & Interval** screen:

Step 1		Select SET CALIBRATION DATE & INTERVAL from the External Sensor Calibration screen.
--------	--	---

EXTERNAL RTD SENSOR CALIBRATION MENU

13.9.2.1 Change Last Calibration Date



Step 1		<p>Select LAST CALIBRATION from the Instrument Calibration Date & Interval screen.</p>
Step 2		<p>Select the required day, month, and year, as required (see Section 1.19.3 on page 25). To change the value, select the row of the variable. Press the value on the left of the current value to decrease the value and the value on the right to increase the value. Repeat pressing of either left or right value decreases or increases the selected current value.</p> <p>Select ✓ to confirm the changes.</p>

Chapter 13. Instrument Calibration

13.9.2.2 Change Calibration Interval

Step 1	<div><div>External Sensor Calibration Status</div><div><div>LAST CALIBRATION</div><div>01 JAN 2021</div></div><div><div>> CALIBRATION INTERVAL</div><div>365 days</div></div><div><div>CALIBRATION DUE</div><div>04 DEC 2022</div></div></div> <div><div></div><div>04 MAY 2022 14:28</div></div>	Select CALIBRATION INTERVAL from the External Sensor Calibration Status screen.
Step 2	<div><div>Calibration Interval</div><div><div>INTERVAL</div><div>365</div></div><div><div>1</div><div>2</div><div>3</div><div><X</div></div><div><div>4</div><div>5</div><div>6</div><div></div></div><div><div>7</div><div>8</div><div>9</div><div>CLR</div></div><div><div>0</div><div></div></div></div> <div><div></div><div>04 MAY 2022 14:28</div></div>	Enter a calibration interval between 7 and 548 (days). Select ✓ to confirm.



13.9.2.3 Change Calibration Due Date

Step 1		<p>Select CALIBRATION DUE from the Instrument Calibration Date & Interval screen.</p>
Step 2		<p>Select the required day, month and year, as required (see Section 1.19.3 on page 25). To change the value, select the row of the variable. Press the value on the left of the current value to decrease the value and the value on the right to increase the value. Repeat pressing of either left or right value decreases or increases the selected current value.</p> <p>Select ✓ to confirm the changes.</p>

14. Files System

The **Files** system menu provides access to all user files stored in the internal memory of the DPI 610E. It is accessible from the Dashboard screen and displays a structure of directories used to organize the files for easy and reliable viewing.

14.1 How to access the Files system menu

Step 1		Select the Files softkey from the Dashboard.
Step 2		Select the required folder from the Files menu. In this example, the Calibration folder is selected.

14.1.1 The Files system screen options

Option	Description
Calibration	Export / View instrument calibration files
Data Log	View / Open / Delete data log files
Procedures	View / Delete test procedures, assets, and results files
Leak Test	View saved leak test result files
Switch Test	View saved switch test result files
Relief Valve	View saved relief valve test result files
Favorites	View a task or channel configuration saved as a Favorite
Error Log	Export / View error log files
Event Log	Export / View event log files

14.2 Calibration

When the **Calibration** folder is selected, any previously exported calibration files will be listed.

If no export has been done before, select the **Export**  softkey to generate the calibration files stored on the unit. There are three types of calibration files:

Factory Calibration – this is the default calibration done on the instrument in the factory prior to shipping. It is saved in permanent storage and cannot be accessed directly or deleted by the user.

Current Calibration – this is the calibration data used by the instrument at any moment in time. If the instrument is new and has not been used, the Current calibration will be the Factory calibration. After calibration adjustment has been done on the instrument, this new data will replace the factory calibration data as the new Current calibration. Subsequent calibrations will overwrite this user calibration data.

Backup Calibration – if the **Backup** calibration feature is used (See Section 13.5 on page 273), a copy of the Current Calibration data is saved as a Backup data file.






Figure 14-1: Calibration Files screen


14.3 Data Log

Select the **Data Log** folder, to show a list of log files saved on the instrument. The log files are accessed, and their contents displayed from this menu.

Delete unwanted log files by the use of either the **Single Delete**  softkey for single files, or the **Delete All**  softkey for all log files.

Data Log File1/2

FILENAME	CH1	CH2
>File 1	PInt	mA{M}
File 2	PInt	mA{M}
File 3	PInt	mA{M}
File 4	PInt	mA{M}
File 5	PInt	mA{M}
File 6	PInt	mA{M}
File 7	PInt	mA{M}

04 MAY 2022 14:28









Figure 14-2: Data Log files screen

14.4 Procedures


The **Procedures** option provides a list of all test procedures created or uploaded and saved on the instrument by the **Documenting** function (see Chapter 11 on page 178). To view the list of available internal procedures, select the **Local (Procedures)** sub-folder and to view the list of stored 4Sight2 procedures, select the **Remote** sub-folder.


Note: Only the list of files can be viewed in the **Files** application. There is the option to delete unwanted procedure files within each sub-folder by using either the **Single Delete**  softkey to delete individual files or the **Delete All**  softkey to delete all files in the sub-folder:

Files/Procedures

Local


Remote

04 MAY 2022 14:28



Local1/2

FILENAME
>File 1
File 2
File 3
File 4
File 5
File 6
File 7

04 MAY 2022 14:28









Figure 14-3: Local Procedures files

14.5 Leak Test

The **Leak Test Results** folder displays a list of saved results files from completed leak tests. This is view only: details of the test results can be viewed by opening the file on a PC.

Unwanted results files within the folder can be deleted the use of either the **Single Delete**  softkey (to delete individual files) or the **Delete All**  softkey (to delete all files in the sub-folder).






Figure 14-4: Leak Test Results screen

14.6 Switch Test

The **Switch Test Results** folder displays a list of saved results files from completed switch tests. This is view only: details of the test results can be viewed by opening the file on a PC.

Unwanted results files within the folder can be deleted the use of either the **Single Delete**  softkey (to delete individual files) or the **Delete All**  softkey (to delete all files in the sub-folder).






Figure 14-5: Switch Test files screen

14.7 Relief Valve

The **Relief Valve Results** folder displays a list of saved results files from completed Relief Valve tests. This is view only: details of the test results can be viewed by opening the file on a PC.

Unwanted results files within the folder can be deleted the use of either the **Single Delete**  softkey (to delete individual files) or the **Delete All**  softkey (to delete all files in the sub-folder).






Figure 14-6: Switch Test files screen

14.8 How to view the File System on a PC

To access the contents of the internal storage of the DPI 610E: first connect the DPI 610E, using the micro-USB cable supplied (or any compatible mini-USB cable) to the USB port of the PC.


From the device Dashboard, select the **Settings**  softkey, then select USB: change the USB setting to “Storage” if not already set. This allows the DPI 610E device to appear as a mass storage drive labeled “DPI610E” or “DPI610E-IS” in the Windows File Explorer on the PC.



The contents of the DPI 610E storage are similarly structured to what can be viewed on the device in terms of the folder structure. The **HART** folder is the exception, because its folder and contents can only be accessed from a PC.

It is possible to copy files in the device storage to a different file location on the PC or files can be deleted to free up space on the device.

Double-click on the DPI 610E drive and select the required **File System** folder from the root directory.



Name	Date modified	Type	Size
Calibration		File folder	
DataLog		File folder	
DocData		File folder	
ErrorLog		File folder	
EventLog		File folder	
Favorites		File folder	
HART		File folder	
LeakTest		File folder	
SwitchTest		File folder	
DK0492.raw	01/02/2022 11:29	RAW File	1,642 KB

14.9 Favorites, Error Log and Event Log

Refer to Chapter 16, “Favorites Menu,” on page 304 for information about how to use the **Favorites** function.

Refer to Section 15.8 on page 302 for information about how to use the **Error Log** function.

Refer to Section 15.9 on page 303 for information about how to use the **Event Log** function.

15. Status Menu



15.1 Status Menu Options

The **Status** menu is a read-only menu that provides important information about the DPI 610E instrument. It is accessible from the Dashboard and has the following view options:




Table 15-1: Status Menu Options

Option	Description
SOFTWARE BUILD	View software build installed on the instrument
CALIBRATION	View Calibration information (instrument and external sensors)
BATTERY	View battery status
MEMORY	View internal memory status
SENSOR	View Sensor information (instrument and external sensors)
ERROR LOG	Export (and view) error log files
EVENT LOG	Export (and view) event log files





15.2 How to show the Status menu screen

Step 1		Select the Status (Information) softkey from the Dashboard.
Step 2		A screen of Status menu options appears. To select the row that has the required option, tap on the row or use the Navigation pad.





15.3 SOFTWARE BUILD

Step 1		<p>In the Status menu screen select the SOFTWARE BUILD row, to show the Status - SOFTWARE BUILD screen.</p>
Step 2		<p>The Status - SOFTWARE BUILD screen shows the MAIN APPLICATION (DK492) and the BOOTLOADER (DK491) build version information.</p> <p>In addition, a QR  softkey is available which when selected navigates to the programming tool information screen. This screen provides the URL and scanable QR code. This code takes the user to where the software programming tool can be downloaded with instructions on how to use it to perform software upgrades</p>

15.4 CALIBRATION

Step 1		<p>In the Status menu screen select the CALIBRATION row, to show the Status - Calibration screen.</p>
Step 2		<p>The Status - Calibration screen shows the INSTRUMENT (or sensor) option. Note: For the EXTERNAL PRESSURE SENSOR option to be available in this screen, the EXT pressure (see Section 8.1.6 on page 144) or EXTERNAL RTD function (see Section 8.2.4 on page 150) must be configured in the Calibrator menu.</p>
Step 3		<p>View the instrument (or sensor) details.</p> <p>Select the Back  softkey to return to the Status - Calibration menu</p>





15.5 BATTERY

Step 1	 	In the Status menu screen select the BATTERY row, to show the Status - Battery screen.
Step 2	 	The Status - Battery screen shows the current instrument battery level and if the battery is either discharging or being charged.

15.6 MEMORY

Step 1	<div><div>Status</div><div><div>SOFTWARE BUILD</div><div>CALIBRATION</div><div>BATTERY</div><div>> MEMORY</div><div>SENSOR</div><div>ERROR LOG</div><div>EVENT LOG</div></div><div>04 MAY 2022 14:28 <div></div></div></div> <div></div>	In the Status menu screen select the MEMORY row, to show the Status - Memory screen.
Step 2	<div><div>Status - Memory</div><div><div>INTERNAL MEMORY</div><div><div><div>■</div>Used Space51%(15.00MB)</div><div><div>□</div>Free Space49%(14.00MB)</div></div><div><div></div><div>029 MB</div></div></div><div>04 MAY 2022 14:28 <div></div></div></div> <div></div>	The Status - Memory screen shows the current free and used space in the instrument's internal memory.

15.7 SENSOR






Step 1		<p>In the Status menu screen select the SENSOR row, to show the Status - Sensor screen.</p>
Step 2		<p>The Status - Sensor screen appears because the instrument has been configured to use an external sensor (see Section 8.1.6 on page 144.)</p> <p>Note: For the EXTERNAL SENSOR option to be available in this screen, the EXT pressure or RTD function must be configured in the Calibrator menu and the sensor successfully connected: refer to Chapter 8 on page 141 for information.</p>
Step 3		<p>View the sensor details.</p> <p>Select the Back  softkey to return to the Status - Sensor screen.</p>

15.8 ERROR LOG

The DPI 610E records detailed information whenever it encounters any operational software or firmware issues.

Note: Each time the **ERROR LOG** is selected, an export of the currently logged errors is automatically created as a CSV file. This export file(s) is displayed in the **Error Log** screen but can only be opened if transferred and accessed from a PC: (refer to Section 9.6.1 on page 167 for how to find and read these files).

15.8.1 How to export and view Exported Error Log files






Step 1		<p>Select the ERROR LOG from the Status menu screen.</p> <p>Note: A “Please Wait” popup message will appear while the log file is being created. It may take up to 1 minute to complete.</p>
Step 2		<p>View the list of ERROR LOG files.</p> <p>To delete all files in the list, tap (or press the associated softkey) the Multiple trashcan (Delete All)  icon. A message window appears asking “Delete all files?”. Select OK or Cancel.</p> <p>Press the down  icon to show one more page of available files.</p> <p>Press the Back  icon to go back to the Status screen.</p>

15.9 EVENT LOG

The DPI 610E records detailed information about significant events that occur on the instrument during operation. These events can include errors, warnings, etc.

Note: Each time the **EVENT LOG** is selected, an export of the currently logged system events is automatically created as a CSV file. This export file(s) is displayed in the **Event Log** screen but can only be opened if transferred and accessed from a PC: (refer to Section 9.6.1 on page 167 for how to find and read these files).

15.9.1 How to export and view Exported Event Log files




Step 1		<p>Select the EVENT LOG from the Status menu screen.</p> <p>Note: A “Please Wait” popup message will appear while the log file is being created. It may take up to 1 minute to complete.</p>
Step 2		<p>View the list of Event Log files.</p> <p>To delete all files in the list, tap (or press the associated softkey) the Multiple trashcan (Delete all)  icon. A message window appears asking “Delete all files?”. Select OK or Cancel.</p> <p>Press the down  icon to show one more page of available files.</p> <p>Press the Back  icon to go back to the Status screen.</p>

16. Favorites Menu

16.1 Favorites Menu Options




A currently active task or channel configuration can be saved as a Favorite. This includes all channel setup parameters i.e., units, Process options, digit resolution and any other associated configurations.

This saved configuration can be selected to automatically load and configure the Calibrator task. Up to 10 Favorite configurations can be saved.

Step 1		<p>Select the Favorites icon or softkey from the Dashboard.</p>
Step 2		<p>The Favourites screen appears. The list on this screen will be empty if no Favorites are available.</p> <p>Select the Add New ☆ softkey to show the Add New Favorite task screen.</p>
Step 3		<p>There are two methods available to save a Favorite configuration:</p> <ol style="list-style-type: none"> 1. SAVE CURRENT CALIBRATOR TASK. See Section 16.1.1 on page 305. 2. CREATE NEW to save a new configuration. See Section 16.1.2 on page 307. <p>Click on a row to select the method.</p>

16.1.1 Save Current Calibrator Task

To save the current Calibrator task and all its settings as a Favorite, first make sure the desired configuration has been made within the Calibrator application.

Step 1		<p>This example screen relates to a Calibrator task for a Leak Test and Current Measure.</p> <p>Select the Back ↩ icon on this screen to show the Dashboard screen.</p> <p>Select the Favorites ☆ softkey from the Dashboard. (For this screen image see Step 1 in Section 16.1 on page 304).</p>
Step 2		<p>Select the Add New ☆ softkey in the Favorites screen.</p>
Step 3		<p>Select the SAVE CURRENT CALIBRATOR TASK option in the Add New Favorite task screen.</p>

Step 4

Favorites

SAVE TASK AS

2022-MAY-04_14-28-03

Max. 20 Characters

QWERTYUIOP

ASDFGHJKL

ZXCVBNM

04 MAY 2022 14:28

✓

↩

Favorites

> 2022-MAY-04_14-28-01

2022-MAY-04_14-28-02

2022-MAY-04_14-28-03

04 MAY 2022 14:28

🗑️

📝

★

↩







Enter a new file name into the **SAVE TASK AS** field or accept the default file name based on the current date. To save the configuration select the **Tick** ✓ softkey. (Maximum characters: 20).

The new configuration file appears in the list in the **Favorites** screen.






Copyright 2022 Baker Hughes Company.
306 | DPI 610E Instruction Manual–English

16.1.2 Save New Configuration as Favorite


This option allows manual configuration of the individual channels within the **Favorites** menu.

Step 1		<p>Select the Favorites  softkey from the Dashboard. (For this screen image see Step 1 in Section 16.1 on page 304).</p> <p>Select the Add New  softkey from the Favorites screen.</p>
Step 2		<p>Select the CREATE NEW option.</p>
Step 3		<p>The Favorites CH1 Setup screen will appear in its current configuration. Select any of the setup parameters to change. When the setup is complete, select the Next  softkey to move to the Favorites CH2 Setup screen.</p>

Chapter 16. Favorites Menu



Step 4		Change any of the setup parameters in the Favorites CH2 Setup screen if required and then select the Save  softkey.
Step 5		Enter the new file name into the NEW TASK NAME field Favorites screen (or accept the default file name based on the current date). Select the Tick  softkey to save the configuration. (Maximum characters: 20).
Step 6		The new configuration file appears in the list in the Favorites screen.

16.2 To Load a Favorites Configuration


From the **Favorites** menu, navigate to the desired saved **Favorites** file by tapping the filename or using the Up/Down button on the navigation keypad. Tap again to load the configuration or press the **Enter**  button if using the navigation keypad.

16.3 Edit an Existing Favorite File

From the **Favorites** menu, navigate to the desired saved **Favorites** file by tapping the file name or using the Up/Down button on the navigation keypad.

Select the **Edit** softkey  to make changes to the Favorites file configuration. Once the edit is complete, select the **Save**  softkey to save the changes made.

16.4 Delete Favorite Files


From the **Favorites** menu, navigate to the desired saved **Favorites** file by tapping the file name or using the Up/Down button on the navigation keypad. Select the **Delete**  softkey to delete the file.

16.5 Transferring Favorite Files

Favorite configuration files can be accessed from a PC via the USB cable connection and appear in the **Favorites** folder in the root directory of the DPI 610E. Use the Windows **Copy** command to copy a file to another folder. These configuration files can then be moved into another DPI 610E instrument and used within that instrument.

Note: Care must be taken when transferring these files to make sure the DPI 610E share the same supported functionality. For example, transferring a configuration file involving the Barometer function from a pneumatic DPI 610E variant to a hydraulic variant which does not support the Barometer function.

16.6 Accessing Favorite Files via the File System

Saved **Favorites** configuration files can be viewed in the File System menu by selecting the File System  softkey from the Dashboard and choosing the **Favorites** folder. Refer to Section 14.8 on page 294 for more information.

17. General Specification

Refer to www.druck.com/dpi610e for the Datasheet that gives the technical specifications for the DPI 610E.

17.1 Open Source Software Licenses

Two files are available with the software installation:

1568-notices-report-08_08_2022_17_04.txt covers DK0491 DPI610E Bootloader.

1563-notices-report-08_08_2022_16_01.txt covers DK0492 DPI610E Main Application.

18. Manufacturer

18.1 Contact details

Druck Limited
2 Fir Tree Lane
Groby
Leicester
LE6 0FH
United Kingdom

Tel: +44 (0)116 231 7100
www.Druck.com

Office Locations

Headquarters

Leicester, UK
☎ +44 (0) 116 2317233
✉ gb.sensing.sales@bakerhughes.com

China

Guangzhou
☎ +86 173 1081 7703
✉ dehou.zhang@bakerhughes.com

Germany

Frankfurt
☎ +49 (0) 69-22222-973
✉ sensing.de.cc@bakerhughes.com

Japan

Tokyo
☎ +81 3 6890 4538
✉ gesitj@bakerhughes.com

Taiwan

Hukou
☎ 886 3 6123148
✉ gb.sensing.sales@bakerhughes.com

Australia

North Sydney
☎ 1300 171 502
✉ custcare.au@bakerhughes.com

China

Shanghai
☎ +86 135 6492 6586
✉ hensen.zhang@bakerhughes.com

India

Bangalore
☎ +91 9986024426
✉ aneesh.madhav@bakerhughes.com

Netherlands

Hoevelaken
☎ +31 334678950
✉ nl.sensing.sales@bakerhughes.com

UAE

Abu Dhabi
☎ +971 528007351
✉ suhel.aboobacker@bakerhughes.com

China

Beijing
☎ +86 180 1929 3751
✉ fan.kai@bakerhughes.com

France

Toulouse
☎ +33 562 888 250
✉ sensing.FR.cc@bakerhughes.com

Italy

Milan
☎ +39 02 36 04 28 42
✉ csd.italia@bakerhughes.com

South Korea

Seongnam-si
☎ +82 31 620 6671
✉ Hyunmin.Kim@bakerhughes.com

USA

Boston
☎ 1-800-833-9438
✉ custcareboston@bakerhughes.com

Services and Support Locations

Tech Support

Global
✉ drucktechsupport@bakerhughes.com

France

Toulouse
☎ +33 562 888 250
✉ sensing.FR.cc@bakerhughes.com

UAE

Abu Dhabi
☎ +971 2 4079381
✉ gulfservices@bakerhughes.com

Brazil

Campinas
☎ +55 19 2104 6924, +55 19 97169 1190
✉ cc.sensing.brasil@bakerhughes.com

India

Pune
☎ +91-2135-620421~425
✉ mcindia.inhouseservice@bakerhughes.com

UK

Leicester
☎ +44 (0) 116 2317107
✉ sensing.grobycc@bakerhughes.com

China

Changzhou
☎ +86 400 818 1099
✉ service.mcchina@bakerhughes.com

Japan

Tokyo
☎ +81 3 6894 1838
✉ service.druck.jp@bakerhughes.com

USA

Billerica
☎ +1 (281) 542-3650
✉ namservice@bakerhughes.com