

# Calibration Test Pump CPP 60-T (pneumatic) Pressure-/Vacuum-generation -28 in Hg...+870 psi

Calibration Test Pump CPP 60-T, pneumatic operated to generate pressure up to +60 bar / +870 PSI switchable to generate vacuum up to -0.95 bar / -28 inHg

The Calibration Test Pump **CPP 60-T** is used to generate pressures and vacuum for checking, adjusting and calibrating mechanical and electronic pressure measuring instruments by comparative measurements. These pressure tests may be carried out in laboratories, workshop or on site at the measuring point. If the instrument under test and a sufficiently accurate reference measuring instrument (e.g. Electronic Pressure Calibrator LPC 300 or LPC 200, ±0.025% FS) are connected to the **CPP 60-T**, the same pressure / vacuum is applied to the two instruments when the pump is operated.

Despite its compact dimensions, the calibration test pump CPP 60-T is easy to operate and allows for exact generation of the required test pressures. A change-over switch enables the generation of vacuum as well. The CPP 30 is fitted with a

fine adjustment valve for the precise adjustment of pressures. The reference instrument is screwed directly on to the top of the pump and the unit under test is connected by means of a connection tube incorporating an adapter 1/4" BSP rotating female (optional 1/4" NPT female) port.

## Specification:

**Pressure** generation: 0...60 bar = 0...870 PSI (or equivalent), switchable to

**Vacuum** generation: 0...-0.95 bar = 0...-28 inHG (or equivalent)

Pressure ports: 1/2" BSP female rotating (with seal) for reference instrument on the top of the pump

(Type LPP-60-T-N14: 1/4" NPT female, type LPP-60-T-G14: 1/4" BSP female rotating)

1/4" BSP female for unit under test (at connection tube)

Tel.: 03303 / 504066

Fax: 03303 / 504068

(Type LPP-60-T-N14: 1/4" NPT female)

Volume per stroke: appr. 11 cm<sup>3</sup>

Materials: anodized aluminum, brass, ABS

Fine adjustment: Fine adjustment valve
Dimension: appr. 150 x 300 x 215 mm

Weight: appr. 2.55 kg

#### Included in standard supply:

- Calibration test pump CPP 60-T
- Connection tube with female rotating pressure port
- Operating manual

#### **Optional accessories:**

- Set of adapters and seals for unit under test
- Carrying case with custom foams



# Calibration Test Pump CPP 60-T (pneumatic) Pressure-/Vacuum-generation -28 in Hg...+870 psi

### **Order-Codes:**

Description		Order CodeC
<b>PP 60-T</b> Calibration Test Pump -0,95+60 bar (-28 in Hg+870 psi) NOTE: if you dismount the reference connector, you get 3/8" BSP female port		CPP-60-T
ditto, but reference port 1/4" BSP female rotating		CPP-60-T-G14
ditto, but reference port and test port 1/4" NPT female		CPP-60-T-N14
Set of BSP adapters and set of seals 1/8" BSP, 3/8" BSP and 1/2" BSP		CPP-ADAPTER-BSP
Set of metric adapters and set of seals M12x1,5 M20x1,5 and Minimess®		CPP-ADAPTER-M
Set of <b>NPT adapters</b> 1/8" NPT, 1/4" NPT, 3/8" NPT, 1/2" NPT		CPP-ADAPTER-NPT
Carrying case with foams		CPP-60-T-KOFFER
<b>CPP-MANO</b> analogue reference gauge DS 63 ±1% FS, 0 2 bar and 0 30 PSI - fine graduation	15 10 25 10 20 10 500 500 500 500 500 500 500 500 500	CPP-MANO-0002
ditto, but range 0 11 bar and 0 160 psi		CPP-MANO-0011
ditto, but range 0 25 bar and 0 365 psi		CPP-MANO-0025
ditto, but range 0 40 bar and 0 600 psi		CPP-MANO-0040
ditto, but range -1 0 bar and -30 0 inHg		CPP-MANO-0000
ditto, but range -1+39 bar and -30 in Hg +580 psi		
Spare part: Test tube with 1/4" BSP female port		CPP-SCHLAUCH
Spare part: Fine adjustment valve with relief valve		CPP-VENTIL
Service Kit for CPP 60-T (O-rings, seals, etc.)		CPP-WARTUNG





info@ics-schneider.de

www.ics-schneider.de

- (1) pressure port for mounting reference pressure instrument
- (2) fine volume adjustment, for generating high pressure appr. 40...60 bar and fine pressure adjustment
- (3) pressure relief valve
- (4) Switch pressure generation / vacuum generation
- (5) pressure port for test item

Tel.: 03303 / 504066

Fax: 03303 / 504068

(6) pump to generate pressure up to appr. 40 bar